Cost report : Supporting material file

Some abbreviations were used to realise the BOM. Here are the details of the abbreviations:

_ Fr: Front
_ Rr: Rear
_ Male r: Male right hand
_ Male l: Male left hand
_ Btw: Between
_ HP : High Pressure
_ LP: Low Pressure
_MC: Master Cylinder
_ ARB : Anti-Roll Bar
_ brack : bracket

All the part and assembly number are connected with a hyperlink to their sheet with their pictures and drawings.

The specified part number doesn't always correspond to the drawing number on pictures in the cartouche.

system	assembly	sub_ assembly	assembly_ no	part	part_comments	m/ b	part_ qty	part_no
BR	Brake System Front	BR_A0100						
BR	Brake System Front		BR_A0100	Front brake rotor	230 mm cast iron disc	b	2	BR_01001
BR	Brake System Front		BR_A0100	Front brake caliper	Beringer 2P1A, dual piston 32mm bore	b	2	BR_01002
BR	Brake System Front		BR_A0100	Front brake reservoir	tank to store brake fluid	b	1	BR_01003
BR	Brake System Front		BR_A0100	Rotor button	to assemble brake rotor and shrink disc	b	12	BR_01004
BR	Brake System Front		BR_A0100	Adapter	Adapter for pressure sensors	m	1	BR_01005
BR	Brake System Front		BR_A0100	Front brake circuit	Hoses stainless lines with fittings	m	1	BR_01006
BR	Brake System Rear	BR_A0200						
BR	Brake System Rear		BR_A0200	Rear brake rotor	Sold attached with the rear brake bell	b	2	BR_02001
BR	Brake System Rear		BR_A0200	Rear brake caliper	B├®ringer 2D1, dual piston 27mm bore	b	2	BR_02002
BR	Brake System Rear		BR_A0200	Rear brake reservoir	tank to store brake fluid	b	1	BR_02003
BR	Brake System Rear		BR_A0200	Adapter	Adapter for pressure sensors	m	1	BR_02004
BR	Brake System Rear		BR_A0200	Rear brake circuit	Hoses stainless lines with fittings	m	1	BR_02005
BR	Brake Master Cylinder	BR_A0300						
BR	Brake Master Cylinder		BR_A0300	Master Cylinder	Bought from Beringer	b	2	BR_03001
BR	Balance Bar	BR_A0400						
BR	Balance Bar		BR_A0400	Balance bar	Bought from Reverchon	b	1	BR_04001
BR	Balance Bar		BR_A0400	Master Cylinder support	Threaded aluminum part	m	2	BR_04002
EL	Dash Panel	EL_A0100						
EL	Dash Panel		EL_A0100	Dashboard plate	inside the front hoop	m	1	EL_01001
EL	Dash Panel		EL_A0100	LED Bar	RPM display	b	1	EL_01002
EL	Dash Panel		EL_A0100	2 way switch	for secondary fonctions	b	4	EL_01003
EL	Dash Panel		EL_A0100	3 way switch	contact switch	b	1	EL_01004
EL	Dash Panel		EL_A0100	push button red	with a red light circle	b	1	EL_01005
EL	Dash Panel		EL_A0100	push button blue	with a blue light circle	b	2	EL_01006
EL	Dash Panel		EL_A0100	1 digit I2C display board	display engaged gear	m	1	EL_01008
EL	Dash Panel		EL_A0100	3 digit I2C dislpay board	display water temp. Or Batt. Voltage	m	1	EL_01009
EL	Dash Panel		EL_A0100	front board	control the Dashboard and sensors	m	1	EL_01010
EL	Dash Panel		EL_A0100	front board box	protecting plastic case	b	1	EL_01011
EL	Dash Panel		EL_A0100	push button	without any light	b	2	EL_01007
EL	Sensors	EL_A0200						
EL	Sensors		EL_A0200	data logger	MK3	b	1	EL_02001
EL	Sensors		EL_A0200	data log connector set	connectors for the MK3	b	1	EL_02002
EL	Sensors		EL_A0200	wheel speed sensor	on each four wheels, Hall effect	b	4	EL_02003
EL	Sensors		EL_A0200	suspension travel sensor	on each four suspensions	b	4	EL_02004

EL	Sensors		EL_A0200	steering wheel pos sensor	in the steering rack	b	1	EL_02005
EL	Sensors		EL_A0200	pressure sensors	pressure of brake sys., fuel, oil	b	4	EL_02006
EL	Sensors		EL_A0200	Lambda sensor	placed on the exhaust	b	1	EL_02007
EL	Sensors		EL_A0200	Camshaft position sensor	present on the purchased engine	b	1	EL_02008
EL	Sensors		EL_A0200	throttle position	linear sensor on the throttle body	b	1	EL_02009
EL	Sensors		EL_A0200	Air temp,pressure sensor	to the ECU	b	1	EL_02010
EL	Sensors		EL_A0200	Crankshaft pos sensor	present on the purchased engine	b	1	EL_02011
EL	Sensors		EL_A0200	Water temp sensor	to the ECU	b	1	EL_02012
EL	Sensors		EL_A0200	GPS Antenna	placed on top of the main hoop	b	1	EL_02013
EL	Sensors		EL_A0200	connectors for the sensor	to the harness (fr./re.)	b	14	EL_02014
EL	Sensors		EL_A0200	lambda connector	standard automobile connector	b	1	EL_02015
EL	Sensors		EL_A0200	camshaft sensors connecto	standard automobile connector	b	1	EL_02016
EL	Sensors		EL_A0200	Crankshaft sensor connect	standard automobile connector	b	1	EL_02017
EL	Sensors		EL_A0200	ECT connector	standard automobile connector	b	1	EL_02018
EL	Sensors		EL_A0200	TPS connector	standard automobile connector	b	1	EL_02019
EL	Sensors		EL_A0200	TMAP connector	standard automobile connector	b	1	EL_02020
EL	Wire Harness/Connectors	EL_A0300						
EL	Wire Harness/Connectors		EL_A0300	front harness	link rear, dashboard, sensors	m	1	EL_03001
EL	Wire Harness/Connectors		EL_A0300	rear harness	link fr. , servo motor, sensors, bat.	m	1	EL_03002
EL	Wire Harness/Connectors		EL_A0300	connector front-rear	8STA71828S&P, sensors and Power	b	2	EL_03003
EL	Wire Harness/Connectors		EL_A0300	connector BSPD	8STA70835S&P, Power and DATA	b	1	EL_03004
EL	Wire Harness/Connectors		EL_A0300	connector rear board	8STA01497P&S, Power and DATA	b	2	EL_03005
EL	Wire Harness/Connectors		EL_A0300	connector front board	8STA01002S&P, 5V Power	b	3	EL_03006
EL	Wire Harness/Connectors		EL_A0300	Brake light	rear red light	b	1	EL_03007
EL	Wire Harness/Connectors		EL_A0300	ECU	DTAFast S80 Pro	b	1	EL_03008
EL	Wire Harness/Connectors		EL_A0300	ECU Power connector	power connector for the ECU	b	1	EL_03009
EL	Wire Harness/Connectors		EL_A0300	DB-9 connector	Access to the DTA	b	1	EL_03010
EL	Wire Harness/Connectors		EL_A0300	ECU Data connector	DATA Connector for the ECU	b	1	EL_03011
EL	Wire Harness/Connectors		EL_A0300	3 phase rectifier connect	2 pin connector	b	2	EL_03012
EL	Wire Harness/Connectors		EL_A0300	injectors connector	2 pin connector	b	4	EL_03013
EL	Wire Harness/Connectors		EL_A0300	Fan connector	to be completed	b	1	EL_03014
EL	Wire Harness/Connectors		EL_A0300	Brake light connector	to be completed	b	1	EL_03015
EL	LV-Battery	EL_A0400						
EL	LV-Battery		EL_A0400	Battery support	on the rear rigth side	m	1	EL_04001
EL	LV-Battery		EL_A0400	LV-Battery	12V Battery	b	1	EL_04002
EL	LV-Battery		EL_A0400	Battery connector	Battery connector	m	2	EL_04003
EL	LV-Battery		EL_A0400	Battery Fuse 250A	General fuse	b	1	EL_04004

EL	LV-Battery		EL_A0400	Master switch	on the right hand side of the main hoop	b	1	EL_04005
EL	LV-Battery		EL_A0400	Master switch pannel	on the right hand side of the main hoop	m	1	EL_04006
EL	LV-Battery		EL_A0400	Booster connector	on the right hand side of the main hoop	b	1	EL_04007
EL	LV-Battery		EL_A0400	3 phase rectifier	mounted on the fire wall	b	1	EL_04008
EL	Fuses	EL_A0500						
EL	Fuses		EL_A0500	Rear Fuse Box	on the rear left hand side	b	1	EL_05001
EL	Fuses		EL_A0500	Brake light Fuse 3A	in the Fuse box	b	1	EL_05002
EL	Fuses		EL_A0500	Fuse 10A	in the Fuse box, Fan, Fr. har.	b	2	EL_05003
EL	Fuses		EL_A0500	Lambda sensor Fuse 5A	in the Fuse box	b	1	EL_05004
EL	Fuses		EL_A0500	Pump Fuse 20A	in the Fuse box	b	1	EL_05005
EL	Fuses		EL_A0500	Fuse 15A	Servo motor ,Inject., in the Fuse Box	b	2	EL_05006
EL	Fuses		EL_A0500	starter relay	on the right hand side of the motor	b	1	EL_05007
EL	Fuses		EL_A0500	relays 35A	in the fuse box, fan, pump, DTA, rear	b	4	EL_05008
EL	Kill Switch	EL_A0600						
EL	Kill Switch		EL_A0600	Main hoop kill Switch	on both sides of the main hoop	b	2	EL_06001
EL	Kill Switch		EL_A0600	24mm kill Switch	Dashboard and BOTS	b	2	EL_06002
EL	Kill Switch		EL_A0600	BSPD	right hand side of the front hoop	m	1	EL_06003
EL	Kill Switch		EL_A0600	Crash sensor	right hand side of the front hoop	b	1	EL_06004
EL	Kill Switch		EL_A0600	BSPD Box	protecting metal case	b	1	EL_06005
EL	Control Unit	EL_A0700						
EL	Control Unit		EL_A0700	Rear box shifter	protecting plastic case	b	1	EL_07001
EL	Control Unit		EL_A0700	Rear board shifter	control the servo motor	m	1	EL_07002
EL	Control Unit		EL_A0700	Servo motor cables	set of cable for the servo motor	b	1	EL_07003
EL	Control Unit		EL_A0700	Servo motor	controled high power motor	b	1	EL_07004
EL	Control Unit		EL_A0700	servo motor support 1	support the servo motor assembly 1	m	1	EL_07005
EL	Control Unit		EL_A0700	servo motor support 2	support the servo motor assembly 2	m	1	EL_07006
EL	Control Unit		EL_A0700	Paddle	placed on the steering wheel	b	1	EL_07007
EN	Engine	EN_A0100						
EN	Engine		EN_A0100	Honda CBR600RR Engine	Second-hand, PC40	b	1	EN_01001
EN	Engine		EN_A0100	Fuel injectors	Second hand	b	4	EN_01002
EN	Engine		EN_A0100	Spark plugs	Second hand	b	4	EN_01003
EN	Engine		EN_A0100	Wet slipper clutch	To help with downshifting	b	1	EN_01004
EN	Engine		EN_A0100	Thermostat	From PC37, new	b	1	EN_01005
EN	Engine		EN_A0100	PAIR plate	Permit to close the PAIR sensors	m	2	EN_01006
EN	Engine		EN_A0100	Adaptater oil pressure	Permit to plug our oil pressure sensors	m	1	EN_01007
EN	Engine		EN_A0100	Oil sump shell	Contain engine's oil	m	1	EN_01008
EN	Engine		EN_A0100	Join plate	Weld with sump shell, attached to engine	b	1	EN_01009

EN	Engine		EN_A0100	Anti-planing plate	Limit oil move, welded with oil sump	m	1	EN_01010
EN	Engine		EN_A0100	Smooth clutch disc	Discs of the clutch system, new	b	8	EN_01011
EN	Engine		EN_A0100	Lining clutch disc	Discs of the clutch system, new	b	7	EN_01012
EN	Engine		EN_A0100	Shifter axis	Shaft between Shifter and gear motor	m	1	EN_01013
EN	Engine		EN_A0100	Shifter gear	Assemble with shifter axis	m	1	EN_01014
EN	Exhaust System	EN_A0200						
EN	Exhaust System		EN_A0200	Exhaust header n┬1	Collect gas from the 1st cylinder	m	1	EN_02001
EN	Exhaust System		EN_A0200	Exhaust header n┬2	Collect gas from the 2nd cylinder	m	1	EN_02002
EN	Exhaust System		EN_A0200	Exhaust header n┬3	Collect gas from the 3rd cylinder	m	1	EN_02003
EN	Exhaust System		EN_A0200	Exhaust header n┬4	Collect gas from the 4th cylinder	m	1	EN_02004
EN	Exhaust System		EN_A0200	1st tubing collector n┬1	Collect gas from exhaust header 1 and 4	m	1	EN_02005
EN	Exhaust System		EN_A0200	1st tubing collector n┬2	Collect gas from exhaust header 2 and 3	m	1	EN_02006
EN	Exhaust System		EN_A0200	2nd tubing collector	Collect gas from primary collectors	m	1	EN_02007
EN	Exhaust System		EN_A0200	Exhaust flange	Join the collector to the engine	m	4	EN_02008
EN	Exhaust System		EN_A0200	Muffler	Buy with a chicane	b	1	EN_02009
EN	Exhaust System		EN_A0200	Muffler clamp	Fasten the muffler to the frame	m	1	EN_02010
EN	Exhaust System		EN_A0200	Exhaust tip	Part chich link collector to engine	m	4	EN_02011
EN	Intake System	EN_A0300						
EN	Intake System		EN_A0300	Air manifold	Under the restrictor	b	1	EN_03001
EN	Intake System		EN_A0300	Flat-bottomed	Under the air manifold	m	1	EN_03002
EN	Intake System		EN_A0300	Tubing collector	Link up the flat-bottomed to the engine	b	1	EN_03003
EN	Intake System		EN_A0300	Coupling sleeve	Link up the air intake to the engine	b	2	EN_03004
EN	Intake System		EN_A0300	Left frame mounting tube	Fasten the air intake to the frame	m	1	EN_03005
EN	Intake System		EN_A0300	Right frame mounting tube	Fasten the air intake to the frame	m	1	EN_03006
EN	Intake System		EN_A0300	Engine mounting tube	Fasten the air intake to the engine	m	2	EN_03007
EN	Intake System		EN_A0300	Mounting plate	Fasten the restrictor to the air intake	m	2	EN_03008
EN	Throttle Body	EN_A0400						
EN	Throttle Body		EN_A0400	Inferior plate	Under the moving plate	m	1	EN_04001
EN	Throttle Body		EN_A0400	Front stop plate	Stop the translation of the moving plate	m	1	EN_04002
EN	Throttle Body		EN_A0400	Rear stop plate	Stop the translation of the moving plate	m	1	EN_04003
EN	Throttle Body		EN_A0400	Medium plate	Moving plate	m	1	EN_04004
EN	Throttle Body		EN_A0400	Superior plate	Above the moving plate	m	1	EN_04005
EN	Throttle Body		EN_A0400	Air filter	Filter the air which goes to the engine	b	1	EN_04006
EN	Throttle Body		EN_A0400	Convergent	Link up the filter to the slide throttle	b	1	EN_04007
EN	Throttle Body		EN_A0400	Air restrictor	Link up the slide throttle to the intake	b	1	EN_04008
EN	Other: Fuel system	EN_A0500						
EN	Other: Fuel system		EN_A0500	Fuel Rail	Above the Engine	b	1	EN_05001

EN	Other: Fuel system		EN_A0500	Fuel Pump	Under the Fuel Tank	b	1	EN_05002
EN	Other: Fuel system		EN_A0500	Pressure Regulator	Left side of the Engine	b	1	EN_05003
EN	Other: Fuel system		EN_A0500	Fuel Filter	Next to the Fuel Pump	b	1	EN_05004
EN	Other: Fuel system		EN_A0500	Fuel Pump Collar	Around the Fuel Pump	m	1	EN_05005
EN	Other: Fuel system		EN_A0500	Pressure Sensor Adapter	At the end of the Fuel Rail	m	1	EN_05006
EN	Cooling System	EN_A0600						
EN	Cooling System		EN_A0600	Radiator	Aluminum radiator	b	1	EN_06001
EN	Cooling System		EN_A0600	Fan	SPAL Fan 1360M3/H	b	1	EN_06002
EN	Cooling System		EN_A0600	Expansion tank base	Part of expansion tank wielded to filler	m	1	EN_06003
EN	Cooling System		EN_A0600	Expansion tank filler nec	Receives the tank cap	b	1	EN_06004
EN	Cooling System		EN_A0600	Expansion tank cap	Expansion tank cap	b	1	EN_06005
EN	Cooling System		EN_A0600	Fixing tube	Maintains the radiator	m	1	EN_06006
EN	Cooling System		EN_A0600	Radiator tab	Tabs wielded to the radiator	m	1	EN_06007
EN	Cooling System		EN_A0600	Expansion tank tab	Wielded to the tank	m	1	EN_06008
EN	Cooling System		EN_A0600	Main coolant line	Engine - radiator links	m	1	EN_06009
EN	Cooling System		EN_A0600	Secondary coolant line	Engine - expansion tank	m	1	EN_06010
EN	Drivetrain Assembly	EN_A0700						
EN	Drivetrain Assembly		EN_A0700	Differential	Adjustable Limited Slip	b	1	EN_07001
EN	Drivetrain Assembly		EN_A0700	Eccentric left	Carry the differential	m	1	EN_07002
EN	Drivetrain Assembly		EN_A0700	Eccentric right	Carry the differential	m	1	EN_07003
EN	Drivetrain Assembly		EN_A0700	Eccentric carrier left	Link between drivetrain and frame	m	1	EN_07004
EN	Drivetrain Assembly		EN_A0700	Eccentric carrier right	Link between drivetrain and frame	m	1	EN_07005
EN	Drivetrain Assembly		EN_A0700	Ball bearing left	Ball bearing	b	1	EN_07006
EN	Drivetrain Assembly		EN_A0700	Ball bearing right	Ball bearing	b	1	EN_07007
EN	Drivetrain Assembly		EN_A0700	Needle roller bearing	Between drive shaft and differential	b	2	EN_07008
EN	Drivetrain Assembly		EN_A0700	Chain	Chain	b	1	EN_07009
EN	Drivetrain Assembly		EN_A0700	Front sprocket	Link between chain and output of the mot	b	1	EN_07010
EN	Drivetrain Assembly		EN_A0700	Rear sprocket	Link between chain and rear sprocket ada	b	1	EN_07011
EN	Drivetrain Assembly		EN_A0700	Rear sprocket adaptator	Link between rear sprocket and different	m	1	EN_07012
EN	Drivetrain Assembly		EN_A0700	Chainshield	Protection around the chain	m	1	EN_07013
EN	Drivetrain Assembly		EN_A0700	Driveshaft left	Driveshaft	b	1	EN_07014
EN	Drivetrain Assembly		EN_A0700	Driveshaft right	Driveshaft	b	1	EN_07015
EN	Drivetrain Assembly		EN_A0700	Tripod	Enable small displacement of driveshafts	b	4	EN_07016
EN	Drivetrain Assembly		EN_A0700	Inner tripod housing	Link differential and driveshaft	b	2	EN_07017
EN	Drivetrain Assembly		EN_A0700	Outer tripod housing	Link between wheel and driveshat	b	2	EN_07018
EN	Drivetrain Assembly		EN_A0700	Tripod housing nut	Nylstop, non metric	b	2	EN_07019
EN	Drivetrain Assembly		EN_A0700	Axle boots	Over driveshafts and tripod housings	b	4	EN_07020

EN	Overflow Bottles	EN_A0800						
EN	Overflow Bottles		EN_A0800	Oil overflow	Contain the oil overflow	m	1	EN_08001
EN	Overflow Bottles		EN_A0800	Water overflow	Contain the water overflow	m	1	EN_08002
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900						
EN	Fuel Tank ÔÇô NOT THE HV-Battery		EN_A0900	Fuel Tank(main1)	Under the seat (Folding-front part))	m	1	EN_09001
EN	Fuel Tank ÔÇô NOT THE HV-Battery		EN_A0900	Fuel Tank(main2)	Under the seat (Folding-top part)	m	1	EN_09002
EN	Fuel Tank ÔÇô NOT THE HV-Battery		EN_A0900	Fuel Tank(bottom)	Under the seat (Folding-bottom part)	m	1	EN_09003
EN	Fuel Tank ÔÇô NOT THE HV-Battery		EN_A0900	Fuel Tank(Triangle)	Under the seat (With Fuel Tank)	m	1	EN_09004
EN	Fuel Tank ÔÇô NOT THE HV-Battery		EN_A0900	Filler Neck	Welded to Fuel Tank	m	1	EN_09005
EN	Fuel Tank ÔÇô NOT THE HV-Battery		EN_A0900	Filler Cap	On the top of filler Tube	b	1	EN_09006
EN	Fuel Tank ÔÇô NOT THE HV-Battery		EN_A0900	Filler Tube	With Fuel Tank	m	1	EN_09007
FR	Frame / Frame Tubes	FR_A0100						
FR	Frame / Frame Tubes		FR_A0100	Round steel tubing	25CrMo4 ; 30*1,5, 25*1,5, 20*15, 15*1,5	m	87	FR_01001
FR	Frame / Frame Tubes		FR_A0100	Square steel tubing	25CrMo4 ; 20*20*1,5 (mm)	m	1	FR_01002
FR	Frame / Frame Tubes		FR_A0100	Round bent steel tubing	25CrMo4 ; 30*2 (mm)	m	2	FR_01003
FR	Frame / Frame Tubes		FR_A0100	Steering bore	CNC machining	m	1	FR_01004
FR	Frame / Frame Tubes		FR_A0100	Jacking bar	CNC machining	m	1	FR_01005
FR	Frame / Frame Tubes		FR_A0100	Sleeved joint	S350 ; Rules-compliant sleeved joints	m	2	FR_01006
FR	Frame / Frame Tubes	FR_A0200						
FR	Brackets	Braking Syst	FR_0200_BR	Front pedal bracket	S355, 3mm thick	m	4	FR_02001_BR
FR	Brackets	Braking Syst	FR_0200_BR	Rear pedal bracket	S355, 3mm thick	m	4	FR_02002_BR
FR	Brackets	Braking Syst	FR_0200_BR	Pedal fluid tank bracket	S355, 1.5mm thick	m	1	FR_02003_BR
FR	Brackets	Braking Syst	FR_0200_BR	Tee breaking bracket	S355, 1.5mm thick	m	1	FR_02004_BR
FR	Brackets	Electrical	FR_0200_EL	Dashboard bracket 1	S235, 1.5mm thick	m	2	FR_02001_EL
FR	Brackets	Electrical	FR_0200_EL	Dashboard bracket 2	S235, 1.5mm thick	m	1	FR_02002_EL
FR	Brackets	Electrical	FR_0200_EL	Dashboard bracket 3	S235, 1.5mm thick	m	1	FR_02003_EL
FR	Brackets	Electrical	FR_0200_EL	Emergency stop bracket	S355, 3mm thick	m	2	FR_02004_EL
FR	Brackets	Electrical	FR_0200_EL	Support battery bracket 2	S235, 1.5mm thick	m	1	FR_02005_EL
FR	Brackets	Electrical	FR_0200_EL	Power box bracket	S235, 1.5mm thick	m	2	FR_02006_EL
FR	Brackets	Electrical	FR_0200_EL	Master switch bracket	S235, 1.5mm thick	m	2	FR_02007_EL
FR	Brackets	Electrical	FR_0200_EL	Crash sensor bracket	S235, 1.5mm thick	m	1	FR_02008_EL
FR	Brackets	Electrical	FR_0200_EL	Support battery bracket 1	S235, 1.5mm thick	m	2	FR_02009_EL
FR	Brackets	Electrical	FR_0200_EL	Electrical earth bracket	S235, 1.5mm thick	m	4	FR_02010_EL
FR	Brackets	Electrical	FR_0200_EL	Breaklight bracket	S235, 1.5mm thick	m	1	FR_02011_EL
FR	Brackets	Electrical	FR_0200_EL	Booster bracket	S355, 3mm thick	m	1	FR_02012_EL
FR	Brackets	Engine & Po	FR_0200_EN	Engine bracket	S700, 4mm thick	m	2	FR_02001_EN
FR	Brackets	Engine & Po	FR_0200_EN	Up excentric carry brack1	S355, 3mm thick	m	2	FR_02002_EN

FR	Brackets	Engine & Po	FR_0200_EN	Low excentric carry brack	S355, 3mm thick	m	4	FR_02003_EN
FR	Brackets	Engine & Po	FR_0200_EN	Up excentric carry brack2	S355, 3mm thick	m	2	FR_02004_EN
FR	Brackets	Engine & Po	FR_0200_EN	Fuel tank bracket	S235, 3mm thick	m	4	FR_02005_EN
FR	Brackets	Engine & Po	FR_0200_EN	Chain shield bracket 1	S355, 3mm thick, top	m	1	FR_02006_EN
FR	Brackets	Engine & Po	FR_0200_EN	Pump bracket	S235, 3mm thick	m	1	FR_02007_EN
FR	Brackets	Engine & Po	FR_0200_EN	Regulator bracket	S235, 2mm thick, for pressure regulator	m	1	FR_02008_EN
FR	Brackets	Engine & Po	FR_0200_EN	Shifter bracket	S355, 3mm thick	m	1	FR_02009_EN
FR	Brackets	Engine & Po	FR_0200_EN	Radiator bracket 1	S355, 3mm thick, rear	m	1	FR_02010_EN
FR	Brackets	Engine & Po	FR_0200_EN	Expansion tank bracket	S235, 1.5mm thick	m	1	FR_02011_EN
FR	Brackets	Engine & Po	FR_0200_EN	Air admission bracket	S235, 1.5mm thick	m	2	FR_02012_EN
FR	Brackets	Engine & Po	FR_0200_EN	Clutch actuation axis	S355, 1.5mm thick	m	1	FR_02013_EN
FR	Brackets	Engine & Po	FR_0200_EN	Clutch actu. cable holder	S355, 1.5mm thick	m	1	FR_02014_EN
FR	Brackets	Engine & Po	FR_0200_EN	Chain shield bracket 2	S355, 3mm thick, top	m	1	FR_02015_EN
FR	Brackets	Engine & Po	FR_0200_EN	Radiator bracket 2	S355, 3mm thick, front	m	1	FR_02016_EN
FR	Brackets	Engine & Po	FR_0200_EN	Radiator bracket 3	S355, 3mm thick, top	m	1	FR_02017_EN
FR	Brackets	Frame & Bo	FR_0200_FR	Jacking bar bracket	attached to excentric carriers	m	2	FR_02001_FR
FR	Brackets	Frame & Bo	FR_0200_FR	Body bracket	S235, 1.5mm thick	m	4	FR_02002_FR
FR	Brackets	Frame & Bo	FR_0200_FR	Floor pan bracket	S235, 1.5mm thick	m	8	FR_02003_FR
FR	Brackets	Miscelleano	FR_0200_MS	Upper bucket seat bracket	S355, 3mm thick	m	2	FR_02001_MS
FR	Brackets	Miscelleano	FR_0200_MS	Lower bucket seat bracket	S355, 3mm thick	m	4	FR_02002_MS
FR	Brackets	Miscelleano	FR_0200_MS	Harness bracket	S700, 4mm thick	m	2	FR_02003_MS
FR	Brackets	Miscelleano	FR_0200_MS	Head support bracket	S355, 3mm thick	m	2	FR_02004_MS
FR	Brackets	Miscelleano	FR_0200_MS	Firewall bracket	S235, 1.5mm thick	m	12	FR_02005_MS
FR	Brackets	Steering sys	FR_0200_ST	Rack brackets	S235, 1.5mm thick	m	2	FR_02001_ST
FR	Brackets	Suspension	FR_0200_SU	A-arm upper fr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02001_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm upper fr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02002_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm upper fr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02003_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm upper fr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02004_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower fr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02005_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower fr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02006_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm upper rr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02007_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm upper rr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02008_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower rr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02009_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower rr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02010_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower fr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02011_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower fr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02012_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm upper rr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02013_SU

FR	Brackets	Suspension	FR_0200_SU	A-arm upper rr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02014_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower rr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02015_SU
FR	Brackets	Suspension	FR_0200_SU	A-arm lower rr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02016_SU
FR	Brackets	Suspension	FR_0200_SU	Fr anti roll bar bracket	S700, 4mm thick	m	2	FR_02017_SU
FR	Brackets	Suspension	FR_0200_SU	Rr anti roll bar bracket	S355, 3mm thick	m	2	FR_02018_SU
FR	Brackets	Suspension	FR_0200_SU	Front rocker bracket 1	S355, 3mm thick	m	2	FR_02019_SU
FR	Brackets	Suspension	FR_0200_SU	Front rocker bracket 2	S355, 3mm thick	m	2	FR_02020_SU
FR	Brackets	Suspension	FR_0200_SU	Ohlins front bracket	S355, 3mm thick	m	2	FR_02021_SU
FR	Brackets	Suspension	FR_0200_SU	Ohlins rear bracket	CNC machining	m	2	FR_02022_SU
FR	Brackets	Suspension	FR_0200_SU	Rear rocker bracket	CNC machined part	m	2	FR_02023_SU
FR	Impact Attenuator	FR_A0300						
FR	Impact Attenuator		FR_A0300	Impact attenuator	Approved by event	b	1	FR_03001
FR	Impact Attenuator		FR_A0300	Anti-Intrusion plate	Steel, (thickness 1.5mm)	m	1	FR_03002
FR	Pedals	FR_A0400						
FR	Pedals		FR_A0400	Upper rail brake pedal	Allow easy setup	m	1	FR_04001
FR	Pedals		FR_A0400	Lower rail	Same for pedal accel and brake	m	2	FR_04002
FR	Pedals		FR_A0400	Accelerator pedal	Aluminium, machining	m	1	FR_04003
FR	Pedals		FR_A0400	Brake pedal	Aluminium, machined part	m	1	FR_04004
FR	Pedals		FR_A0400	Top foot support	Laser cutted part + bending	m	2	FR_04005
FR	Pedals		FR_A0400	Below foot support	Laser cutted part + bending	m	2	FR_04006
FR	Pedals		FR_A0400	Side support brake pedal	Lateral support	m	2	FR_04007
FR	Pedals		FR_A0400	Side support accelerator	Symmetric allow FR_04018 to slide	m	2	FR_04008
FR	Pedals		FR_A0400	Rod accelerator	Rod mounted btw pedal and cable support	m	2	FR_04009
FR	Pedals		FR_A0400	Brake support	Brake over-travel switch support	m	1	FR_04010
FR	Pedals		FR_A0400	Cable sheath support	For accel. cable sheath	m	1	FR_04011
FR	Pedals		FR_A0400	Inside spacer	Upper part of the master cylinder	m	2	FR_04012
FR	Pedals		FR_A0400	Outside spacer	Upper part of the master cylinder	m	2	FR_04013
FR	Pedals		FR_A0400	Upper rail accel. pedal	Allow easy setup	m	1	FR_04014
FR	Pedals		FR_A0400	Accel. cable sheath	Cable protection	b	1	FR_04015
FR	Pedals		FR_A0400	Accel. cable	To open the throttle	b	1	FR_04016
FR	Pedals		FR_A0400	Throttle pedal stop	Mechanical stop	m	1	FR_04017
FR	Pedals		FR_A0400	Accel pedal slide part	Steel, slide on FR_04008	m	1	FR_04018
FR	Floor Pan	FR_A0500						
FR	Floor Pan		FR_A0500	Front floor pan	Floor pan from front hoop to front car	b	1	FR_05001
FR	Floor Pan		FR_A0500	Rear floor pan	Floor pan from front hoop to main hoop	b	1	FR_05002
FR	Other: Clutch actuation system	FR_A0600						
FR	Other: Clutch actuation system		FR_A0600	Lever	Drilled tube	m	1	FR_06001

FR	Other: Clutch actuation system		FR_A0600	Clutch cable sheath	-	b	1	FR_06002
FR	Other: Clutch actuation system		FR_A0600	Clutch cable	-	b	1	FR_06003
FR	Other: Clutch actuation system		FR_A0600	Lock plate	In the lever, prevent cable from removin	m	1	FR_06004
FR	Other: Clutch actuation system		FR_A0600	Cable protectors	On the lever, prevent cable from cutting	m	2	FR_06005
FR	Other: Clutch actuation system		FR_A0600	Bronze rings	Lubrificating rings for the lever	b	2	FR_06006
FR	Other: Bodywork	FR_A0700						
FR	Other: Bodywork		FR_A0700	Nose	Nose of the bodywork	b	1	FR_07001
FR	Other: Bodywork		FR_A0700	Back nose	Part of the nose after the suspensions	b	1	FR_07002
FR	Other: Bodywork		FR_A0700	Big side plate	Side plate from the front hoop to main	b	2	FR_07003
FR	Other: Bodywork		FR_A0700	Middle side plate	Lower side plate with holes	b	2	FR_07004
FR	Other: Bodywork		FR_A0700	Medium side plate	Side plate over the middle side plate	b	2	FR_07005
FR	Other: Bodywork		FR_A0700	Small side plate	Side plate next to impact attenuator	b	2	FR_07006
FR	Other: Bodywork		FR_A0700	Push clips	Attachement of the nose to the frame	b	4	FR_07007
MS	Fire Wall	MS_A0100						
MS	Fire Wall		MS_A0100	Firewall Bottom Plate	Behind the seat	m	1	MS_01001
MS	Fire Wall		MS_A0100	Firewall Middle Plate	Below harness	m	1	MS_01002
MS	Fire Wall		MS_A0100	Firewall Top Plate	At the back of the head foam	m	1	MS_01003
MS	Fire Wall		MS_A0100	Firewall Joints	Triangles for MS_01003	m	2	MS_01004
MS	Fire Wall		MS_A0100	Firewall Floor Plate	Join the Firewall to the Floor Pan	m	1	MS_01005
MS	Headrest / Restraints	MS_A0200						
MS	Headrest / Restraints		MS_A0200	Headrest Plate	Sthrengthen the Headrest	m	1	MS_02001
MS	Headrest / Restraints		MS_A0200	Head Foam	Absorb chocs for Head impact	b	1	MS_02002
MS	Headrest / Restraints		MS_A0200	Side Head Foam	Absorb chocs for Head impact on the side	b	2	MS_02003
MS	Headrest / Restraints		MS_A0200	Top Back Foam	Absorb chocs for back impact	b	1	MS_02004
MS	DriverÔÇÖs Harness	MS_A0300						
MS	DriverÔÇÖs Harness		MS_A0300	Harness	Seatbelt of the Pilot	b	1	MS_03001
MS	Seats	MS_A0400						
MS	Seats		MS_A0400	Seat	Allow the Pilot to seat	b	1	MS_04001
MS	Seats		MS_A0400	Back Foam	Soften the seat for the back	b	1	MS_04002
ST	Steering Wheel	ST_A0100						
ST	Steering Wheel		ST_A0100	Steering wheel	Bought at Formula Seven.	b	1	ST_01001
ST	Steering Wheel		ST_A0100	Spacer	Between steering wheel and Quick release	m	1	ST_01002
ST	Steering Wheel		ST_A0100	Quick Release mobil part	Removing part of the Quick release	b	1	ST_01003
ST	Steering Shaft	ST_A0200						
ST	Steering Shaft		ST_A0200	Quick Release Shaft	Fixed part of the Quick release	b	1	ST_02001
ST	Steering Shaft		ST_A0200	Steering Shaft Pivot	Bearing seat for the steering pivot	m	1	ST_02002

ST	Steering Shaft		ST_A0200	Steering U-joint	U-joint for steering column and ST_02002	b	1	ST_02003
ST	Steering Shaft		ST_A0200	Steering column	Steering column	m	1	ST_02004
ST	Steering Shaft		ST_A0200	Spline coupler	Connect the steering column to the rack	b	1	ST_02005
ST	Steering Shaft		ST_A0200	Bearing, Ball, Radial	Steering pivot bearings	b	2	ST_02006
ST	Steering Shaft		ST_A0200	U-joint boot	Over steering u-joint	b	1	ST_02007
ST	Steering Rack	ST_A0300						
ST	Steering Rack		ST_A0300	Steering Rack	Bought at Formula Seven.	b	1	ST_03001
ST	Steering Rack		ST_A0300	Half moon	To support the steering rack.	m	4	ST_03002
ST	Steering Rack		ST_A0300	Steering Rack protection	To protect the steering rack.	m	1	ST_03003
ST	Tie Rods	ST_A0400						
ST	Tie Rods		ST_A0400	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	ST_04001
ST	Tie Rods		ST_A0400	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	ST_04002
ST	Tie Rods		ST_A0400	Carbon tube	carbon tubes for tie rod	b	2	ST_04003
ST	Tie Rods		ST_A0400	Rod ends bearing, male r	2 with a left-hand thread	b	2	ST_04004
ST	Tie Rods		ST_A0400	Rod ends bearing, male l	2 with a right-hand thread	b	2	ST_04005
ST	Tie Rods		ST_A0400	Spacer 1	M6 type 16 mm spacer, frame side	m	4	ST_04006
ST	Tie Rods		ST_A0400	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	ST_04007
SU	A-Arms front upper	SU_A0100						
SU	A-Arms front upper		SU_A0100	Upper fr. bearing support	Wheel side	m	2	SU_01001
SU	A-Arms front upper		SU_A0100	Inner bearing support	Frame side	m	4	SU_01002
SU	A-Arms front upper		SU_A0100	Front carbon fiber tube	Carbon tube at the front	b	2	SU_01003
SU	A-Arms front upper		SU_A0100	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_01004
SU	A-Arms front upper		SU_A0100	Spacer 1	M6 type 16 mm spacer, frame side	m	8	SU_01005
SU	A-Arms front upper		SU_A0100	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_01006
SU	A-Arms front upper		SU_A0100	Cylinder aluminium	Glued junction carbon/bearing support	m	4	SU_01007
SU	A-Arms front upper		SU_A0100	Spherical bearing	M6, steel/steel contact	b	6	SU_01008
SU	A-Arms front lower	SU_A0200						
SU	A-Arms front lower		SU_A0200	Lower fr. bearing support	Wheel side	m	2	SU_02001
SU	A-Arms front lower		SU_A0200	Inner bearing support	Frame side	m	4	SU_02002
SU	A-Arms front lower		SU_A0200	Front carbon fiber tube	Carbon tube at the front	b	2	SU_02003
SU	A-Arms front lower		SU_A0200	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_02004
SU	A-Arms front lower		SU_A0200	Spacer 1	M6 type 16 mm spacer, frame side	m	8	SU_02005
SU	A-Arms front lower		SU_A0200	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_02006
SU	A-Arms front lower		SU_A0200	Spherical bearing	M6, steel/steel contact	b	6	SU_02007
SU	A-Arms rear upper	SU_A0300						
SU	A-Arms rear upper		SU_A0300	Upper rr. bearing support	Wheel side (1 + symmetric)	m	2	SU_03001

SU	A-Arms rear upper		SU_A0300	Inner bearing support	Frame side	m	4	SU_03002
SU	A-Arms rear upper		SU_A0300	Front carbon fiber tube	Carbon tube at the front	b	2	SU_03003
SU	A-Arms rear upper		SU_A0300	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_03004
SU	A-Arms rear upper		SU_A0300	Spacer 1	M6 type 16 mm spacer, frame side	m	8	SU_03005
SU	A-Arms rear upper		SU_A0300	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_03006
SU	A-Arms rear upper		SU_A0300	Cylinder aluminium	Glued junction carbon/bearing support	m	4	SU_03007
SU	A-Arms rear upper		SU_A0300	Spherical bearing	M6, steel/steel contact	b	6	SU_03008
SU	A-Arms rear lower	SU_A0400						
SU	A-Arms rear lower		SU_A0400	Lower rr. bearing support	Wheel side	m	2	SU_04001
SU	A-Arms rear lower		SU_A0400	Inner bearing support	Frame side	m	4	SU_04002
SU	A-Arms rear lower		SU_A0400	Front carbon fiber tube	Carbon tube at the front	b	2	SU_04003
SU	A-Arms rear lower		SU_A0400	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_04004
SU	A-Arms rear lower		SU_A0400	Spacer 1	M6 type 16 mm spacer, frame side	m	8	SU_04005
SU	A-Arms rear lower		SU_A0400	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_04006
SU	A-Arms rear lower		SU_A0400	Spherical bearing	M6, steel/steel contact	b	6	SU_04007
SU	Shocks Front	SU_A0500						
SU	Shocks Front		SU_A0500	Dampers	Ohlins TTX 25	b	2	SU_05001
SU	Shocks Front		SU_A0500	Springs	Springs mounted on the dampers	b	2	SU_05002
SU	Shocks Front		SU_A0500	Damper Spacers	M8 type 20 mm spacer	m	8	SU_05003
SU	Bell Cranks Front	SU_A0600						
SU	Bell Cranks Front		SU_A0600	Front rocker	Sheet of metal for the rocker	m	4	SU_06001
SU	Bell Cranks Front		SU_A0600	Front rocker spacer 1	for the pivot	m	2	SU_06002
SU	Bell Cranks Front		SU_A0600	Front rocker spacer 2	M6 type 20 mm spacer	m	8	SU_06003
SU	Shocks Rear	SU_A0700						
SU	Shocks Rear		SU_A0700	Dampers	Ohlins TTX 25	b	2	SU_07001
SU	Shocks Rear		SU_A0700	Springs	Springs mounted on the dampers	b	2	SU_07002
SU	Shocks Rear		SU_A0700	Damper spacers	M8 type 20 mm spacer	m	8	SU_07003
SU	Bell Cranks Rear	SU_A0800						
SU	Bell Cranks Rear		SU_A0800	Rear Rocker	Sheet of metal for the rocker	m	4	SU_08001
SU	Bell Cranks Rear		SU_A0800	Rear rocker spacer 1	for the pivot	m	2	SU_08002
SU	Bell Cranks Rear		SU_A0800	Rear rocker spacer 2	M6 type 20 mm spacer	m	8	SU_08003
SU	Tie Rod - Rear	SU_A0900						
SU	Tie Rod - Rear		SU_A0900	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	SU_09001
SU	Tie Rod - Rear		SU_A0900	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	SU_09002
SU	Tie Rod - Rear		SU_A0900	Carbon tube	carbon tubes for tie rod	b	2	SU_09003
SU	Tie Rod - Rear		SU_A0900	Rod ends bearing, male r	2 with a left-hand thread	b	2	SU_09004

SU	Tie Rod - Rear		SU_A0900	Rod ends bearing, male l	2 with a right-hand thread	b	2	SU_09005
SU	Tie Rod - Rear		SU_A0900	Spacer 1	M6 type 16 mm spacer, frame side	m	4	SU_09006
SU	Tie Rod - Rear		SU_A0900	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_09007
SU	Front Uprights	SU_A1000						
SU	Front Uprights		SU_A1000	Front Left Upright	Right's drawing, left is symmetric.	m	2	SU_10001
SU	Front Uprights		SU_A1000	Upper Arm Bracket		m	2	SU_10002
SU	Front Uprights		SU_A1000	Upper Arm Wedge Shim	2mm, 3mm, 1mm for camber adjustments	m	6	SU_10003
SU	Front Uprights		SU_A1000	Speed Sensor Washer	external sensor washer	m	2	SU_10004
SU	Front Uprights		SU_A1000	Upper Arm Wedge Base		m	2	SU_10005
SU	Rear Uprights	SU_A1100						
SU	Rear Uprights		SU_A1100	Rear Left Upright	Right's drawing, left is symmetric.	m	2	SU_11001
SU	Rear Uprights		SU_A1100	Upper Arm Bracket	same part as in Front Assembly	m	2	SU_11002
SU	Rear Uprights		SU_A1100	Upper Arm Wedge Shim	2mm,3mm, 1mm for camber adjustments	m	6	SU_11003
SU	Rear Uprights		SU_A1100	Speed Sensor Washer	external sensor washer, same as front	m	2	SU_11004
SU	Push/Pullrod Front	SU_A1200						
SU	Push/Pullrod Front		SU_A1200	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	SU_12001
SU	Push/Pullrod Front		SU_A1200	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	SU_12002
SU	Push/Pullrod Front		SU_A1200	Carbon tube	carbon tubes for tie rod	b	2	SU_12003
SU	Push/Pullrod Front		SU_A1200	Rod ends bearing, male r	2 with a right-hand thread	b	2	SU_12004
SU	Push/Pullrod Front		SU_A1200	Rod ends bearing, male l	2 with a left-hand thread	b	2	SU_12005
SU	Push/Pullrod Front		SU_A1200	Spacer	M6 type 16 mm spacer, A-arm side	m	4	SU_12006
SU	Push/Pullrod Rear	SU_A1300						
SU	Push/Pullrod Rear		SU_A1300	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	SU_13001
SU	Push/Pullrod Rear		SU_A1300	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	SU_13002
SU	Push/Pullrod Rear		SU_A1300	Carbon tube	carbon tubes for tie rod	b	2	SU_13003
SU	Push/Pullrod Rear		SU_A1300	Rod ends bearing, male r	2 with a right-hand thread	b	2	SU_13004
SU	Push/Pullrod Rear		SU_A1300	Spacer	M6 type 16 mm spacer, A-arm side	m	4	SU_13006
SU	Anti Roll Bar Front	SU_A1400						
SU	Anti Roll Bar Front		SU_A1400	Torsion bar	Tube used for the anti roll bar, 25CrMo4	b	1	SU_14001
SU	Anti Roll Bar Front		SU_A1400	Right bearing support	Outside diameter of the SU_14007	m	1	SU_14002
SU	Anti Roll Bar Front		SU_A1400	Left bearing support	Outside diameter of the SU_14007	m	1	SU_14003
SU	Anti Roll Bar Front		SU_A1400	End plate	Laser cutted, S355, 3mm thick	m	4	SU_14004
SU	Anti Roll Bar Front		SU_A1400	Rod ends bearing, male r	2 male thread, ARB rod, right hand	b	2	SU_14005
SU	Anti Roll Bar Front		SU_A1400	Rod ends bearing female r	2 female thread, ARB rod, right hand	b	2	SU_14006
SU	Anti Roll Bar Front		SU_A1400	Spherical plain bearings	Used in the bearing supports, M12	b	2	SU_14007
SU	Anti Roll Bar Front		SU_A1400	Spacer	M6 type 16 mm spacer	m	4	SU_14008

SU	Anti Roll Bar Rear	SU_A1500						
SU	Anti Roll Bar Rear		SU_A1500	Torsion bar	Tube used for the anti roll bar, 25CrMo4	b	1	SU_15001
SU	Anti Roll Bar Rear		SU_A1500	Right bearing support	Outside diameter of the SU_15007	m	1	SU_15002
SU	Anti Roll Bar Rear		SU_A1500	Left bearing support	Outside diameter of the SU_15007	m	1	SU_15003
SU	Anti Roll Bar Rear		SU_A1500	End plate	Laser cutted, S355, 3mm thick	m	4	SU_15004
SU	Anti Roll Bar Rear		SU_A1500	Rod ends bearing, male r	2 with a right-hand thread, ARB rod	b	2	SU_15005
SU	Anti Roll Bar Rear		SU_A1500	Rod ends bearing, male l	2 with a left-hand thread, ARB rod	b	2	SU_15006
SU	Anti Roll Bar Rear		SU_A1500	Spherical plain bearings	Used in the bearing support, M12	b	2	SU_15007
SU	Anti Roll Bar Rear		SU_A1500	Spacer	M6 type 16 mm spacer	m	4	SU_15008
SU	Anti Roll Bar Rear		SU_A1500	Aluminium tapped tube	Aluminium tube for the ARB rod	m	2	SU_15009
WT	Wheels	WT_A0100						
WT	Wheels		WT_A0100	Oz Magnesium Rim		b	4	WT_01001
WT	Wheels		WT_A0100	Hoosier 13", Dry		b	4	WT_01002
WT	Front Hubs	WT_A0200						
WT	Front Hubs		WT_A0200	Front Hub	Aluminium	m	2	WT_02001
WT	Front Hubs		WT_A0200	Brake Bell	Aluminium, junction between disc and hub	m	2	WT_02002
WT	Front Hubs		WT_A0200	Front Bearing Washer	outer side of the external bearing	m	2	WT_02003
WT	Front Hubs		WT_A0200	Speed disc spacer 1	to position WT_02005 (1mm thick)	m	6	WT_02004
WT	Front Hubs		WT_A0200	Speed sensor disc	iron teeth shape like	m	2	WT_02005
WT	Front Hubs		WT_A0200	Speed disc spacer 2	to position WT_02005 (2mm thick)	m	4	WT_02006
WT	Front Hubs		WT_A0200	Front Bearing	Wheel Bearing, Ball, Angular Contact	b	4	WT_02007
WT	Front Hubs		WT_A0200	Front Hub Lock	SKF lock nut KM10	b	2	WT_02008
WT	Front Hubs		WT_A0200	Front Hub Locknut Washer	SKF locknut washer MB10	b	2	WT_02009
WT	Front Hubs		WT_A0200	Rim Dowel	hand trimmed	b	8	WT_02010
WT	Front Hubs		WT_A0200	Rim Nut		b	8	WT_02011
WT	Rear Hubs	WT_A0300						
WT	Rear Hubs		WT_A0300	Rear Hub	Aluminium, flutting for tripod housing	m	2	WT_03001
WT	Rear Hubs		WT_A0300	Brake Bell	Sold attached with the rear breake rotor	b	2	WT_03002
WT	Rear Hubs		WT_A0300	Rear Bearing Washer	outer side of the external bearing	m	2	WT_03003
WT	Rear Hubs		WT_A0300	Tripod Housing Spacer	rear upright vehicle inner side	m	2	WT_03004
WT	Rear Hubs		WT_A0300	Speed disc spacer 1	to position WT_03006 (1mm thick)	m	6	WT_03005
WT	Rear Hubs		WT_A0300	Speed sensor disc	iron teeth shape like	m	2	WT_03006
WT	Rear Hubs		WT_A0300	Speed disc spacer 2	to position WT_03006 (2mm thick)	m	4	WT_03007
WT	Rear Hubs		WT_A0300	Rear Bearing	Wheel Bearing, Ball, Angular Contact	b	4	WT_03008
WT	Rear Hubs		WT_A0300	Rim Dowel	hand trimmed	b	8	WT_03009
WT	Rear Hubs		WT_A0300	Rim Nut		b	8	WT_03010

BR	Brake System	BR_A0100						Back
BR	Brake System Front	BR_A0100	Front brake rc	230 mm cast i	b	2	BR_01001	
BR	Brake System Front	BR_A0100	Front brake ca	Beringer 2P1A	b	2	BR_01002	
BR	Brake System Front	BR_A0100	Front brake re	tank to store l	b	1	BR_01003	
BR	Brake System Front	BR_A0100	Rotor button	to assemble b	b	12	BR_01004	
BR	Brake System Front	BR_A0100	Adapter	Adapter for pı	m	1	BR_01005	
BR	Brake System Front	BR_A0100	Front brake ci	Hoses stainles	m	1	BR_01006	
BR	Brake System Front	BR_A0100	[Assembly Processes]		m	1	P_BR_A0100	

BR BR_A0100 Front brake rotor BR_01001 Back

BR BR_A0100 Front brake caliper BR_01002 Back

BR BR_A0100 Front brake reservoir BR_01003 Back

BR BR_A0100 Rotor button BR_01004 Back

BR BR_A0100 Adapter BR_01005 [Back]

BR	BR_A0100	Front brake circuit	BR_01006	Back

BR	Brake System BR_A0200							Back
BR	Brake System Rear	BR_A0200	Rear brake rotor	Sold attached with the rear brake bell	b	2	BR_02001	
BR	Brake System Rear	BR_A0200	Rear brake caliper	B├®ringer 2D1, dual piston 27mm bore	b	2	BR_02002	
BR	Brake System Rear	BR_A0200	Rear brake reservoir	tank to store brake fluid	b	1	BR_02003	
BR	Brake System Rear	BR_A0200	Adapter	Adapter for pressure sensors	m	1	BR_02004	
BR	Brake System Rear	BR_A0200	Rear brake circuit	Hoses stainless lines with fittings	m	1	BR_02005	
BR	Brake System Rear	BR_A0200	[Assembly Processes]		m	1	P_BR_A0200	

BR	BR_A0200	Rear brake rotor	BR_02001	Back

BR	BR_A0200	Rear brake caliper	BR_02002	Back

BR BR_A0200 Rear brake reservoi BR_02003 Back

BR BR_A0200 Adapter BR_02004 Back

BR BR_A0200 Rear brake circuit BR_02005 [Back](#)

BR	Brake Master Cylinde	BR_A0300					Back
BR	Brake Master Cylinder	BR_A0300	Master Cylinder	Bought from Beringer	b	2	BR_03001

BR BR_A0300 Master Cylinder BR_03001 [Back](#)

BR	Balance Bar	BR_A0400							Back
BR	Balance Bar		BR_A0400	Balance bar	Bought from Reverchon	b	1	BR_04001	
BR	Balance Bar		BR_A0400	Master Cylinder support	Threaded aluminum part	m	2	BR_04002	

BR BR_A0400 Balance bar BR_04001 Back

BR BR_A0400 Master Cylinder support BR_04002 [Back]

EL	Dash Panel	EL_A0100						
EL	Dash Panel		EL_A0100	Dashboard plate	inside the front hoop	m	1	EL_01001
EL	Dash Panel		EL_A0100	LED Bar	RPM display	b	1	EL_01002
EL	Dash Panel		EL_A0100	2 way switch	for secondary fonctions	b	4	EL_01003
EL	Dash Panel		EL_A0100	3 way switch	contact switch	b	1	EL_01004
EL	Dash Panel		EL_A0100	push button red	with a red light circle	b	1	EL_01005
EL	Dash Panel		EL_A0100	push button blue	with a blue light circle	b	2	EL_01006
EL	Dash Panel		EL_A0100	1 digit I2C display board	display engaged gear	m	1	EL_01008
EL	Dash Panel		EL_A0100	3 digit I2C dislpay board	display water temp. Or Batt. Voltag	m	1	EL_01009
EL	Dash Panel		EL_A0100	front board	control the Dashboard and sensors	m	1	EL_01010
EL	Dash Panel		EL_A0100	front board box	protecting plastic case	b	1	EL_01011
EL	Dash Panel		EL_A0100	push button	without any light	b	2	EL_01007

Back

EL EL_A0100 Dashboard plate EL_01001 [Back]

EL EL_A0100 LED Bar EL_01002 Back

EL EL_A0100 2 way switch EL_01003 Back

EL EL_A0100 3 way switch EL_01004 Back

EL EL_A0100 push button red EL_01005 Back

EL EL_A0100 push button blue EL_01006 Back

EL EL_A0100 1 digit I2C display board EL_01008 [Back](#)

EL EL_A0100 3 digit I2C dislpay board EL_01009 [Back]

EL EL_A0100 front board EL_01010 Back

EL EL_A0100 front board box EL_01011 Back

EL EL_A0100 push button EL_01007 Back

EL	Sensors	EL_A0200						Back
EL	Sensors		EL_A0200	data logger	MK3	b	1	EL_02001
EL	Sensors		EL_A0200	data log connector set	connectors for the MK3	b	1	EL_02002
EL	Sensors		EL_A0200	wheel speed sensor	on each four wheels, Hall effect	b	4	EL_02003
EL	Sensors		EL_A0200	suspension travel sensor	on each four suspensions	b	4	EL_02004
EL	Sensors		EL_A0200	steering wheel pos sensor	in the steering rack	b	1	EL_02005
EL	Sensors		EL_A0200	pressure sensors	pressure of brake sys., fuel, oil	b	4	EL_02006
EL	Sensors		EL_A0200	Lambda sensor	placed on the exhaust	b	1	EL_02007
EL	Sensors		EL_A0200	Camshaft position sensor	present on the purchased engine	b	1	EL_02008
EL	Sensors		EL_A0200	throttle position	linear sensor on the throttle bod	b	1	EL_02009
EL	Sensors		EL_A0200	Air temp,pressure sensor	to the ECU	b	1	EL_02010
EL	Sensors		EL_A0200	Crankshaft pos sensor	present on the purchased engine	b	1	EL_02011
EL	Sensors		EL_A0200	Water temp sensor	to the ECU	b	1	EL_02012
EL	Sensors		EL_A0200	GPS Antenna	placed on top of the main hoop	b	1	EL_02013
EL	Sensors		EL_A0200	connectors for the sensor	to the harness (fr./re.)	b	14	EL_02014
EL	Sensors		EL_A0200	lambda connector	standard automobile connector	b	1	EL_02015
EL	Sensors		EL_A0200	camshaft sensors connectc	standard automobile connector	b	1	EL_02016
EL	Sensors		EL_A0200	Crankshaft sensor connect	standard automobile connector	b	1	EL_02017
EL	Sensors		EL_A0200	ECT connector	standard automobile connector	b	1	EL_02018
EL	Sensors		EL_A0200	TPS connector	standard automobile connector	b	1	EL_02019
EL	Sensors		EL_A0200	TMAP connector	standard automobile connector	b	1	EL_02020

EL EL_A0200 data logger EL_02001 Back

EL EL_A0200 data log connector set EL_02002 Back

EL EL_A0200 wheel speed senso EL_02003 [Back](#)

EL EL_A0200 suspension travel senso EL_02004 Back

EL EL_A0200 steering wheel pos senso EL_02005 Back

EL EL_A0200 pressure sensor: EL_02006 Back

EL EL_A0200 Lambda sensor EL_02007 Back

EL EL_A0200 Camshaft position sensor EL_02008 Back

EL EL_A0200 throttle position EL_02009 Back

EL EL_A0200 Air temp,pressure senso EL_02010 Back

EL EL_A0200 Crankshaft pos senso EL_02011 Back

EL EL_A0200 Water temp senso EL_02012 Back

EL EL_A0200 GPS Antenna EL_02013 Back

EL EL_A0200 connectors for the senso EL_02014 Back

EL EL_A0200 lambda connector EL_02015 Back

EL EL_A0200 camshaft sensors connectc EL_02016 Back

EL	EL_A0200	Crankshaft sensor connect	EL_02017	Back

EL EL_A0200 ECT connector EL_02018 Back

EL	EL_A0200	TPS connector	EL_02019	Back

EL	EL_A0200	TMAP connector EL_02020	Back

EL	Wire Harness/Connectors	EL_A0300						Back
EL	Wire Harness/Connectors	EL_A0300	front harness	link rear, dashboard, sensors	m	1	EL_03001	
EL	Wire Harness/Connectors	EL_A0300	rear harness	link fr. , servo motor, sensors, bat.	m	1	EL_03002	
EL	Wire Harness/Connectors	EL_A0300	connector front-rear	8STA71828S&P, sensors and Power	b	2	EL_03003	
EL	Wire Harness/Connectors	EL_A0300	connector BSPD	8STA70835S&P, Power and DATA	b	1	EL_03004	
EL	Wire Harness/Connectors	EL_A0300	connector rear board	8STA01497P&S, Power and DATA	b	2	EL_03005	
EL	Wire Harness/Connectors	EL_A0300	connector front board	8STA01002S&P, 5V Power	b	3	EL_03006	
EL	Wire Harness/Connectors	EL_A0300	Brake light	rear red light	b	1	EL_03007	
EL	Wire Harness/Connectors	EL_A0300	ECU	DTAFast S80 Pro	b	1	EL_03008	
EL	Wire Harness/Connectors	EL_A0300	ECU Power connector	power connector for the ECU	b	1	EL_03009	
EL	Wire Harness/Connectors	EL_A0300	DB-9 connector	Access to the DTA	b	1	EL_03010	
EL	Wire Harness/Connectors	EL_A0300	ECU Data connector	DATA Connector for the ECU	b	1	EL_03011	
EL	Wire Harness/Connectors	EL_A0300	3 phase rectifier connect	2 pin connector	b	2	EL_03012	
EL	Wire Harness/Connectors	EL_A0300	injectors connector	2 pin connector	b	4	EL_03013	
EL	Wire Harness/Connectors	EL_A0300	Fan connector	to be completed	b	1	EL_03014	
EL	Wire Harness/Connectors	EL_A0300	Brake light connector	to be completed	b	1	EL_03015	

EL	EL_A0300	front harness EL_03001	Back

EL EL_A0300 rear harness EL_03002 Back

EL EL_A0300 connector front-rear EL_03003 Back

EL EL_A0300 connector BSPD EL_03004 Back

EL EL_A0300 connector rear board EL_03005 Back

EL EL_A0300 connector front board EL_03006 Back

EL EL_A0300 Brake light EL_03007 Back

EL EL_A0300 ECU EL_03008 Back

EL EL_A0300 ECU Power connector EL_03009 [Back](#)

EL	EL_A0300	DB-9 connector	EL_03010	Back

EL EL_A0300 ECU Data connector EL_03011 [Back]

EL EL_A0300 3 phase rectifier connec EL_03012 Back

EL EL_A0300 injectors connector EL_03013 Back

EL	EL_A0300	Fan connector	EL_03014	Back

EL	EL_A0300	Brake light connector EL_03015	Back

EL	LV-Battery	EL_A0400						Back
EL	LV-Battery	EL_A0400	Battery support	on the rear rigth side	m	1	EL_04001	
EL	LV-Battery	EL_A0400	LV-Battery	12V Battery	b	1	EL_04002	
EL	LV-Battery	EL_A0400	Battery connector	Battery connector	m	2	EL_04003	
EL	LV-Battery	EL_A0400	Battery Fuse 250A	General fuse	b	1	EL_04004	
EL	LV-Battery	EL_A0400	Master switch	on the right hand side of the main hoo	b	1	EL_04005	
EL	LV-Battery	EL_A0400	Master switch pannel	on the right hand side of the main hoo	m	1	EL_04006	
EL	LV-Battery	EL_A0400	Booster connector	on the right hand side of the main hoo	b	1	EL_04007	
EL	LV-Battery	EL_A0400	3 phase rectifier	mounted on the fire wall	b	1	EL_04008	

EL EL_A0400 Battery support EL_04001 Back

EL EL_A0400 LV-Battery EL_04002 Back

EL EL_A0400 Battery connector EL_04003 Back

EL EL_A0400 Battery Fuse 250A EL_04004 Back

EL EL_A0400 Master switch EL_04005 Back

EL EL_A0400 Master switch pannel EL_04006 Back

EL EL_A0400 Booster connector EL_04007 Back

EL EL_A0400 3 phase rectifier EL_04008 Back

EL	Fuses	EL_A0500						Back
EL	Fuses	EL_A0500	Rear Fuse Box	on the rear left hand side	b	1	EL_05001	
EL	Fuses	EL_A0500	Brake light Fuse 3A	in the Fuse box	b	1	EL_05002	
EL	Fuses	EL_A0500	Fuse 10A	in the Fuse box, Fan, Fr. har.	b	2	EL_05003	
EL	Fuses	EL_A0500	Lambda sensor Fuse 5A	in the Fuse box	b	1	EL_05004	
EL	Fuses	EL_A0500	Pump Fuse 20A	in the Fuse box	b	1	EL_05005	
EL	Fuses	EL_A0500	Fuse 15A	Servo motor ,Inject., in the Fuse Bo	b	2	EL_05006	
EL	Fuses	EL_A0500	starter relay	on the right hand side of the motor	b	1	EL_05007	
EL	Fuses	EL_A0500	relays 35A	in the fuse box, fan, pump, DTA, rea	b	4	EL_05008	

35A
14VDC
301-1A-S-R1 12VDC
C1736
35A
14VDC
301-1A-S-R1 12VDC
35A/20A
14VDC
301-1C-C-D1 12VDC
JC1834
35A/20A
14VDC

EL	EL_A0500	Brake light Fuse 3A	EL_05002	Back

EL EL_A0500 Fuse 10A EL_05003 Back

EL EL_A0500 Lambda sensor Fuse 5/ EL_05004 Back

EL EL_A0500 Pump Fuse 20A EL_05005 Back

EL EL_A0500 Fuse 15A EL_05006 Back

EL EL_A0500 starter relay EL_05007 Back

EL EL_A0500 relays 35A EL_05008 Back

EL	Kill Switch	EL_A0600						Back
EL	Kill Switch		EL_A0600	Main hoop kill Switch	on both sides of the main hoop	b	2	EL_06001
EL	Kill Switch		EL_A0600	24mm kill Switch	Dashboard and BOTS	b	2	EL_06002
EL	Kill Switch		EL_A0600	BSPD	right hand side of the front hoo	m	1	EL_06003
EL	Kill Switch		EL_A0600	Crash sensor	right hand side of the front hoo	b	1	EL_06004
EL	Kill Switch		EL_A0600	BSPD Box	protecting metal case	b	1	EL_06005

EL EL_A0600 Main hoop kill Switch EL_06001 Back

EL EL_A0600 24mm kill Switch EL_06002 Back

EL EL_A0600 BSPD EL_06003 Back

EL EL_A0600 Crash sensor EL_06004 Back

EL EL_A0600 BSPD Box EL_06005 Back

EL	Control Unit	EL_A0700						Back
EL	Control Unit	EL_A0700	Rear box shifter	protecting plastic case	b	1	EL_07001	
EL	Control Unit	EL_A0700	Rear board shifter	control the servo motor	m	1	EL_07002	
EL	Control Unit	EL_A0700	Servo motor cables	set of cable for the servo motor	b	1	EL_07003	
EL	Control Unit	EL_A0700	Servo motor	controled high power motor	b	1	EL_07004	
EL	Control Unit	EL_A0700	servo motor support 1	support the servo motor assembly	m	1	EL_07005	
EL	Control Unit	EL_A0700	servo motor support 2	support the servo motor assembly	m	1	EL_07006	
EL	Control Unit	EL_A0700	Paddle	placed on the steering wheel	b	1	EL_07007	

EL EL_A0700 Rear box shifter EL_07001 Back

EL EL_A0700 Rear board shifter EL_07002 [Back](#)

EL EL_A0700 Servo motor cables EL_07003 Back

EL EL_A0700 Servo motor EL_07004 Back

EL EL_A0700 servo motor support 1 EL_07005 Back

EL EL_A0700 servo motor support 2 EL_07006 Back

EL EL_A0700 Paddle EL_07007 Back

EN	Engine	EN_A0100						Back
EN	Engine		EN_A0100	Honda CBR600RR Engine	Second-hand, PC40	b	1	EN_01001
EN	Engine		EN_A0100	Fuel injectors	Second hand	b	4	EN_01002
EN	Engine		EN_A0100	Spark plugs	Second hand	b	4	EN_01003
EN	Engine		EN_A0100	Wet slipper clutch	To help with downshifting	b	1	EN_01004
EN	Engine		EN_A0100	Thermostat	From PC37, new	b	1	EN_01005
EN	Engine		EN_A0100	PAIR plate	Permit to close the PAIR sensors	m	2	EN_01006
EN	Engine		EN_A0100	Adaptater oil pressure	Permit to plug our oil pressure sensors	m	1	EN_01007
EN	Engine		EN_A0100	Oil sump shell	Contain engine's oil	m	1	EN_01008
EN	Engine		EN_A0100	Join plate	Weld with sump shell, attached to engin	b	1	EN_01009
EN	Engine		EN_A0100	Anti-planing plate	Limit oil move, welded with oil sump	m	1	EN_01010
EN	Engine		EN_A0100	Smooth clutch disc	Discs of the clutch system, new	b	8	EN_01011
EN	Engine		EN_A0100	Lining clutch disc	Discs of the clutch system, new	b	7	EN_01012
EN	Engine		EN_A0100	Shifter axis	Shaft between Shifter and gear motor	m	1	EN_01013
EN	Engine		EN_A0100	Shifter gear	Assemble with shifter axis	m	1	EN_01014

EN EN_A0100 Honda CBR600RR Engine EN_01001 Back

EN EN_A0100 Spark plugs EN_01003 Back

EN EN_A0100 Wet slipper clutch EN_01004 Back

EN EN_A0100 Thermostat EN_01005 Back

EN EN_A0100 PAIR plate EN_01006 Back

EN EN_A0100 Adaptater oil pressure EN_01007 [Back]

EN EN_A0100 Oil sump shell EN_01008 [Back]

EN EN_A0100 Join plate EN_01009 Back

EN EN_A0100 Anti-planing plate EN_01010 [Back]

EN EN_A0100 Smooth clutch disc EN_01011 Back

EN EN_A0100 Lining clutch disc EN_01012 Back

EN EN_A0100 Shifter axis EN_01013 [Back](#)

EN EN_A0100 Shifter gear EN_01014 [Back]

EN	Exhaust System	EN_A0200						Back
EN	Exhaust System	EN_A0200	Exhaust header n┬ 1	Collect gas from the 1st cylinder	m	1	EN_02001	
EN	Exhaust System	EN_A0200	Exhaust header n┬ 2	Collect gas from the 2nd cylinder	m	1	EN_02002	
EN	Exhaust System	EN_A0200	Exhaust header n┬ 3	Collect gas from the 3rd cylinder	m	1	EN_02003	
EN	Exhaust System	EN_A0200	Exhaust header n┬ 4	Collect gas from the 4th cylinder	m	1	EN_02004	
EN	Exhaust System	EN_A0200	1st tubing collector n┬ 1	Collect gas from exhaust header 1 and	m	1	EN_02005	
EN	Exhaust System	EN_A0200	1st tubing collector n┬ 2	Collect gas from exhaust header 2 and	m	1	EN_02006	
EN	Exhaust System	EN_A0200	2nd tubing collector	Collect gas from primary collectors	m	1	EN_02007	
EN	Exhaust System	EN_A0200	Exhaust flange	Join the collector to the engine	m	4	EN_02008	
EN	Exhaust System	EN_A0200	Muffler	Buy with a chicane	b	1	EN_02009	
EN	Exhaust System	EN_A0200	Muffler clamp	Fasten the muffler to the frame	m	1	EN_02010	
EN	Exhaust System	EN_A0200	Exhaust tip	Part chich link collector to engine	m	4	EN_02011	

EN EN_A0200 Exhaust header n 1 EN_02001 Back

EN EN_A0200 Exhaust header n 2 EN_02002 Back

EN EN_A0200 Exhaust header n 3 EN_02003 Back

EN EN_A0200 Exhaust header n┬4 EN_02004 Back

EN EN_A0200 1st tubing collector n 1 EN_02005 Back

EN EN_A0200 1st tubing collector n T 2 EN_02006 Back

EN EN_A0200 2nd tubing collector EN_02007 Back

EN EN_A0200 Exhaust flange EN_02008 [Back]

EN EN_A0200 Muffler EN_02009 Back

EN EN_A0200 Muffler clamp EN_02010 [Back]

EN EN_A0200 Exhaust tip EN_02011 Back

EN	Intake System	EN_A0300						Back
EN	Intake System	EN_A0300	Air manifold	Under the restrictor	b	1	EN_03001	
EN	Intake System	EN_A0300	Flat-bottomed	Under the air manifold	m	1	EN_03002	
EN	Intake System	EN_A0300	Tubing collector	Link up the flat-bottomed to the engin	b	1	EN_03003	
EN	Intake System	EN_A0300	Coupling sleeve	Link up the air intake to the engine	b	2	EN_03004	
EN	Intake System	EN_A0300	Left frame mounting tube	Fasten the air intake to the frame	m	1	EN_03005	
EN	Intake System	EN_A0300	Right frame mounting tube	Fasten the air intake to the frame	m	1	EN_03006	
EN	Intake System	EN_A0300	Engine mounting tube	Fasten the air intake to the engine	m	2	EN_03007	
EN	Intake System	EN_A0300	Mounting plate	Fasten the restrictor to the air intake	m	2	EN_03008	

AIRRIK

EN EN_A0300 Flat-bottomed EN_03002 [Back](#)

EN EN_A0300 Coupling sleeve EN_03004 Back

EN EN_A0300 Left frame mounting tube EN_03005 Back

EN EN_A0300 Right frame mounting tube EN_03006 Back

EN EN_A0300 Engine mounting tube EN_03007 Back

EN EN_A0300 Mounting plate EN_03008 [Back](#)

EN	Throttle Body EN_A0400						Back
EN	Throttle Body	EN_A0400	Inferior plate	Under the moving plate	m	1	EN_04001
EN	Throttle Body	EN_A0400	Front stop plate	Stop the translation of the moving plat	m	1	EN_04002
EN	Throttle Body	EN_A0400	Rear stop plate	Stop the translation of the moving plat	m	1	EN_04003
EN	Throttle Body	EN_A0400	Medium plate	Moving plate	m	1	EN_04004
EN	Throttle Body	EN_A0400	Superior plate	Above the moving plate	m	1	EN_04005
EN	Throttle Body	EN_A0400	Air filter	Filter the air which goes to the engine	b	1	EN_04006
EN	Throttle Body	EN_A0400	Convergent	Link up the filter to the slide throttle	b	1	EN_04007
EN	Throttle Body	EN_A0400	Air restrictor	Link up the slide throttle to the intake	b	1	EN_04008
EN	Throttle Body	EN_A0400	[Assembly Processes]		m	1	P_EN_A0400

EN EN_A0400 Inferior plate EN_04001 [Back]

EN EN_A0400 Front stop plate EN_04002 [Back]

EN EN_A0400 Rear stop plate EN_04003 [Back](#)

EN EN_A0400 Medium plate EN_04004 [Back]

EN EN_A0400 Superior plate EN_04005 [Back](#)

EN EN_A0400 Convergent EN_04007 Back

EN EN_A0400 Air restrictor EN_04008 Back

EN	Other: Fuel system	EN_A0500					
EN	Other: Fuel system	EN_A0500	Fuel Rail	Above the Engine	b	1	EN_05001
EN	Other: Fuel system	EN_A0500	Fuel Pump	Under the Fuel Tank	b	1	EN_05002
EN	Other: Fuel system	EN_A0500	Pressure Regulator	Left side of the Engine	b	1	EN_05003
EN	Other: Fuel system	EN_A0500	Fuel Filter	Next to the Fuel Pump	b	1	EN_05004
EN	Other: Fuel system	EN_A0500	Fuel Pump Collar	Around the Fuel Pump	m	1	EN_05005
EN	Other: Fuel system	EN_A0500	Pressure Sensor Adapte	At the end of the Fuel Ra	m	1	EN_05006

Back

EN EN_A0500 Fuel Rail EN_05001 Back

EN EN_A0500 Pressure Regulator EN_05003 Back

EN EN_A0500 Fuel Pump Co EN_05005 Back

EN EN_A0500 Pressure Sensor Adapte EN_05006 [Back]

EN	Cooling System	EN_A0600						Back
EN	Cooling System	EN_A0600	Radiator	Aluminum radiator	b	1	EN_06001	
EN	Cooling System	EN_A0600	Fan	SPAL Fan 1360M3/H	b	1	EN_06002	
EN	Cooling System	EN_A0600	Expansion tank base	Part of expansion tank wielded to fille	m	1	EN_06003	
EN	Cooling System	EN_A0600	Expansion tank filler nec	Receives the tank cap	b	1	EN_06004	
EN	Cooling System	EN_A0600	Expansion tank cap	Expansion tank cap	b	1	EN_06005	
EN	Cooling System	EN_A0600	Fixing tube	Maintains the radiator	m	1	EN_06006	
EN	Cooling System	EN_A0600	Radiator tab	Tabs wielded to the radiator	m	1	EN_06007	
EN	Cooling System	EN_A0600	Expansion tank tab	Wielded to the tank	m	1	EN_06008	
EN	Cooling System	EN_A0600	Main coolant line	Engine - radiator links	m	1	EN_06009	
EN	Cooling System	EN_A0600	Secondary coolant line	Engine - expansion tank	m	1	EN_06010	

EN EN_A0600 Expansion tank base EN_06003 Back

EN	EN_A0600	Expansion tank filler nec	EN_06004	Back

EN EN_A0600 Expansion tank cap EN_06005 [Back]

EN EN_A0600 Main coolant line EN_06009 Back

EN EN_A0600 Secondary coolant line EN_06010 Back

EN	Drivetrain Assembly	EN_A0700						Back
EN	Drivetrain Assembly	EN_A0700	Differential	Adjustable Limited Slip	b	1	EN_07001	
EN	Drivetrain Assembly	EN_A0700	Eccentric left	Carry the differential	m	1	EN_07002	
EN	Drivetrain Assembly	EN_A0700	Eccentric right	Carry the differential	m	1	EN_07003	
EN	Drivetrain Assembly	EN_A0700	Eccentric carrier left	Link between drivetrain and frame	m	1	EN_07004	
EN	Drivetrain Assembly	EN_A0700	Eccentric carrier right	Link between drivetrain and frame	m	1	EN_07005	
EN	Drivetrain Assembly	EN_A0700	Ball bearing left	Ball bearing	b	1	EN_07006	
EN	Drivetrain Assembly	EN_A0700	Ball bearing right	Ball bearing	b	1	EN_07007	
EN	Drivetrain Assembly	EN_A0700	Needle roller bearing	Between drive shaft and differential	b	2	EN_07008	
EN	Drivetrain Assembly	EN_A0700	Chain	Chain	b	1	EN_07009	
EN	Drivetrain Assembly	EN_A0700	Front sprocket	Link between chain and output of the mo	b	1	EN_07010	
EN	Drivetrain Assembly	EN_A0700	Rear sprocket	Link between chain and rear sprocket ada	b	1	EN_07011	
EN	Drivetrain Assembly	EN_A0700	Rear sprocket adaptator	Link between rear sprocket and different	m	1	EN_07012	
EN	Drivetrain Assembly	EN_A0700	Chainshield	Protection around the chain	m	1	EN_07013	
EN	Drivetrain Assembly	EN_A0700	Driveshaft left	Driveshaft	b	1	EN_07014	
EN	Drivetrain Assembly	EN_A0700	Driveshaft right	Driveshaft	b	1	EN_07015	
EN	Drivetrain Assembly	EN_A0700	Tripod	Enable small displacement of driveshafts	b	4	EN_07016	
EN	Drivetrain Assembly	EN_A0700	Inner tripod housing	Link differential and driveshaft	b	2	EN_07017	
EN	Drivetrain Assembly	EN_A0700	Outer tripod housing	Link between wheel and driveshat	b	2	EN_07018	
EN	Drivetrain Assembly	EN_A0700	Tripod housing nut	Nylstop, non metric	b	2	EN_07019	
EN	Drivetrain Assembly	EN_A0700	Axle boots	Over driveshafts and tripod housings	b	4	EN_07020	

EN EN_A0700 Eccentric left EN_07002 Back

EN EN_A0700 Eccentric right EN_07003 [Back]

EN EN_A0700 Eccentric carrier left EN_07004 [Back]

EN EN_A0700 Eccentric carrier right EN_07005 Back

EN EN_A0700 Ball bearing left EN_07006 Back

EN EN_A0700 Ball bearing right EN_07007 Back

EN EN_A0700 Needle roller bearing EN_07008 Back

EN EN_A0700 Chain EN_07009 Back

EN EN_A0700 Front sprocket EN_07010 Back

EN EN_A0700 Rear sprocket EN_07011 Back

EN EN_A0700 Rear sprocket adaptatoı EN_07012 [Back](#)

EN EN_A0700 Chainshield EN_07013 Back

EN EN_A0700 Driveshaft left EN_07014 Back

EN EN_A0700 Driveshaft right EN_07015 Back

EN EN_A0700 Tripod EN_07016 Back

EN EN_A0700 Inner tripod housing EN_07017 Back

EN EN_A0700 Outer tripod housing EN_07018 Back

EN EN_A0700 Tripod housing nut EN_07019 Back

EN	Overflow Bottles	EN_A0800						Back
EN	Overflow Bottles	EN_A0800	Oil overflow	Contain the oil overflow	m	1	EN_08001	
EN	Overflow Bottles	EN_A0800	Water overflow	Contain the water overflow	m	1	EN_08002	
EN	Overflow Bottles	EN_A0800	[Assembly Processes]		m	1	EN_A0800_P	

EN EN_A0800 Oil overflow EN_08001 Back

EN EN_A0800 Water overflow EN_08002 Back

EN	Fuel Tank ÔÇô NOT THE HV-Batter	EN_A0900						Back
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900	Fuel Tank(main1)	Under the seat (Folding-front part))	m	1	EN_09001	
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900	Fuel Tank(main2)	Under the seat (Folding-top part)	m	1	EN_09002	
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900	Fuel Tank(bottom)	Under the seat (Folding-bottom part	m	1	EN_09003	
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900	Fuel Tank(Triangle	Under the seat (With Fuel Tank)	m	1	EN_09004	
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900	Filler Neck	Welded to Fuel Tank	m	1	EN_09005	
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900	Filler Cap	On the top of filler Tube	b	1	EN_09006	
EN	Fuel Tank ÔÇô NOT THE HV-Battery	EN_A0900	Filler Tube	With Fuel Tank	m	1	EN_09007	

EN EN_A0900 Fuel Tank(main1) EN_09001 [Back](#)

EN EN_A0900 Fuel Tank(main2) EN_09002 [Back]

EN EN_A0900 Fuel Tank(bottom) EN_09003 [Back]

EN EN_A0900 Fuel Tank(Triangle) EN_09004 [Back]

EN EN_A0900 Filler Neck EN_09005 Back

EN EN_A0900 Filler Cap EN_09006 Back

EN EN_A0900 Filler Tube EN_09007 Back

FR	Brackets	FR_0200_BR						Back
FR	Brackets	Braking System	FR_0200_BR	Front pedal bracket	S355, 3mm thick	m	4	FR_02001_BR
FR	Brackets	Braking System	FR_0200_BR	Rear pedal bracket	S355, 3mm thick	m	4	FR_02002_BR
FR	Brackets	Braking System	FR_0200_BR	Pedal fluid tank bracket	S355, 1.5mm thick	m	1	FR_02003_BR
FR	Brackets	Braking System	FR_0200_BR	Tee breaking bracket	S355, 1.5mm thick	m	1	FR_02004_BR

FR FR_0200_BR Front pedal bracket FR_02001_BR Back

FR FR_0200_BR Rear pedal bracket FR_02002_BR [Back]

FR FR_0200_BR Pedal fluid tank bracket FR_02003_BR [Back](#)

FR FR_0200_BR Tee breaking bracke FR_02004_BR Back

FR	Brackets	FR_0200_EL							Back
FR	Brackets	Electrical	FR_0200_EL	Dashboard bracket 1	S235, 1.5mm thick	m	2	FR_02001_EL	
FR	Brackets	Electrical	FR_0200_EL	Dashboard bracket 2	S235, 1.5mm thick	m	1	FR_02002_EL	
FR	Brackets	Electrical	FR_0200_EL	Dashboard bracket 3	S235, 1.5mm thick	m	1	FR_02003_EL	
FR	Brackets	Electrical	FR_0200_EL	Emergency stop bracket	S355, 3mm thick	m	2	FR_02004_EL	
FR	Brackets	Electrical	FR_0200_EL	Support battery bracket 2	S235, 1.5mm thick	m	1	FR_02005_EL	
FR	Brackets	Electrical	FR_0200_EL	Power box bracket	S235, 1.5mm thick	m	2	FR_02006_EL	
FR	Brackets	Electrical	FR_0200_EL	Master switch bracket	S235, 1.5mm thick	m	2	FR_02007_EL	
FR	Brackets	Electrical	FR_0200_EL	Crash sensor bracket	S235, 1.5mm thick	m	1	FR_02008_EL	
FR	Brackets	Electrical	FR_0200_EL	Support battery bracket 1	S235, 1.5mm thick	m	2	FR_02009_EL	
FR	Brackets	Electrical	FR_0200_EL	Electrical earth bracket	S235, 1.5mm thick	m	4	FR_02010_EL	
FR	Brackets	Electrical	FR_0200_EL	Breaklight bracket	S235, 1.5mm thick	m	1	FR_02011_EL	
FR	Brackets	Electrical	FR_0200_EL	Booster bracket	S355, 3mm thick	m	1	FR_02012_EL	

FR FR_0200_EL Dashboard bracket 1 FR_02001_EL Back

FR FR_0200_EL Dashboard bracket 2 FR_02002_EL [Back]

FR FR_0200_EL Dashboard bracket 3 FR_02003_EL [Back](#)

FR FR_0200_EL Emergency stop bracket FR_02004_EL [Back](#)

FR FR_0200_EL Support battery bracket 2 FR_02005_EL [Back]

FR FR_0200_EL Power box bracket FR_02006_EL [Back]

FR FR_0200_EL Master switch bracket FR_02007_EL Back

FR FR_0200_EL Crash sensor bracket FR_02008_EL [Back]

FR FR_0200_EL Support battery bracket 1 FR_02009_EL [Back]

FR FR_0200_EL Electrical earth bracket FR_02010_EL [Back]

FR FR_0200_EL Breaklight bracket FR_02011_EL [Back]

FR FR_0200_EL Booster bracket FR_02012_EL [Back]

FR	Brackets	FR_0200_EN							Back
FR	Brackets	Engine & Powertrain	FR_0200_EN	Engine bracket	S700, 4mm thick	m	2	FR_02001_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Up excentric carry brack1	S355, 3mm thick	m	2	FR_02002_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Low excentric carry brack	S355, 3mm thick	m	4	FR_02003_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Up excentric carry brack2	S355, 3mm thick	m	2	FR_02004_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Fuel tank bracket	S235, 3mm thick	m	4	FR_02005_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Chain shield bracket 1	S355, 3mm thick, top	m	1	FR_02006_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Pump bracket	S235, 3mm thick	m	1	FR_02007_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Regulator bracket	S235, 2mm thick, for pressure regulato	m	1	FR_02008_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Shifter bracket	S355, 3mm thick	m	1	FR_02009_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Radiator bracket 1	S355, 3mm thick, rear	m	1	FR_02010_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Expansion tank bracket	S235, 1.5mm thick	m	1	FR_02011_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Air admission bracket	S235, 1.5mm thick	m	2	FR_02012_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Clutch actuation axis	S355, 1.5mm thick	m	1	FR_02013_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Clutch actu. cable holder	S355, 1.5mm thick	m	1	FR_02014_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Chain shield bracket 2	S355, 3mm thick, top	m	1	FR_02015_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Radiator bracket 2	S355, 3mm thick, front	m	1	FR_02016_EN	
FR	Brackets	Engine & Powertrain	FR_0200_EN	Radiator bracket 3	S355, 3mm thick, top	m	1	FR_02017_EN	

FR FR_0200_EN Engine bracket FR_02001_EN [Back](#)

FR FR_0200_EN Up excentric carry brack1 FR_02002_EN [Back](#)

FR FR_0200_EN Low excentric carry brack FR_02003_EN [Back](#)

FR FR_0200_EN Up excentric carry brack2 FR_02004_EN [Back](#)

FR FR_0200_EN Fuel tank bracket FR_02005_EN [Back]

FR FR_0200_EN Chain shield bracket 1 FR_02006_EN Back

FR FR_0200_EN Pump bracket FR_02007_EN Back

FR FR_0200_EN Regulator bracket FR_02008_EN Back

FR FR_0200_EN Shifter bracket FR_02009_EN [Back](#)

FR FR_0200_EN Radiator bracket 1 FR_02010_EN [Back](#)

FR FR_0200_EN Expansion tank bracket FR_02011_EN [Back]

FR FR_0200_EN Air admission bracket FR_02012_EN [Back]

FR FR_0200_EN Clutch actuation axis FR_02013_EN Back

FR FR_0200_EN Clutch actu. cable holder FR_02014_EN [Back]

FR FR_0200_EN Chain shield bracket 2 FR_02015_EN Back

FR FR_0200_EN Radiator bracket 2 FR_02016_EN [Back](#)

FR FR_0200_EN Radiator bracket 3 FR_02017_EN [Back]

FR	Brackets	FR_0200_FR						Back
FR	Brackets	Frame & Body	FR_0200_FR	Jacking bar bracket	attached to excentric carriers	m	2	FR_02001_FR
FR	Brackets	Frame & Body	FR_0200_FR	Body bracket	S235, 1.5mm thick	m	4	FR_02002_FR
FR	Brackets	Frame & Body	FR_0200_FR	Floor pan bracket	S235, 1.5mm thick	m	8	FR_02003_FR

FR FR_0200_FR Jacking bar bracket FR_02001_FR [Back](#)

FR FR_0200_FR Body bracket FR_02002_FR [Back]

FR FR_0200_FR Floor pan bracket FR_02003_FR [Back]

FR	Brackets	FR_0200_MS							Back
FR	Brackets	Miscelleanous, Finish & Assembly	FR_0200_MS	Upper bucket seat bracke	S355, 3mm thick	m	2	FR_02001_MS	
FR	Brackets	Miscelleanous, Finish & Assembly	FR_0200_MS	Lower bucket seat bracke	S355, 3mm thick	m	4	FR_02002_MS	
FR	Brackets	Miscelleanous, Finish & Assembly	FR_0200_MS	Harness bracket	S700, 4mm thick	m	2	FR_02003_MS	
FR	Brackets	Miscelleanous, Finish & Assembly	FR_0200_MS	Head support bracket	S355, 3mm thick	m	2	FR_02004_MS	
FR	Brackets	Miscelleanous, Finish & Assembly	FR_0200_MS	Firewall bracket	S235, 1.5mm thick	m	12	FR_02005_MS	

FR FR_0200_MS Upper bucket seat bracke FR_02001_MS Back

FR FR_0200_MS Lower bucket seat bracke FR_02002_MS Back

FR FR_0200_MS Harness bracket FR_02003_MS Back

FR FR_0200_MS Head support bracket FR_02004_MS Back

FR FR_0200_MS Firewall bracket FR_02005_MS Back

FR	Brackets	FR_0200_ST						Back
FR	Brackets	Steering system	FR_0200_ST	Rack brackets	S235, 1.5mm thick	m	2	FR_02001_ST

FR FR_0200_ST Rack brackets FR_02001_ST [Back](#)

FR	Brackets	FR_0200_SU							Back
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper fr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02001_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper fr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02002_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper fr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02003_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper fr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02004_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower fr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02005_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower fr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02006_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper rr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02007_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper rr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02008_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower rr arm fr_2	upper part, S700, 4mm thick	m	2	FR_02009_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower rr arm fr_1	lower part, S700, 4mm thick	m	2	FR_02010_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower fr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02011_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower fr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02012_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper rr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02013_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm upper rr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02014_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower rr arm rr_2	upper part, S700, 4mm thick	m	2	FR_02015_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	A-arm lower rr arm rr_1	lower part, S700, 4mm thick	m	2	FR_02016_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	Fr anti roll bar bracket	S700, 4mm thick	m	2	FR_02017_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	Rr anti roll bar bracket	S355, 3mm thick	m	2	FR_02018_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	Front rocker bracket 1	S355, 3mm thick	m	2	FR_02019_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	Front rocker bracket 2	S355, 3mm thick	m	2	FR_02020_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	Ohlins front bracket	S355, 3mm thick	m	2	FR_02021_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	Ohlins rear bracket	CNC machining	m	2	FR_02022_SU	
FR	Brackets	Suspension bracket	FR_0200_SU	Rear rocker bracket	CNC machined part	m	2	FR_02023_SU	

FR FR_0200_SU A-arm upper fr arm fr_ FR_02001_SU Back

FR FR_0200_SU A-arm upper fr arm fr_ FR_02002_SU Back

FR FR_0200_SU A-arm upper fr arm rr_2 FR_02003_SU Back

FR FR_0200_SU A-arm upper fr arm rr_: FR_02004_SU [Back](#)

FR FR_0200_SU A-arm lower fr arm fr_; FR_02005_SU [Back](#)

FR FR_0200_SU A-arm lower fr arm fr_: FR_02006_SU [Back](#)

FR FR_0200_SU A-arm upper r FR_02007_SU Back

FR FR_0200_SU A-arm upper rr arm fr_: FR_02008_SU [Back](#)

FR FR_0200_SU A-arm lower rr arm fr_: FR_02009_SU [Back](#)

FR FR_0200_SU A-arm lower rr arm fr_: FR_02010_SU [Back](#)

FR FR_0200_SU A-arm lower fr arm rr_: FR_02011_SU [Back](#)

FR FR_0200_SU A-arm lower fr arm rr_: FR_02012_SU Back

FR FR_0200_SU A-arm upper rr arm rr_2 FR_02013_SU [Back](#)

FR FR_0200_SU A-arm upper rr arm rr_1 FR_02014_SU [Back](#)

FR FR_0200_SU A-arm lower rr arm rr_2 FR_02015_SU [Back](#)

FR FR_0200_SU A-arm lower rr arm rr_: FR_02016_SU [Back](#)

FR FR_0200_SU Fr anti roll bar bracket FR_02017_SU Back

FR FR_0200_SU Rr anti roll bar bracket FR_02018_SU Back

FR FR_0200_SU Front rocker bracket 1 FR_02019_SU Back

FR FR_0200_SU Front rocker bracket 2 FR_02020_SU Back

FR FR_0200_SU Ohlins front bracket FR_02021_SU Back

FR FR_0200_SU Ohlins rear bracket FR_02022_SU [Back]

FR FR_0200_SU Rear rocker bracket FR_02023_SU Back

FR	Frame / Frame Tubes	FR_A0100						Back
FR	Frame / Frame Tubes	FR_A0100	Round steel tubing	25CrMo4 ; 30*1,5, 25*1,5, 20*15, 15*1,5	m	87	FR_01001	
FR	Frame / Frame Tubes	FR_A0100	Square steel tubing	25CrMo4 ; 20*20*1,5 (mm)	m	1	FR_01002	
FR	Frame / Frame Tubes	FR_A0100	Round bent steel tubing	25CrMo4 ; 30*2 (mm)	m	2	FR_01003	
FR	Frame / Frame Tubes	FR_A0100	Steering bore	CNC machining	m	1	FR_01004	
FR	Frame / Frame Tubes	FR_A0100	Jacking bar	CNC machining	m	1	FR_01005	
FR	Frame / Frame Tubes	FR_A0100	Sleeved joint	S350 ; Rules-compliant sleeved joints	m	2	FR_01006	

FR	FR_A0100	Round steel tubing FR_01001	Back

FR	FR_A0100	Square steel tubing	FR_01002	Back

FR	FR_A0100	Round bent steel tubing	FR_01003	Back

FR FR_A0100 Steering bore FR_01004 [Back](#)

FR	FR_A0100	Jacking bar	FR_01005	Back

FR	FR_A0100	Sleeved joint	FR_01006	Back

FR	Impact Attenuator FR_A0300							Back
FR	Impact Attenuator	FR_A0300	Impact attenuator	Approved by event	b	1	FR_03001	
FR	Impact Attenuator	FR_A0300	Anti-Intrusion plate	Steel, (thickness 1.5mm)	m	1	FR_03002	

FR	FR_A0300	Impact attenuator FR_03001	Back

FR	FR_A0300	Anti-Intrusion plate FR_03002	Back

FR	Pedals	FR_A0400					

[Back](#)

FR	Pedals	FR_A0400	Upper rail brake pedal	Allow easy setup	m	1	FR_04001
FR	Pedals	FR_A0400	Lower rail	Same for pedal accel and brake	m	2	FR_04002
FR	Pedals	FR_A0400	Accelerator pedal	Aluminium, machining	m	1	FR_04003
FR	Pedals	FR_A0400	Brake pedal	Aluminium, machined part	m	1	FR_04004
FR	Pedals	FR_A0400	Top foot support	Laser cutted part + bending	m	2	FR_04005
FR	Pedals	FR_A0400	Below foot support	Laser cutted part + bending	m	2	FR_04006
FR	Pedals	FR_A0400	Side support brake peda	Lateral support	m	2	FR_04007
FR	Pedals	FR_A0400	Side support accelerator	Symmetric allow FR_04018 to slide	m	2	FR_04008
FR	Pedals	FR_A0400	Rod accelerator	Rod mounted btw pedal and cable suppor	m	2	FR_04009
FR	Pedals	FR_A0400	Brake support	Brake over-travel switch support	m	1	FR_04010
FR	Pedals	FR_A0400	Cable sheath support	For accel. cable sheath	m	1	FR_04011
FR	Pedals	FR_A0400	Inside spacer	Upper part of the master cylinder	m	2	FR_04012
FR	Pedals	FR_A0400	Outside spacer	Upper part of the master cylinder	m	2	FR_04013
FR	Pedals	FR_A0400	Upper rail accel. pedal	Allow easy setup	m	1	FR_04014
FR	Pedals	FR_A0400	Accel. cable sheath	Cable protection	b	1	FR_04015
FR	Pedals	FR_A0400	Accel. cable	To open the throttle	b	1	FR_04016
FR	Pedals	FR_A0400	Throttle pedal stop	Mechanical stop	m	1	FR_04017
FR	Pedals	FR_A0400	Accel pedal slide part	Steel, slide on FR_04008	m	1	FR_04018

FR FR_A0400 Upper rail brake peda FR_04001 [Back]

FR FR_A0400 Lower rail FR_04002 Back

FR FR_A0400 Accelerator pedal FR_04003 [Back](#)

FR FR_A0400 Brake pedal FR_04004 [Back]

FR FR_A0400 Top foot support FR_04005 [Back]

FR FR_A0400 Below foot support FR_04006 [Back]

FR FR_A0400 Side support brake peda FR_04007 [Back]

FR FR_A0400 Side support accelerator FR_04008 [Back]

FR FR_A0400 Rod accelerator FR_04009 [Back]

FR FR_A0400 Brake support FR_04010 [Back](#)

FR FR_A0400 Cable sheath support FR_04011 [Back]

FR FR_A0400 Inside spacer FR_04012 [Back]

FR FR_A0400 Outside spacer FR_04013 [Back](#)

FR FR_A0400 Upper rail accel. pedal FR_04014 [Back]

FR FR_A0400 Accel. cable sheath FR_04015 Back

FR FR_A0400 Accel. cable FR_04016 Back

FR FR_A0400 Throttle pedal stop FR_04017 [Back]

FR FR_A0400 Accel pedal slide part FR_04018 [Back]

FR	Floor Pan	FR_A0500						Back
FR	Floor Pan	FR_A0500	Front floor pan	Floor pan from front hoop to front car	b	1	FR_05001	
FR	Floor Pan	FR_A0500	Rear floor pan	Floor pan from front hoop to main hoo	b	1	FR_05002	

FR FR_A0500 Front floor pan FR_05001 [Back]

FR FR_A0500 Rear floor pan FR_05002 [Back]

FR	Other: Clutch actuation system	FR_A0600						Back
FR	Other: Clutch actuation system	FR_A0600	Lever	Drilled tube	m	1	FR_06001	
FR	Other: Clutch actuation system	FR_A0600	Clutch cable sheath	-	b	1	FR_06002	
FR	Other: Clutch actuation system	FR_A0600	Clutch cable	-	b	1	FR_06003	
FR	Other: Clutch actuation system	FR_A0600	Lock plate	In the lever, prevent cable from removi	m	1	FR_06004	
FR	Other: Clutch actuation system	FR_A0600	Cable protectors	On the lever, prevent cable from cuttin	m	2	FR_06005	
FR	Other: Clutch actuation system	FR_A0600	Bronze rings	Lubrificating rings for the lever	b	2	FR_06006	

FR FR_A0600 Lever FR_06001 [Back](#)

FR FR_A0600 Clutch cable sheath FR_06002 Back

FR FR_A0600 Clutch cable FR_06003 Back

FR FR_A0600 Lock plate FR_06004 Back

FR FR_A0600 Cable protectors FR_06005 Back

FR FR_A0600 Bronze rings FR_06006 Back

FR	Other: Bodywork	FR_A0700						Back
FR	Other: Bodywork	FR_A0700	Nose	Nose of the bodywork	b	1	FR_07001	
FR	Other: Bodywork	FR_A0700	Back nose	Part of the nose after the suspensions	b	1	FR_07002	
FR	Other: Bodywork	FR_A0700	Big side plate	Side plate from the front hoop to mai	b	2	FR_07003	
FR	Other: Bodywork	FR_A0700	Middle side plate	Lower side plate with holes	b	2	FR_07004	
FR	Other: Bodywork	FR_A0700	Medium side plate	Side plate over the middle side plate	b	2	FR_07005	
FR	Other: Bodywork	FR_A0700	Small side plate	Side plate next to impact attenuator	b	2	FR_07006	
FR	Other: Bodywork	FR_A0700	Push clips	Attachement of the nose to the frame	b	4	FR_07007	

FR FR_A0700 Nose FR_07001 Back

FR FR_A0700 Back nose FR_07002 [Back]

FR FR_A0700 Big side plate FR_07003 [Back](#)

FR FR_A0700 Middle side plate FR_07004 [Back](#)

FR FR_A0700 Medium side plate FR_07005 [Back](#)

FR FR_A0700 Small side plate FR_07006 [Back]

FR	FR_A0700	Push clips	FR_07007	Back

MS	Fire Wall	MS_A0100						Back
MS	Fire Wall		MS_A0100	Firewall Bottom Plate	Behind the seat	m	1	MS_01001
MS	Fire Wall		MS_A0100	Firewall Middle Plate	Below harness	m	1	MS_01002
MS	Fire Wall		MS_A0100	Firewall Top Plate	At the back of the head foam	m	1	MS_01003
MS	Fire Wall		MS_A0100	Firewall Joints	Triangles for MS_01003	m	2	MS_01004
MS	Fire Wall		MS_A0100	Firewall Floor Plate	Join the Firewall to the Floor Par	m	1	MS_01005

MS MS_A0100 Firewall Bottom Plate MS_01001 [Back]

MS MS_A0100 Firewall Middle Plate MS_01002 [Back]

MS MS_A0100 Firewall Top Plate MS_01003 [Back]

MS MS_A0100 Firewall Joints MS_01004 [Back](#)

MS MS_A0100 Firewall Floor Plate MS_01005 [Back]

MS	Headrest / Restraints	MS_A0200						Back
MS	Headrest / Restraints	MS_A0200	Headrest Plate	Sthrengthen the Headrest	m	1	MS_02001	
MS	Headrest / Restraints	MS_A0200	Head Foam	Absorb chocs for Head impact	b	1	MS_02002	
MS	Headrest / Restraints	MS_A0200	Side Head Foam	Absorb chocs for Head impact on the sid	b	2	MS_02003	
MS	Headrest / Restraints	MS_A0200	Top Back Foam	Absorb chocs for back impact	b	1	MS_02004	

MS MS_A0200 Headrest Plate MS_02001 [Back](#)

MS MS_A0200 Head Foam MS_02002 Back

MS MS_A0200 Side Head Foam MS_02003 Back

MS MS_A0200 Top Back Foam MS_02004 Back

MS DriverÔÇÖs Harness	MS_A0300						Back
MS DriverÔÇÖs Harness		MS_A0300	Harness	Seatbelt of the Pilot b	1	MS_03001	

MS MS_A0300 Harness MS_03001 Back

MS	Seats	MS_A0400						Back
MS	Seats		MS_A0400	Seat	Allow the Pilot to seat	b	1	MS_04001
MS	Seats		MS_A0400	Back Foam	Soften the seat for the bac	b	1	MS_04002

MS MS_A0400 Seat MS_04001 Back

MS MS_A0400 Back Foam MS_04002 Back

ST	Steering Wheel	ST_A0100						Back
ST	Steering Wheel	ST_A0100	Steering wheel	Bought at Formula Seven.	b	1	ST_01001	
ST	Steering Wheel	ST_A0100	Spacer	Between steering wheel and Quick relea	m	1	ST_01002	
ST	Steering Wheel	ST_A0100	Quick Release mobil par	Removing part of the Quick release	b	1	ST_01003	

ST ST_A0100 Steering wheel ST_01001 Back

ST ST_A0100 Spacer ST_01002 Back

ST ST_A0100 Quick Release ST_01003 Back

ST	Steering Shaft	ST_A0200						Back
ST	Steering Shaft	ST_A0200	Quick Release Shaft	Fixed part of the Quick release	b	1	ST_02001	
ST	Steering Shaft	ST_A0200	Steering Shaft Pivot	Bearing seat for the steering pivot	m	1	ST_02002	
ST	Steering Shaft	ST_A0200	Steering U-joint	U-joint for steering column and ST_02002	b	1	ST_02003	
ST	Steering Shaft	ST_A0200	Steering column	Steering column	m	1	ST_02004	
ST	Steering Shaft	ST_A0200	Spline coupler	Connect the steering column to the rack	b	1	ST_02005	
ST	Steering Shaft	ST_A0200	Bearing, Ball, Radial	Steering pivot bearings	b	2	ST_02006	
ST	Steering Shaft	ST_A0200	U-joint boot	Over steering u-joint	b	1	ST_02007	

ST ST_A0200 Quick Release Shaf ST_02001 Back

ST ST_A0200 Steering Shaft Pivot ST_02002 [Back]

ST ST_A0200 Steering U-joint ST_02003 Back

ST ST_A0200 Steering column ST_02004 [Back]

ST ST_A0200 Spline coupler ST_02005 Back

ST ST_A0200 Bearing, Ball, Radial ST_02006 Back

ST ST_A0200 U-joint boot ST_02007 Back

ST	Steering Rack	ST_A0300						Back
ST	Steering Rack	ST_A0300	Steering Rack	Bought at Formula Seven.	b	1	ST_03001	
ST	Steering Rack	ST_A0300	Half moon	To support the steering rack	m	4	ST_03002	
ST	Steering Rack	ST_A0300	Steering Rack protection	To protect the steering rack.	m	1	ST_03003	

ST ST_A0300 Steering Rack ST_03001 Back

ST ST_A0300 Half moon ST_03002 [Back]

ST ST_A0300 Steering Rack protection ST_03003 Back

ST	Tie Rods	ST_A0400					
ST	Tie Rods	ST_A0400	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	ST_04001
ST	Tie Rods	ST_A0400	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	ST_04002
ST	Tie Rods	ST_A0400	Carbon tube	carbon tubes for tie rod	b	2	ST_04003
ST	Tie Rods	ST_A0400	Rod ends bearing, male r	2 with a left-hand thread	b	2	ST_04004
ST	Tie Rods	ST_A0400	Rod ends bearing, male l	2 with a right-hand thread	b	2	ST_04005
ST	Tie Rods	ST_A0400	Spacer 1	M6 type 16 mm spacer, frame side	m	4	ST_04006
ST	Tie Rods	ST_A0400	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	ST_04007

Back

ST ST_A0400 Tapped insert, right hand ST_04001 [Back]

ST ST_A0400 Tapped insert, left hanc ST_04002 [Back](#)

ST ST_A0400 Carbon tube ST_04003 Back

ST ST_A0400 Rod ends bearing, male ST_04004 Back

ST ST_A0400 Rod ends bearing, male ST_04005 Back

ST ST_A0400 Spacer 1 ST_04006 Back

ST ST_A0400 Spacer 2 ST_04007 Back

SU	A-Arms front uppe	SU_A0100						Back
SU	A-Arms front upper	SU_A0100	Upper fr. bearing suppor	Wheel side	m	2	SU_01001	
SU	A-Arms front upper	SU_A0100	Inner bearing support	Frame side	m	4	SU_01002	
SU	A-Arms front upper	SU_A0100	Front carbon fiber tube	Carbon tube at the front	b	2	SU_01003	
SU	A-Arms front upper	SU_A0100	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_01004	
SU	A-Arms front upper	SU_A0100	Spacer 1	M6 type 16 mm spacer, frame side	m	8	SU_01005	
SU	A-Arms front upper	SU_A0100	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_01006	
SU	A-Arms front upper	SU_A0100	Cylinder aluminium	Glued junction carbon/bearing support	m	4	SU_01007	
SU	A-Arms front upper	SU_A0100	Spherical bearing	M6, steel/steel contact	b	6	SU_01008	

SU SU_A0100 Upper fr. bearing support SU_01001 [Back]

SU SU_A0100 Inner bearing support SU_01002 [Back]

SU SU_A0100 Front carbon fiber tube SU_01003 Back

SU SU_A0100 Back Carbon f SU_01004 Back

SU SU_A0100 Spacer 1 SU_01005 Back

SU SU_A0100 Spacer 2 SU_01006 Back

SU SU_A0100 Cylinder aluminium SU_01007 Back

SU SU_A0100 Spherical bearing SU_01008 Back

SU	A-Arms front lowe	SU_A0200						Back
SU	A-Arms front lower	SU_A0200	Lower fr. bearing support	Wheel side	m	2	SU_02001	
SU	A-Arms front lower	SU_A0200	Inner bearing support	Frame side	m	4	SU_02002	
SU	A-Arms front lower	SU_A0200	Front carbon fiber tube	Carbon tube at the front	b	2	SU_02003	
SU	A-Arms front lower	SU_A0200	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_02004	
SU	A-Arms front lower	SU_A0200	Spacer 1	M6 type 16 mm spacer, frame sid	m	8	SU_02005	
SU	A-Arms front lower	SU_A0200	Spacer 2	M6 type 25 mm spacer, wheel sid	m	4	SU_02006	
SU	A-Arms front lower	SU_A0200	Spherical bearing	M6, steel/steel contact	b	6	SU_02007	

SU SU_A0200 Lower fr. bearing support SU_02001 Back

SU SU_A0200 Inner bearing support SU_02002 [Back](#)

SU SU_A0200 Front carbon fiber tube SU_02003 Back

SU	SU_A0200	Back Carbon fiber tube	SU_02004	Back

SU SU_A0200 Spacer 1 SU_02005 Back

SU SU_A0200 Spacer 2 SU_02006 Back

SU SU_A0200 Spherical bearing SU_02007 Back

SU	A-Arms rear uppe	SU_A0300						Back
SU	A-Arms rear upper	SU_A0300	Upper rr. bearing support	Wheel side (1 + symmetric)	m	2	SU_03001	
SU	A-Arms rear upper	SU_A0300	Inner bearing support	Frame side	m	4	SU_03002	
SU	A-Arms rear upper	SU_A0300	Front carbon fiber tube	Carbon tube at the front	b	2	SU_03003	
SU	A-Arms rear upper	SU_A0300	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_03004	
SU	A-Arms rear upper	SU_A0300	Spacer 1	M6 type 16 mm spacer, frame side	m	8	SU_03005	
SU	A-Arms rear upper	SU_A0300	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_03006	
SU	A-Arms rear upper	SU_A0300	Cylinder aluminium	Glued junction carbon/bearing support	m	4	SU_03007	
SU	A-Arms rear upper	SU_A0300	Spherical bearing	M6, steel/steel contact	b	6	SU_03008	

SU SU_A0300 Upper rr. bearing support SU_03001 [Back]

SU SU_A0300 Inner bearing support SU_03002 [Back]

SU SU_A0300 Front carbon fiber tube SU_03003 Back

SU	SU_A0300	Back Carbon fiber tube	SU_03004	Back

SU SU_A0300 Spacer 1 SU_03005 Back

SU SU_A0300 Spacer 2 SU_03006 Back

SU SU_A0300 Cylinder aluminium SU_03007 Back

SU SU_A0300 Spherical bearing SU_03008 Back

SU	A-Arms rear lowe SU_A0400							Back
SU	A-Arms rear lower	SU_A0400	Lower rr. bearing support	Wheel side	m	2	SU_04001	
SU	A-Arms rear lower	SU_A0400	Inner bearing support	Frame side	m	4	SU_04002	
SU	A-Arms rear lower	SU_A0400	Front carbon fiber tube	Carbon tube at the front	b	2	SU_04003	
SU	A-Arms rear lower	SU_A0400	Back Carbon fiber tube	Carbon tube at the rear	b	2	SU_04004	
SU	A-Arms rear lower	SU_A0400	Spacer 1	M6 type 16 mm spacer, frame sid	m	8	SU_04005	
SU	A-Arms rear lower	SU_A0400	Spacer 2	M6 type 25 mm spacer, wheel sid	m	4	SU_04006	
SU	A-Arms rear lower	SU_A0400	Spherical bearing	M6, steel/steel contact	b	6	SU_04007	

SU SU_A0400 Lower rr. bearing support SU_04001 [Back]

SU SU_A0400 Inner bearing support SU_04002 [Back]

SU SU_A0400 Front carbon fiber tube SU_04003 Back

SU	SU_A0400	Back Carbon fiber tube	SU_04004	Back

SU SU_A0400 Spacer 1 SU_04005 Back

SU SU_A0400 Spacer 2 SU_04006 Back

SU SU_A0400 Spherical bearing SU_04007

SU	Shocks Front	SU_A0500						Back
SU	Shocks Front	SU_A0500	Dampers	Ohlins TTX 25	b	2	SU_05001	
SU	Shocks Front	SU_A0500	Springs	Springs mounted on the damper	b	2	SU_05002	
SU	Shocks Front	SU_A0500	Damper Spacers	M8 type 20 mm spacer	m	8	SU_05003	

SU SU_A0500 Dampers SU_05001 Back

SU SU_A0500 Springs SU_05002 Back

SU SU_A0500 Damper Spacers SU_05003 Back

SU	Bell Cranks Front	SU_A0600						Back
SU	Bell Cranks Front	SU_A0600	Front rocker	Sheet of metal for the rocke	m	4	SU_06001	
SU	Bell Cranks Front	SU_A0600	Front rocker spacer 1	for the pivot	m	2	SU_06002	
SU	Bell Cranks Front	SU_A0600	Front rocker spacer 2	M6 type 20 mm spacer	m	8	SU_06003	

SU SU_A0600 Front rocker SU_06001 [Back]

SU SU_A0600 Front rocker spacer 1 SU_06002 [Back]

SU SU_A0600 Front rocker spacer 2 SU_06003 [Back]

SU	Shocks Rear SU_A0700							Back
SU	Shocks Rear	SU_A0700	Dampers	Ohlins TTX 25	b	2	SU_07001	
SU	Shocks Rear	SU_A0700	Springs	Springs mounted on the damper	b	2	SU_07002	
SU	Shocks Rear	SU_A0700	Damper spacers	M8 type 20 mm spacer	m	8	SU_07003	

SU SU_A0700 Dampers SU_07001 Back

SU SU_A0700 Springs SU_07002 Back

SU SU_A0700 Damper spacers SU_07003 [Back]

SU	Bell Cranks Rear	SU_A0800					
SU	Bell Cranks Rear	SU_A0800	Rear Rocker	Sheet of metal for the rocke	m	4	SU_08001
SU	Bell Cranks Rear	SU_A0800	Rear rocker spacer 1	for the pivot	m	2	SU_08002
SU	Bell Cranks Rear	SU_A0800	Rear rocker spacer 2	M6 type 20 mm spacer	m	8	SU_08003

Back

SU SU_A0800 Rear Rocker SU_08001 [Back]

SU SU_A0800 Rear rocker spacer 1 SU_08002 [Back]

SU SU_A0800 Rear rocker spacer 2 SU_08003 [Back](#)

SU	Tie Rod - Rear	SU_A0900						Back
SU	Tie Rod - Rear	SU_A0900	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	SU_09001	
SU	Tie Rod - Rear	SU_A0900	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	SU_09002	
SU	Tie Rod - Rear	SU_A0900	Carbon tube	carbon tubes for tie rod	b	2	SU_09003	
SU	Tie Rod - Rear	SU_A0900	Rod ends bearing, male r	2 with a left-hand thread	b	2	SU_09004	
SU	Tie Rod - Rear	SU_A0900	Rod ends bearing, male l	2 with a right-hand thread	b	2	SU_09005	
SU	Tie Rod - Rear	SU_A0900	Spacer 1	M6 type 16 mm spacer, frame side	m	4	SU_09006	
SU	Tie Rod - Rear	SU_A0900	Spacer 2	M6 type 25 mm spacer, wheel side	m	4	SU_09007	

SU SU_A0900 Tapped insert, right hand SU_09001 [Back]

SU SU_A0900 Tapped insert, left hand SU_09002 [Back](#)

SU SU_A0900 Carbon tube SU_09003 Back

SU SU_A0900 Rod ends bearing, male SU_09004 Back

SU SU_A0900 Rod ends bearing, male SU_09005 Back

SU SU_A0900 Spacer 1 SU_09006 Back

SU SU_A0900 Spacer 2 SU_09007 Back

SU	Front Uprights	SU_A1000						Back
SU	Front Uprights	SU_A1000	Front Left Upright	Right's drawing, left is symmetric.	m	2	SU_10001	
SU	Front Uprights	SU_A1000	Upper Arm Bracket		m	2	SU_10002	
SU	Front Uprights	SU_A1000	Upper Arm Wedge Shim	2mm, 3mm, 1mm for camber adjustment	m	6	SU_10003	
SU	Front Uprights	SU_A1000	Speed Sensor Washer	external sensor washer	m	2	SU_10004	
SU	Front Uprights	SU_A1000	Upper Arm Wedge Base		m	2	SU_10005	

SU SU_A1000 Front Left Upright SU_10001 [Back](#)

SU SU_A1000 Upper Arm Bracke SU_10002 [Back](#)

SU SU_A1000 Upper Arm Wedge Shim SU_10003 [Back]

SU SU_A1000 Speed Sensor Washe SU_10004 [Back]

SU SU_A1000 Upper Arm Wedge Bas SU_10005 [Back]

SU	Rear Uprights	SU_A1100						Back
SU	Rear Uprights	SU_A1100	Rear Left Upright	Right's drawing, left is symmetric.	m	2	SU_11001	
SU	Rear Uprights	SU_A1100	Upper Arm Bracket	same part as in Front Assembly	m	2	SU_11002	
SU	Rear Uprights	SU_A1100	Upper Arm Wedge Shir	2mm,3mm, 1mm for camber adjustment	m	6	SU_11003	
SU	Rear Uprights	SU_A1100	Speed Sensor Washer	external sensor washer, same as front	m	2	SU_11004	

SU SU_A1100 Rear Left Upright SU_11001 [Back](#)

SU SU_A1100 Upper Arm Bracket SU_11002 [Back](#)

SU SU_A1100 Upper Arm Wedge Shim SU_11003 [Back]

SU SU_A1100 Speed Sensor Washe SU_11004 [Back]

SU	Push/Pullrod Front	SU_A1200						Back
SU	Push/Pullrod Front	SU_A1200	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	SU_12001	
SU	Push/Pullrod Front	SU_A1200	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	SU_12002	
SU	Push/Pullrod Front	SU_A1200	Carbon tube	carbon tubes for tie rod	b	2	SU_12003	
SU	Push/Pullrod Front	SU_A1200	Rod ends bearing, male r	2 with a right-hand thread	b	2	SU_12004	
SU	Push/Pullrod Front	SU_A1200	Rod ends bearing, male l	2 with a left-hand thread	b	2	SU_12005	
SU	Push/Pullrod Front	SU_A1200	Spacer	M6 type 16 mm spacer, A-arm side	m	4	SU_12006	

SU SU_A1200 Tapped insert, right hand SU_12001 [Back]

SU SU_A1200 Tapped insert, left hanc SU_12002 [Back](#)

SU SU_A1200 Carbon tube SU_12003 Back

SU SU_A1200 Rod ends bearing, male SU_12004 Back

SU SU_A1200 Rod ends bearing, male SU_12005 Back

SU SU_A1200 Spacer SU_12006 [Back](#)

SU	Push/Pullrod Rear	SU_A1300						Back
SU	Push/Pullrod Rear	SU_A1300	Tapped insert, right hand	Right-hand thread, glued to carbon tube	m	2	SU_13001	
SU	Push/Pullrod Rear	SU_A1300	Tapped insert, left hand	Left-hand thread, glued to carbon tube	m	2	SU_13002	
SU	Push/Pullrod Rear	SU_A1300	Carbon tube	carbon tubes for tie rod	b	2	SU_13003	
SU	Push/Pullrod Rear	SU_A1300	Rod ends bearing, male r	2 with a right-hand thread	b	2	SU_13004	
SU	Push/Pullrod Rear	SU_A1300	Spacer	M6 type 16 mm spacer, A-arm side	m	4	SU_13006	

SU SU_A1300 Tapped insert, right hand SU_13001 [Back]

SU SU_A1300 Tapped insert, left hanc SU_13002 [Back](#)

SU SU_A1300 Carbon tube SU_13003 Back

SU SU_A1300 Rod ends bearing, male SU_13004 Back

SU SU_A1300 Spacer SU_13006 Back

SU	Anti Roll Bar Front SU_A1400							Back
SU	Anti Roll Bar Front	SU_A1400	Torsion bar	Tube used for the anti roll bar, 25CrMo	b	1	SU_14001	
SU	Anti Roll Bar Front	SU_A1400	Right bearing support	Outside diameter of the SU_14007	m	1	SU_14002	
SU	Anti Roll Bar Front	SU_A1400	Left bearing support	Outside diameter of the SU_14007	m	1	SU_14003	
SU	Anti Roll Bar Front	SU_A1400	End plate	Laser cutted, S355, 3mm thick	m	4	SU_14004	
SU	Anti Roll Bar Front	SU_A1400	Rod ends bearing, male r	2 male thread, ARB rod, right hand	b	2	SU_14005	
SU	Anti Roll Bar Front	SU_A1400	Rod ends bearing female	2 female thread, ARB rod, right hand	b	2	SU_14006	
SU	Anti Roll Bar Front	SU_A1400	Spherical plain bearings	Used in the bearing supports, M12	b	2	SU_14007	
SU	Anti Roll Bar Front	SU_A1400	Spacer	M6 type 16 mm spacer	m	4	SU_14008	

SU SU_A1400 Torsion bar SU_14001 Back

SU SU_A1400 Right bearing support SU_14002 [Back]

SU SU_A1400 Left bearing support SU_14003 [Back]

SU SU_A1400 End plate SU_14004 [Back]

SU SU_A1400 Rod ends bearing, male SU_14005 Back

SU SU_A1400 Rod ends bearing female SU_14006 Back

SU SU_A1400 Spherical plain bearings SU_14007 Back

SU SU_A1400 Spacer SU_14008 Back

SU	Anti Roll Bar Rear	SU_A1500					
SU	Anti Roll Bar Rear	SU_A1500	Torsion bar	Tube used for the anti roll bar, 25CrMo4	b	1	SU_15001
SU	Anti Roll Bar Rear	SU_A1500	Right bearing support	Outside diameter of the SU_15007	m	1	SU_15002
SU	Anti Roll Bar Rear	SU_A1500	Left bearing support	Outside diameter of the SU_15007	m	1	SU_15003
SU	Anti Roll Bar Rear	SU_A1500	End plate	Laser cutted, S355, 3mm thick	m	4	SU_15004
SU	Anti Roll Bar Rear	SU_A1500	Rod ends bearing, male	2 with a right-hand thread, ARB rod	b	2	SU_15005
SU	Anti Roll Bar Rear	SU_A1500	Rod ends bearing, male	2 with a left-hand thread, ARB rod	b	2	SU_15006
SU	Anti Roll Bar Rear	SU_A1500	Spherical plain bearings	Used in the bearing support, M12	b	2	SU_15007
SU	Anti Roll Bar Rear	SU_A1500	Spacer	M6 type 16 mm spacer	m	4	SU_15008
SU	Anti Roll Bar Rear	SU_A1500	Aluminium tapped tube	Aluminium tube for the ARB rod	m	2	SU_15009

Back

SU SU_A1500 Torsion bar SU_15001 Back

SU SU_A1500 Right bearing support SU_15002 [Back]

SU SU_A1500 Left bearing support SU_15003 [Back]

SU SU_A1500 End plate SU_15004 [Back]

SU SU_A1500 Rod ends bearing, male SU_15005 [Back]

SU SU_A1500 Rod ends bearing, male SU_15006 Back

SU SU_A1500 Spherical plain bearings SU_15007 Back

SU SU_A1500 Spacer SU_15008 Back

SU SU_A1500 Aluminium tapped tube SU_15009 [Back]

WT	Wheels	WT_A0100					Back
WT	Wheels		WT_A0100	Oz Magnesium Rir	b	4	WT_01001
WT	Wheels		WT_A0100	Hoosier 13", Dry	b	4	WT_01002

WT WT_A0100 Oz Magnesium Rin WT_01001 Back

WT WT_A0100 Hoosier 13", Dry WT_01002 Back

WT	Front Hubs	WT_A0200						Back
WT	Front Hubs	WT_A0200	Front Hub	Aluminium	m	2	WT_02001	
WT	Front Hubs	WT_A0200	Brake Bell	Aluminium, junction between disc and hub	m	2	WT_02002	
WT	Front Hubs	WT_A0200	Front Bearing Washer	outer side of the external bearing	m	2	WT_02003	
WT	Front Hubs	WT_A0200	Speed disc spacer 1	to position WT_02005 (1mm thick)	m	6	WT_02004	
WT	Front Hubs	WT_A0200	Speed sensor disc	iron teeth shape like	m	2	WT_02005	
WT	Front Hubs	WT_A0200	Speed disc spacer 2	to position WT_02005 (2mm thick)	m	4	WT_02006	
WT	Front Hubs	WT_A0200	Front Bearing	Wheel Bearing, Ball, Angular Contact	b	4	WT_02007	
WT	Front Hubs	WT_A0200	Front Hub Lock	SKF lock nut KM10	b	2	WT_02008	
WT	Front Hubs	WT_A0200	Front Hub Locknut Washer	SKF locknut washer MB10	b	2	WT_02009	
WT	Front Hubs	WT_A0200	Rim Dowel	hand trimmed	b	8	WT_02010	
WT	Front Hubs	WT_A0200	Rim Nut		b	8	WT_02011	

WT WT_A0200 Front Hub WT_02001 Back

WT WT_A0200 Brake Bell WT_02002 Back

WT WT_A0200 Front Bearing Washer WT_02003 [Back](#)

WT WT_A0200 Speed disc spacer 1WT_02004 [Back](#)

WT WT_A0200 Speed sensor disc WT_02005 [Back]

WT WT_A0200 Speed disc spacer 2 WT_02006 [Back](#)

WT WT_A0200 Front Bearing WT_02007 Back

WT WT_A0200 Front Hub Lock WT_02008 Back

WT WT_A0200 Front Hub Locknut Washer WT_02009 Back

WT WT_A0200 Rim Dowel WT_02010 Back

WT WT_A0200 Rim Nut WT_02011 Back

WT	Rear Hubs	WT_A0300						Back
WT	Rear Hubs	WT_A0300	Rear Hub	Aluminium, flutting for tripod housing	m	2	WT_03001	
WT	Rear Hubs	WT_A0300	Brake Bell	Sold attached with the rear breake roto	b	2	WT_03002	
WT	Rear Hubs	WT_A0300	Rear Bearing Washer	outer side of the external bearing	m	2	WT_03003	
WT	Rear Hubs	WT_A0300	Tripod Housing Spacer	rear upright vehicle inner side	m	2	WT_03004	
WT	Rear Hubs	WT_A0300	Speed disc spacer 1	to position WT_03006 (1mm thick)	m	6	WT_03005	
WT	Rear Hubs	WT_A0300	Speed sensor disc	iron teeth shape like	m	2	WT_03006	
WT	Rear Hubs	WT_A0300	Speed disc spacer 2	to position WT_03006 (2mm thick)	m	4	WT_03007	
WT	Rear Hubs	WT_A0300	Rear Bearing	Wheel Bearing, Ball, Angular Contact	b	4	WT_03008	
WT	Rear Hubs	WT_A0300	Rim Dowel	hand trimmed	b	8	WT_03009	
WT	Rear Hubs	WT_A0300	Rim Nut		b	8	WT_03010	

WT WT_A0300 Rear Hub WT_03001 [Back]

WT WT_A0300 Brake Bell WT_03002 Back

WT WT_A0300 Rear Bearing Washer WT_03003 [Back]

WT WT_A0300 Tripod Housing Spacer WT_03004 [Back](#)

WT WT_A0300 Speed disc spacer 1WT_03005 [Back](#)

WT WT_A0300 Speed sensor disc WT_03006 [Back]

WT WT_A0300 Speed disc spacer 2 WT_03007 [Back](#)

WT WT_A0300 Rear Bearing WT_03008 Back

WT WT_A0300 Rim Dowel WT_03009 Back

WT WT_A0300 Rim Nut WT_03010 Back