

```
press body switches to play notes:
    harder press / moist fingers give higher pitch
    press more body switches for arpeggiator mode:
    while arpeggiator is playing, pot2 changes arpeggiator speed

push button 1:
    start/stop sequencer

while holding button 1:
    bodyswitches:
        erase notes in sequencer

while holding button 2:
    bodyswitches:
        erase notes in sequencer
    pot 1:
        sequencer speed

while holding button 3:
    bodyswitches:
        change sequencer bank (0-7)
    pot 1:
    change octave
    pot 2:
        change preset

while holding button 1 AND button 3:
    bodyswitches:
        select active sequencer slice
```