

**CRANKCASE**

1. Thoroughly wash the case halves in mild solvent.
2. Clean all the gasket mating surfaces and crankcase mating surfaces thoroughly.

3. Inspect:

- Crankcase
Cracks/Damage → Replace.
- Oil delivery passages
Clog → Blow out with compressed air.