

**CLUTCH**

- | | |
|------------------|-------------------------|
| ① Clutch spring | ⑨ Clutch housing |
| ② Pressure plate | ⑩ Spacer |
| ③ Push plate | ⑪ Conical spring washer |
| ④ Cushion spring | ⑫ Push rod (#1) |
| ⑤ Clutch plate | ⑬ Ball |
| ⑥ Friction plate | ⑭ Push rod (#2) |
| ⑦ Clutch boss | ⑮ Push lever |
| ⑧ Spacer | ⑯ Primary drive gear |

