



Tightening Torque:

Parts to be tightened	Thread Size	Tightening Torque			Remarks
		Nm	m • kg	ft • lb	
Engine Mount:					
Engine (Front) and Frame	M10 x 1.25	45	4.5	33	
Engine (Rear) and Frame	M8 x 1.25	33	3.3	24	
Pivot Shaft and Frame	M14 x 1.5	85	8.5	61	
Swingarm and Under Guard	M8 x 1.25	23	2.3	17	
Rear Shock Absorber (Upper) and Frame	M10 x 1.25	25	2.5	18	
Front Arm (Lower and Upper) and Frame	M10 x 1.25	30	3.0	22	
Front Shock Absorber (Upper and Lower)	M10 x 1.25	45	4.5	33	
Steering Knuckle and Ball Joint	M10 x 1.25	48	4.8	35	
Steering Knuckle and Knuckle Arm	M10 x 1.25	38	3.8	27	
Knuckle Arm and Tie-Rod End	M10 x 1.25	25	2.5	18	
Tie-Rod (Locknut)	M10 x 1.25	30	3.0	22	
Tie-Rod End and Steering Column	M10 x 1.25	25	2.5	18	
Steering Column and Frame	M10 x 1.25	30	3.0	22	
Steering Column Holder and Frame	M8 x 1.25	23	2.3	17	Use lock washer.
Steering Column and Handlebar Holder	M8 x 1.25	20	2.0	14	
Fuel Cock	M6 x 1.0	5	0.5	3.6	
Front Wheel Nut	M10 x 1.25	45	4.5	33	
Front Hub Nut	M14 x 1.5	70	7.0	51	
Front Brake Camshaft Lever	M6 x 1.0	9	0.9	6.5	
Rear Axle Ring Nut	M33 x 1.5				SEE NOTE.
Rear Wheel Nut	M10 x 1.25	45	4.5	33	
Rear Wheel Hub Nut	M14 x 1.5	120	12	87	
Rear Axle Hub and Swingarm	M10 x 1.25	50	5.0	36	
Brake Caliper and Bracket	M8 x 1.25	23	2.3	17	
Rear Axle Hub and Brake Caliper Bracket	M8 x 1.25	28	2.8	20	
Brake Disc and Bracket	M8 x 1.25	28	2.8	20	
Chain Puller and Locknut	M8 x 1.25	16	1.6	12	
Driven Sprocket	M8 x 1.25	24	2.4	17	
Footrest	M10 x 1.25	55	5.5	40	
Front Bumper	M8 x 1.25	26	2.6	19	
Rear Bumper	M8 x 1.25	35	3.5	25	

NOTE:

Apply locking agent (LOCTITE®) to nuts threads.

1. Tighten the nut (inside) to 55 Nm (5.5 m • kg, 40 ft • lb) while holding the rear axle.
2. Hold the nut (inside) and tighten the nut (outside) to 190 Nm (19.0 m • kg, 140 ft • lb).
3. Hold the nut (outside) and tighten back the nut (inside) to 240 Nm (24.0 m • kg, 170 ft • lb).