

PERIODIC INSPECTION AND ADJUSTMENT

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE/LUBRICATION

Item	Remarks	Initial			Every	
		1 month	3 month	6 month	6 month	1 year
Transmission	Replace oil.	○		○	○	○
Spark plug	Check condition. Clean or replace if necessary.	○	○	○	○	○
Air filter	Clean and oil. Replace if necessary.		○	○	○	○
Carburetor	Check idle speed/starter operation. Adjust if necessary.		○	○	○	○
Fuel line	Check fuel hose for cracks or damage. Replace if necessary.			○	○	○
Throttle operation	Inspect.	○	○	○	○	○
Front brake operation	Inspect and adjust free play if necessary.	○	○	○	○	○
Front brake shoes	Check wear limit. Replace if necessary.			○	○	○
Rear brake pad	Check pad wear. Replace if necessary.			○	○	○
Clutch	Inspect free play and operation. Replace if necessary.	○		○	○	○
Drive chain	Lubricate, free play, alignment. Replace if necessary.	○		○	○	○
Drive chain guard and rollers	Check wear and replace if necessary.			○	○	○
Steering system	Inspect free play, clean and lube.	○	○	○	○	○
Front and Rear suspension	Inspect and lubricate.	○	○	○	○	○
Tire, wheels	Inspect air pressure, wheel run-out, and tire wear. Inspect bearings. Replace bearings if necessary.	○	○	○	○	○
Throttle, control cable	Check routing and connection. Lubricate.	○	○	○	○	○
Outside nut and bolts	Retighten.	○	○	○	○	○
Frame	Clean and inspect.		○	○	○	○
Lighting equipment	Inspect.	○	○	○	○	○

3