



4. Inspect:

- Pilot air screw ①
- Starter plunger ②
Wear/Contamination → Replace.
- O-rings
Damage → Replace.

5. Inspect:

- Throttle valve ①
Wear/Damage → Replace.

6. Check:

- Free movement
Stick → Replace.
Insert the throttle valve into the carburetor body, and check for free movement.

7. Inspect:

- Jet needle ①
Bends/Wear → Replace.
- Throttle valve cable ②
Wear/Damage → Replace.
- Gasket
Damage → Replace.

8. Inspect:

- Float ①
Damage → Replace.

5

ASSEMBLY

Reverse the "DISASSEMBLY" procedure.
Note the following points.

⚠ CAUTION:

Before reassembling, wash all parts with a clean gasoline.