


⚠ CAUTION:

When tightening the locknut, hold the adjuster with a spanner so that the adjuster is not turned together with the locknut.

- Set the adjuster cover ④ onto the rear brake caliper body ⑤.
- Tighten the locknut ② on the left lever holder.
- Set the adjuster cover to the left lever holder.

⚠ WARNING:

After this adjustment is performed, block the rear of the machine off the ground, and spin the rear wheels to ensure there is no brake drag. If any brake drag is noticed, perform the above steps again.