

REAR WHEEL AND REAR AXLE

- | | |
|-----------------------|-------------------------|
| ① Rear axle | ⑩ Lock washer |
| ② Oil seal | ⑪ Drive chain |
| ③ Bearing | ⑫ Rear axle nut (Inner) |
| ④ Spacer | ⑬ Rear axle nut (Outer) |
| ⑤ Rear axle hub | ⑭ Rear wheel hub |
| ⑥ Inner collar | ⑮ Cotter pin |
| ⑦ Driven sprocket hub | |
| ⑧ Driven sprocket | |
| ⑨ Chain tensioner | |

*Rear Axle Nut Tightening Steps:

Apply locking agent (LOCTITE®) to rear axle nuts threads.

1st: Tighten the inner rear axle nut.

55 Nm (5.5 m•kg, 40 ft•lb)

2nd: Tighten the outer rear axle nut while holding the inner rear axle nut.

190 Nm (19.0 m•kg, 140 ft•lb)

3rd: Loosen the inner rear axle nut while holding the outer rear axle nut.

240 Nm (24.0 m•kg, 170 ft•lb)

