Eagle A3 Pro

Configuration for use with OS FltStab firmware.

AILR_IN

AUX_IN
RUD_IN
ELE_IN
AIL_IN

RUD_OUT/OWI
ELE_OUT
AIL_OUT

AILR_OUT

AIL_SW
ELE_SW
RUD_SW

Remove LED2

Replace R5 with wire jumper

Solder power wire to +ve header pin

Solder signal wire to jumper and LED2 pad

Solder ground wire to LED2 ground pad