# HowTo Set Channel Plan by Driver

2019/4/1 version V1

1.Introduction	2
2. Set channel plan	
2.1. Modify module parameter	
2.2. Proc command	
3. Check channel plan	

### 1. Introduction

This document introduces how to set channel plan by Realtek wifi driver rather than modifies efuse 0xB8[6:0](domain code).

## 2. Set channel plan

Please chose a suitable Channel Plan Domain Code from document "WS-xxxxxx-Willis-Efuse\_Channel\_Plan-Rxx.xlsx" before setting your channel plan .The channel plane can be set by modifying module parameter or proc command

7###1	FI Channel Plan Contents						
	Domain Code EEPROM		EEPROM		Specific Regulatory Domain		
	2G RD	5G RD	0xB8 Bit[6:0]	2G Channels	5G Channels	2G Note	
Case	e Old Define		00h~1Fh	Old Define	Old Define		
1	2G_WORLD	5G_NULL	20h	1,2,3,4,5,6,7,8,9,10,11,12,13	NA	2G Worldwide 13 Active scan Ch01~11 Passive scan Ch12, 13	
2	2G_ETSI1	5G_NULL	21h	1,2,3,4,5,6,7,8,9,10,11,12,13	NA	ETSI Ch01~13	
3	2G_FCC1	5G_NULL	22h	1,2,3,4,5,6,7,8,9,10,11	NA	FCC Ch01~11	
4	2G_MKK1	5G_NULL	23h	1,2,3,4,5,6,7,8,9,10,11,12,13,14	NA	MKK Ch01~14	
5	2G_ETSI2	5G_NULL	24h	10,11,12,13	NA	ETSI Ch10~13	
6	2G_FCC1	5G_FCC1	25h	1,2,3,4,5,6,7,8,9,10,11	36,40,44,48, 52,56,60,64, 100,104,108,112,116,120,124,128,132,136,140, 149,153,157,161,165	FCC Ch01~11	
7	2G_WORLD	5G_ETSI1	26h	1,2,3,4,5,6,7,8,9,10,11,12,13	36,40,44,48, 52,56,60,64, 100,104,108,112,116,120,124,128,132,136,140	2G Worldwide 13 Active scan Ch01~11 Passive scan Ch12, 13	

# 2.1. Modify module parameter

Please select one method listed below.

1. Set rtw\_channel\_plan parameter when insmod

Ex: insmod 8812bu.ko rtw channel plan=0x7F

2. Set rtw\_channel\_plan parameter in driver /os\_dep/linux/os\_intfs.c

Ex. int rtw\_channel\_plan = 0x7F

3. Set rtw\_channel\_plan parameter in Makefile

Ex. CONFIG RTW CHPLAN = 0x7F

#### 2.2. Proc command

Channel plan should be set before starting wpa\_supplicant. Set channel plan for each adapter:

Ex: echo 0x7F > /proc/net/rtl8812bu/wlan1/chan\_plan

The initial country code and channel plan setting will be replaced.

## 3. Check channel plan

Check channel plan for each adapter:

Ex: cat /proc/net/rtl8812bu/wlan1/chan\_plan

Note: rtl8812bu and wlan1 depend on your chip and interface.