38 VF139 - Airbag Warning Management (VF139_V1_PJ3U)

Document Code: VF139_V1_PJ3U | Components: IPC, ORC (Airbag ECU), BCM

38.12 Indication Management

IND_ROW | AIR BAG FAIL.V1 | When FailPresent == 1 or AirBagLampReq == ON | Yes - Airbag failure, see hand
IND_ROW | AIR BAG TEMPORARY CALIBRATION.V1 | When ORC is in Plant Mode / Temporary Calibration active | Y
IND_ROW | AIR BAG RECOVERY.V1 | When CAN node ORC_FD_1 is in timeout > tREC | Yes - Check Airbag System |
IND_ROW | PASSENGER AIR BAG OFF.V1 | When PassengerAirBagStatus == DISABLED | Yes - Passenger Airbag Deac

38.14.1 Configuration Parameters Table

ID | Parameter Name | First Trial Value | Range Value | Resolution | Unit | Component | Implementation | XCP | Impact | Description
PAR_ROW | PAR_139_01 | tREC | 2,5 | 0,1÷5 | 0,1 | s | IPC | SUPPLIER EOL_2 | NO | Diagnosis | Time-out of the signa
PAR_ROW | PAR_139_02 | T_AIRBAG_STARTUP_CHK | 4,0 | 2,0÷6,0 | 0,5 | s | IPC | SUPPLIER EOL_2 | NO | HMI | Duration
PAR_ROW | PAR_139_03 | CFG_PAB_PRESENT | 1 | 0÷1 | 1 | - | IPC | PROXI | NO | Vehicle Configuration | Enables Passe
PAR_ROW | PAR_139_04 | T_ORC_CRASH_LATCH | 50 | 10÷200 | 10 | ms | ORC | SUPPLIER EOL | YES | Safety | Crash deploy

62 VF143 - Hand Brake Management (VF143_V1_PJ3U)

Document Code: VF143_V1_PJ3U | Components: IPC, BCM, BSM (ESC)

62.12 Indication Management

IND_ROW | HAND BRAKE.V1 | When HandBrakeSwitchSts == ENGAGED and VehicleSpeed <= V_TH_HB | No | Park Brak
IND_ROW | HAND BRAKE VEHICLE IN MOVEMENT.V1 | When HandBrakeSwitchSts == ENGAGED and VehicleSpeed > V_TH_
IND_ROW | EPB AUTO HOLD ACTIVE.V1 | When EPB_AutoHoldSts == ACTIVE | Yes - Auto Hold Active | Auto Hold G

62.14.1 Configuration Parameters Table

ID | Parameter Name | First Trial Value | Range Value | Resolution | Unit | Component | Implementation | XCP | Impact | Description

PAR_ROW | PAR_143_01 | V_TH_HB | 5 | 3÷15 | 1 | km/h | IPC | SUPPLIER EOL_2 | NO | HMI Warning | Vehicle speed thre
PAR_ROW | PAR_143_02 | T_HB_WARN | 1,5 | 0,5÷5,0 | 0,5 | s | IPC | SUPPLIER EOL_2 | NO | HMI Warning | Debounce tim
PAR_ROW | PAR_143_03 | T_HB_CHIME_REPEAT | 30 | 10÷120 | 5 | s | IPC | SUPPLIER EOL_2 | NO | Acoustic Chime | Repet
PAR_ROW | PAR_143_04 | T_BCM_HB_DEBOUNCE | 100 | 20÷500 | 10 | ms | BCM | SUPPLIER EOL | NO | Input Acquisition | H

64 VF145 - Low Brake Fluid Level Management (VF145_V1_PJ3U)

Document Code: VF145_V1_PJ3U | Components: IPC, BCM

64.12 Indication Management

IND_ROW | LOW BRAKE FLUID.V1 | When BrakeFluidLevelSts == LOW | Yes - Brake fluid level low, stop vehicle

IND_ROW | BRAKE SYSTEM FAIL.V1 | When EBD_FailSts == PRESENT | Yes - Brake system failure | Brake System

64.14.1 Configuration Parameters Table

ID | Parameter Name | First Trial Value | Range Value | Resolution | Unit | Component | Implementation | XCP | Impact | Description

PAR_ROW | PAR_145_01 | T_LBF_FILTER | 2,0 | 0,5÷5,0 | 0,1 | s | IPC | SUPPLIER EOL_2 | NO | HMI Filter | Filtering

71 VF150 - Wiper and Washer Management (VF150_V2_PJ3U)

Document Code: VF150_V2_PJ3U | Components: IPC, BCM, RLS

71.12 Indication Management

IND_ROW | WINDSHIELD WASHER FLUID LOW.V1 | When WasherFluidLevelSts == LOW | Yes - Top up windshield wash

IND_ROW | RAIN SENSOR FAIL.V1 | When RainSensorFailSts == FAIL | Yes - Automatic wipers unavailable | Ded

71.14.1 Configuration Parameters Table

ID | Parameter Name | First Trial Value | Range Value | Resolution | Unit | Component | Implementation | XCP | Impact | Description

PAR_ROW | - | - | - | - | - | - | - | - | - | - | -

29 VF118 - Seat Belt Reminder (SBR) Management (VF118_V3_PJ3U)

Document Code: VF118_V3_PJ3U | Components: IPC, ORC, BCM

29.12 Indication Management

IND_ROW | SEAT BELT REMINDER FRONT.V1 | When FrontBeltSts == UNBUCKLED | No (Dedicated SBR Graphic) | Sea
IND_ROW | SEAT BELT REMINDER REAR.V1 | When RearBeltBuckleChange == UNBUCKLED_IN_MOTION | Yes - Rear Seat

29.14.1 Configuration Parameters Table

ID | Parameter Name | First Trial Value | Range Value | Resolution | Unit | Component | Implementation | XCP | Impact | Description
PAR_ROW | PAR_118_01 | V_SBR_SPEED_TH | 20 | 10÷30 | 1 | km/h | IPC | SUPPLIER EOL_2 | NO | ECE-R16 Compliance | Ve
PAR_ROW | PAR_118_02 | T_SBR_CHIME_DURATION | 90 | 30÷180 | 5 | s | IPC | SUPPLIER EOL_2 | NO | ECE-R16 Compliance
PAR_ROW | PAR_118_03 | D_SBR_DIST_TH | 500 | 100÷1000 | 50 | m | IPC | SUPPLIER EOL_2 | NO | ECE-R16 Compliance | D
PAR_ROW | PAR_118_04 | CFG_REAR_SBR_ENABLE | 1 | 0÷1 | 1 | - | IPC | PROXI | NO | Market Variant | PROXI configurat

88 VF210 - Tire Pressure Monitoring System (TPMS) (VF210_V1_PJ3U)

Document Code: VF210_V1_PJ3U | Components: IPC, BSM, RFHM

88.12 Indication Management

IND_ROW | TPMS LOW PRESSURE.V1 | When TirePressureWarn == LOW_PRESSURE | Yes - Check tire pressure | TPMS
IND_ROW | TPMS SYSTEM FAIL.V1 | When TPMS_SystemSts == FAULT | Yes - TPMS unavailable, service required |

88.14.1 Configuration Parameters Table

ID | Parameter Name | First Trial Value | Range Value | Resolution | Unit | Component | Implementation | XCP | Impact | Description
PAR_ROW | PAR_210_01 | T_TPMS_BLINK_TIME | 75 | 60÷90 | 5 | s | IPC | SUPPLIER EOL_2 | NO | FMVSS138 / Regulation |
PAR_ROW | PAR_210_02 | P_TPMS_WARN_HYST | 0,2 | 0,1÷0,5 | 0,05 | bar | IPC | SUPPLIER EOL_2 | NO | HMI Display | Pr