

## CS业务主叫

立天通信技术有限公司		
UE	Node-B SRNC	CN
	CH/PRACH): RRC Connection Req	
J	分配RNTI并选	
	择L2/L1参数 2、NBAP: RL Setup Req	
	ZV NDAT: KE Setup Keq	
	开始RX	
	3、NBAP: RL Setup Resp	
	4. ALCAP: Establish Req	
	5, ALCAP: Establish Resp	
	6. DCH-FP: DL Synchronization	
	7. DCH-FP: UL Synchronization	
4	开始TX	
8. RRC(CCCH/FAC	I/SCCPCH): RRC Connection Setup	
4	9. NBAP: RL Restore Ind	
10 RRC(DCCH/DC	/PDCH): RRC Connection Setup Complete	
	/PDCH): Initial Direct Transfer(CM Service Reg)	No.
II, KRC(DCCII/DC		66000
	12 RANAP: Initial UE Me	<del></del>
14. RRC(DCCH/DC	13. RANAP: Direct Tra   PDCH ): DL Direct Transfer(User Authentication Req)	nsier
4		
15\ KKC(DCCH/DC	I/PDCH): DL Direct Transfer(User Authentication Resp)	nefer
		-
18、RRC(DCCH/DC	17, RANAP: Security Mode Comm	nana
· · · · · · · · · · · · · · · · · · ·	/PDCH): Security Mode Complete	
,(2 2 2 3 3 2	20, RANAP: Security Mode Com	plete
21、RRC(DCCH/DCI	PDCH): UL Direct Transfer(Setup)	
	22、RANAP: Direct Tra	nsfer
	23, RANAP: Direct Tra	nsfer
24、RRC(DCCH/DCI	PDCH): DL Direct Transfer(Call Proceeding)	
	25, RANAP: RAB Assignment	Req
	选择L2/L1和Iu	25
	数据承载参数	u colu
	26, ALCAP: Establishmen	A STATE OF THE REAL PROPERTY.
	27, ALCAP: Establishment	_
	28. NBAP: RL Reconfiguration Req	
7	29、NBAP: RL Reconfiguration Resp	
	30、ALCAP: Establish Req	
	31、ALCAP: Establish Resp	
	32 DCH-FP: DL Synchronization	
	33 DCH-FP: UL Synchronization	
34、RRC(DCCH/DC	/PDCH): RB Setup Req	
•	/PDCH): RB Setup Complete	
	36, RANAP: RAB Assignment	Resp
	37, RANAP: Direct Transfe	~
38 RRC(DCCH/DC	/PDCH): DL Direct Message(Alerting)	
DOV RINCIDECTI/DE	39, RANAP: Direct Transfe	er
40、RRC(DCCH/DC	/PDCH): DL Direct Message(Connect)	
41、RRC(DCCH/DC	I/PDCH): DL Direct Message(Connect ACK)	
	42 RANAP: Direct Transfe	r
	通话开始 WWW.SDT	M.COIV
	AT NH / I / II	



## CS业务被叫

立天通信技术有限公司	JOHN WILL
UE .	Node-B SRNC C
2 DDC/DCCH	//PCH/S-CCPCH): Paging Type 1
•	
3, RRC(CCCH/RA	ACH/PRACH): RRC Connection Req
	分配RNTI并选
	择L2/L1参数 4、NBAP: RL Setup Req
	开始RX 5、NBAP: RL Setup Resp
	6. ALCAP: Establish Req
	7, ALCAP: Establish Resp
	8 DCH-FP: DL Synchronization
	9 DCH-FP: UL Synchronization
	开始TX
10、RRC(CCCH/FA	ACH/SCCPCH): RRC Connection Setup
	11. NBAP: RL Restore Ind
12、RRC(DCCH/DC	CH/PDCH): RRC Connection Setup Complete WINTERSTITE OF
13、RRC(DCCH/D	OCH/PDCH): Initial Direct Transfer(Paging Resp)
	14 RANAP: Initial UE Messag
/	15, RANAP: Direct Transfer
<del> </del>	CH/PDCH): DL Direct Transfer(User Authentication Req)
17、RRC(DCCH/DC	CH/PDCH): DL Direct Transfer(User Authentication Resp) 18、RANAP: Direct Transfer
	19, RANAP: Security Mode Command
20、RRC(DCCH/DC	CH/PDCH): Security Mode Command
21、RRC(DCCH/DC	CH/PDCH): Security Mode Complete
	22. RANAP: Security Mode Complete
24、RRC(DCCH/DC	23、RANAP: Direct Transfer
25、RRC(DCCH/D	CH/PDCH): DL Direct Transfer(Call Confirm)
	26, RANAP: Direct Transfer
	27、RANAP: RAB Assignment Req
	选择L2/L1和Iu
_	数据承载参数 WILLIAM SDTM CO
	28, ALCAP: Establishment Reg
	29, ALCAP: Establishment Resp 30, NBAP: RL Reconfiguration Req
/	31. NBAP: RL Reconfiguration Resp
	32、ALCAP: Establish Req
	33、ALCAP: Establish Resp
	34 DCH-FP: DL Synchronization
AC DREMESTS	35 DCH-FP: UL Synchronization
<del> </del>	CH/PDCH): RB Setup Req
3/\ RRC(DCCH/DC	CH/PDCH): RB Setup Complete
39. RRC(DCCH/DC	38、RANAP: RAB Assignment Resp CH/PDCH); DL Direct Message(Alerting)
NACIDECII/DC	40. RANAP: Direct Transfer
41、RRC(DCCH/DC	CH/PDCH): DL Direct Message(Connect)
	42, RANAP: Direct Transfer
44、RRC(DCCH/DC	43. RANAP: Direct Transfer CH/PDCH): DL Direct Message(Connect ACK)
1,= 5,= 3,=	
	通话开始 WWW.SDTM.CO