Dishwasher quick guide

Clean the filter once a month: twist it anticlockwise, lift it out and rinse it under warm water.

Programmes

Programme	Time
Eco 50	3 h 20 min
Quick 45	45 min

Error codes

E24 means the water is not draining. Check the filter and the drain hose.

Warranty: two years from the date of purchase (keep the receipt).