



Stacker Mini-Arcade Build Instructions








Notice: This project is not sponsored nor affiliated with IKEA $^{\text{\tiny{M}}}$. The IKEA $^{\text{\tiny{M}}}$ icons are used in project to give this manual the IKEA $^{\text{\tiny{M}}}$ charm and because they look pretty.




















8-2

In the wiring diagram in 8-1, the following LED matrix pins (labeled on the board) should be wired to the matching Arduino pin as per the table below:

Arduino Pin	LED Matrix Pin
VCC	VCC
GND	GND
D4	CS
D11	DATA
D13	CLK

The following 2 Arduino pins should be connected to the button (pin on button are reversible): **D2 & GND**

