











Item #	mn Name Error:Manufa	#Column Name Error:Manufacturer No	Quantity	#Column Name Error:Note	Designator	
1			8		C1, C2, C6, C7, C15, C16,	Capa
					C17, C18	
2			8		C8, C9, C10, C11, C12,	Capa
					C13, C19, C20	
3			1		D2	Photo
4			2		LS1, LS2	Louds
5			1		P1	Heade
6			1		R1	Tappe
7			10		R2, R3, R4, R5, R6, R7, R8,	Resis
					R9, R10, R11	
8			1		S1	Single
9			1		U2	Low V
10			1		U3	Remo
11			1		U4	Micro

	Cap2	Cap2
RAD-0.2	Cap2	Cap2
PIN2	Fil-3C	Photo Sen
PIN2	Speaker	Speaker
HDR1X2	Header 2	Header 2
VR3	Res Tap	Res Tap
XIAL-0.3	Res1	Res1
SPST-2	SW-SPST	SW-SPST
N08E	LM386N-4/NOPB	LM386N-4/NOPB
SO20_N	M3005LD	M3005LD
N16E	CD4046BCN	CD4046BCN
	PIN2 PIN2 HDR1X2 VR3 XIAL-0.3 SPST-2 N08E SO20_N	PIN2 Fil-3C PIN2 Speaker  IDR1V2 Header 2 VR3 Res Tap  XJAL-0.3 Res1  SPST-2 SW-SPST  N08E LM386N-4/NOPB SC02_N M300SLD