

Pairing Your Cow Remote and Robot

Simple instructions for legacy V1 systems and paired V2 systems

Before you start: stop the robot in a safe area. Keep the remote and robot within 3 ft / 1 m of each other.

Which system do I have?

V1 — Legacy system

The original system. It does not use customer pairing. Turn both units on and use them normally.

V2 — Paired system

The current system. It remembers one remote and one robot after they are paired.

Pair a V2 remote and robot

You only need to do this for a new remote, a replacement remote, or after unpairing.

- 1 Turn both units on.** Keep other nearby robots and remotes turned off while pairing.
- 2 Open pairing on the robot.** Hold the robot's BOOT button for about 4 seconds, then release it. The orange Signal light flashes.
- 3 Open pairing on the remote.** Hold the Front and Back drive-direction buttons together for about 4 seconds, then release them. The remote's orange pairing light flashes.
- 4 Wait for confirmation and test safely.** Pairing normally completes within a few seconds. The robot's green Power light confirms the saved connection; then verify that the controls respond in a safe area.

Unpair or change to a different remote

1. Clear the robot

Hold the robot's BOOT button for 10 seconds. This removes its saved remote.

2. Clear the remote

Hold the Front and Back drive-direction buttons together for 10 seconds. This removes its saved robot.

3. Pair again

Repeat the V2 pairing steps above. If replacing a lost remote, clear the robot and the new remote, then pair them together.

Important: Do not use the robot RST button to pair or unpair—it only restarts the robot. If pairing does not complete within one minute, repeat the steps with both units close together.