# Koruza compute module board

# **CONTENTS:**

PAGE1 - CONTENTS

PAGE2 - POWER, MODULE, KORUZA CONNECTORS

PAGE3 - HUB, USB, ETHERNET

# **REVISION HISTORY:**

### TODO:

- \* RPi zero reader
- \* 5V power supplay 9 V to 5V

### NEED TO CHECK:

- \* Ethernet PoE pins
- \* Ethernet pins 5 and 10, do they go to GND?
- \* Ethernet does shield go to GND?



