

## Task #75: Verify serial monitor is working with AVR128DA48

## Nano Every Test



The Nano Every serial monitor is functioning properly in the IDE. The TX light on the board is also flashing to indicate transmission.

## AVR128DA48 Test



The Serial monitor does not transmit the desired text to the IDE. Changing the baud rate and searching through the config files have not fixed the issue. The TX indicator light is also non-responsive on the actual board. This problem needs to be discussed with our project's sponsor, Bob Martin. Our sponsor has conveyed that he will take care technical issues involving low level functionality.