Vacuum Cleaner



Category: **Hospitality & Housekeeping** Type: **Full SOP** Priority: **High** 21 labs

Covers these lab items: Vacuum cleaner; Vacuum cleaners

What it is used for

A vacuum cleaner removes dust and loose dirt from suitable floors, furniture, and other surfaces. Correct attachments, filters, and operating methods help maintain cleaning performance and reduce electrical hazards.

Main parts

- Motor creates suction to draw in dust and debris.
- Hose or inlet carries dirt toward the collection unit.
- Floor head or nozzle contacts the surface being cleaned.
- Dust bag or collection bin stores collected dirt.
- Filter traps dust before air leaves the machine.
- Handle and wheels help move the cleaner around the area.
- Power switch and cord or battery control the power supply.

Before you start

1. Read the operating instructions and confirm the cleaner suits the surface and cleaning task.
2. Inspect the housing, hose, nozzle, filter, dust bag or bin, and power supply.
3. Empty the collection bin or replace the dust bag if it is full.
4. Check that the filter is correctly fitted and suitable for the material being collected.
5. Remove large objects, sharp debris, and tangled cords from the cleaning path.
6. Keep hands dry and disconnect the power before fitting attachments or opening the unit.

How to use

1. Choose the correct floor head or attachment for the surface being cleaned.
2. Fit the hose, nozzle, filter, and dust bag or bin securely.
3. Connect the plug with dry hands or check that the battery is properly fitted.
4. Switch on the cleaner and move the nozzle slowly across the surface.
5. Overlap cleaning passes slightly to collect dust from the whole area.
6. Use the appropriate attachment for corners, upholstery, or other suitable surfaces.
7. Switch off immediately if suction drops, the motor overheats, or unusual noise occurs.
8. Switch off and unplug the machine before removing blockages or emptying the bin.
9. Empty the bin or replace the bag carefully without scattering dust.
10. Clean and store the machine after use, following the manufacturer's instructions.

⚠ Safety

- Never vacuum liquids unless the cleaner is specifically designed for wet cleaning.
- Do not vacuum hot ash, burning material, flammable liquids, or hazardous substances with an ordinary cleaner.
- Keep the cord away from the nozzle, wheels, sharp edges, and hot surfaces.
- Never operate a cleaner with a damaged cord, plug, housing, or wet electrical parts.
- Disconnect power before clearing blockages, changing filters, or performing maintenance.
- Keep fingers and loose clothing away from moving brush rollers.

Care & storage

- Empty the dust bin or replace the bag before it becomes overfilled.
- Clean or replace filters according to the manufacturer's instructions and dry washable filters fully.
- Check the hose, brush, wheels, and cord regularly for blockages or damage.
- Store the cleaner and accessories in a dry place with the cord loosely arranged.

Common mistakes to avoid

- Using an ordinary dry vacuum cleaner to collect water or wet waste.
- Operating the machine with a full bin or blocked filter.
- Pulling the cleaner by its power cord instead of its handle.
- Cleaning or opening the unit before switching off and disconnecting power.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar