Hair Steamer



Category: **Beauty, Wellness & Fitness** Type: **Full SOP** Priority: **High** 10 labs

Covers these lab items: Climazone; Hair Steamer; Head steamer; Scalp steamer

What it is used for

A hair steamer produces warm vapour to support selected hair and scalp care treatments. Correct temperature, distance, hygiene, and supervision help prevent burns and discomfort.

Main parts

- Water reservoir holds the water used to produce vapour.
- Heating unit warms water to generate steam.
- Hood or nozzle directs vapour toward the hair and scalp.
- Control panel adjusts operating settings on supported models.
- Stand or height adjustment positions the unit for the user.
- Timer controls treatment duration on supported models.
- Power cord and switch supply and control electrical power.

Before you start

1. Read the manufacturer's instructions and confirm the steamer is suitable for the intended treatment.
2. Inspect the cord, plug, housing, reservoir, hood, and controls for damage.
3. Place the unit on a stable surface with clear space around it.
4. Fill the reservoir only with the type and amount of water specified by the manufacturer.
5. Clean reusable contact surfaces and prepare the person's hair and scalp as required.
6. Check the person's comfort and ask about scalp injuries, sensitivity, or discomfort before starting.

How to use

1. Switch off and unplug the unit before filling or adjusting the reservoir.
2. Fill the reservoir to the marked level and secure its cap if provided.
3. Position the user comfortably and adjust the hood or nozzle according to instructions.
4. Keep the recommended distance between the steam outlet and the scalp.
5. Switch on the steamer and select the approved temperature and treatment time.
6. Check comfort frequently and stop if the person reports excessive heat or irritation.
7. Keep the user supervised throughout the treatment and avoid directing steam toward the face.
8. Switch off the unit when the treatment ends and allow steam output to stop.
9. Wait for the unit to cool before opening the reservoir or draining remaining water.
10. Empty, clean, dry, and store the unit according to the manufacturer's instructions.

⚠ Safety

- Never touch the steam outlet or direct hot steam onto the skin or eyes.
- Do not open a hot or pressurised reservoir; allow the unit to cool first.
- Keep water away from the plug, switch, cord connections, and other electrical parts.
- Do not operate the steamer with a damaged cord, unstable stand, or leaking reservoir.
- Stop immediately if the user experiences burning, dizziness, breathing discomfort, or irritation.
- Use the equipment only under trained supervision and follow its specified operating limits.

Care & storage

- Unplug the unit and allow it to cool before cleaning or draining it.
- Remove mineral deposits only using the method approved by the manufacturer.
- Dry the reservoir and external surfaces before storage to reduce residue and contamination.
- Inspect the cord, plug, reservoir, and steam outlet regularly and report defects.

Common mistakes to avoid

- Filling the reservoir beyond its marked maximum level.
- Positioning the steam outlet too close to the scalp or face.
- Opening the reservoir while it is hot or pressurised.
- Leaving water inside the unit for long periods or ignoring mineral buildup.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar