Air Conditioner



Category: **Hospitality & Housekeeping** Type: **Full SOP** Priority: **High** 3 labs

Covers these lab items: Air Conditioner; Air Conditioner 1.5 tonne

What it is used for

An air conditioner removes heat from an indoor space and transfers it outdoors to maintain comfortable conditions. Correct settings, unobstructed airflow, and routine cleaning help improve performance and reduce energy use.

Main parts

- Indoor unit distributes conditioned air into the room.
- Outdoor unit releases heat to the outside air.
- Compressor circulates refrigerant through the cooling system.
- Evaporator coil absorbs heat from indoor air.
- Condenser coil releases heat outdoors.
- Fan and blower move air through the indoor and outdoor units.
- Air filter captures dust and airborne particles.
- Thermostat or remote controller sets the temperature and operating mode.

Before you start

1. Read the user manual and identify the available operating modes and controls.
2. Inspect the visible units, power cord or isolator, and remote control for damage.
3. Ensure indoor and outdoor air inlets and outlets are not blocked.
4. Check that the air filter is correctly installed and reasonably clean.
5. Close doors and windows where practical to reduce unwanted heat entry.
6. Confirm there is no visible water leakage, damaged wiring, or unusual smell.

How to use

1. Switch on the air conditioner using the approved control or remote.
2. Select the required cooling or other supported operating mode.
3. Set a suitable target temperature and fan speed for the room conditions.
4. Allow the unit to start and check that air flows from the indoor outlet.
5. Adjust the air direction to distribute airflow without blowing directly on people unnecessarily.
6. Keep doors and windows closed where appropriate and avoid blocking the air filter or vents.
7. Monitor cooling performance, unusual noise, water leakage, and any fault indicators.
8. Switch the unit off using the control before isolating power for cleaning or maintenance.
9. Clean the filter according to the manual and allow it to dry before reinstalling.
10. Record or report persistent cooling problems, unusual sounds, or recurring error codes.

⚠ Safety

- Do not touch electrical parts or switches with wet hands.
- Never operate the unit if wiring, plugs, or electrical covers are damaged.
- Do not insert fingers or tools into fans or air outlets.
- Do not open refrigerant lines or attempt refrigerant repairs without qualified authorisation.
- Keep outdoor units clear of obstructions and do not stand on unstable supports to reach them.
- Isolate power according to the manual before cleaning accessible components or arranging maintenance.

Care & storage

- Clean or replace air filters at the recommended interval.
- Keep indoor and outdoor air inlets and outlets clear of dust and obstructions.
- Wipe accessible external surfaces with suitable materials and avoid spraying water into electrical areas.
- Arrange qualified servicing for refrigerant issues, persistent leakage, reduced cooling, or electrical faults.

Common mistakes to avoid

- Setting the temperature unnecessarily low and expecting faster cooling.
- Operating with a clogged filter or blocked airflow.
- Ignoring water leakage, unusual noises, or fault indicators.
- Cleaning internal electrical parts without isolating power.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar