Climate Control System



Category: **Hospitality & Housekeeping** Type: **Full SOP** Priority: **High** 3 labs

Covers these lab items: Temperature & humidity control system; Temperature control, fans, portable heaters if needed

What it is used for

A climate control system maintains suitable indoor temperature and humidity using controls, fans, and heating or cooling equipment. Correct settings, airflow management, and routine monitoring help support comfort, indoor air quality, and energy efficiency.

Main parts

- Temperature sensor measures indoor air temperature.
- Humidity sensor measures moisture level where fitted.
- Controller or thermostat sets target conditions and operating modes.
- Fan or blower circulates indoor air.
- Heating unit provides heat where installed.
- Cooling unit removes heat where installed.
- Air filter captures dust and particles where fitted.
- Display, switches, and control panel show settings and system status.

Before you start

1. Read the operating instructions and identify the system's temperature and humidity controls.
2. Inspect the controller, visible wiring, plugs, fans, filters, and heating or cooling units for damage.
3. Check that air inlets and outlets are clear and the room is not obstructed.
4. Confirm portable heaters, if used, are approved for the location and placed on a stable surface.
5. Check for unusual smells, visible leakage, damaged cables, or fault indicators.
6. Identify the recommended temperature and humidity range for the room's intended use.

How to use

1. Switch on the system using the approved controller or switch.
2. Select the required heating, cooling, ventilation, or automatic mode as available.
3. Set the target temperature and humidity within the recommended range for the space.
4. Adjust fan speed and airflow direction to distribute air evenly.
5. If a portable heater is needed, switch it on according to its instructions and monitor the room temperature.
6. Observe the displayed temperature, humidity, airflow, and system status during operation.
7. Adjust settings gradually if conditions move outside the required range.
8. Report unusual noise, repeated cycling, condensation, excessive dryness, or persistent humidity problems.
9. Switch off equipment that is not needed and follow the approved shutdown procedure.

⚠ Safety

- Never cover fans, air outlets, heaters, or ventilation grilles.
- Keep portable heaters away from curtains, bedding, paper, water, and other combustible materials.
- Do not use portable heaters with damaged cables, loose plugs, or signs of overheating.
- Avoid extension leads unless explicitly permitted by the equipment instructions and facility rules.
- Keep hands dry when operating electrical controls and do not open electrical panels without authorisation.
- Do not set extreme temperatures or humidity levels that could endanger occupants or damage stored materials.

Care & storage

- Clean or replace filters at the recommended interval.
- Keep sensors unobstructed and avoid placing them next to direct sunlight, heaters, or cooling outlets.
- Wipe accessible external surfaces with a suitable dry or lightly damp cloth as permitted by the manual.
- Inspect fans, vents, and portable heater cables regularly and arrange qualified service for faults.
- Record temperature and humidity readings when required by the facility procedure.

Common mistakes to avoid

- Setting unsuitable temperature or humidity targets for the room's use.
- Blocking air inlets or outlets with furniture or stored items.
- Leaving a portable heater close to combustible materials or unattended when prohibited.
- Ignoring persistent condensation, unusual smells, or system fault indicators.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.