# Hand Blender



Category: **Food Processing & Kitchen** Type: **Full SOP** Priority: **High** 3 labs

**Covers these lab items:** Hand Blender; Hand blender cum mixer

## What it is used for

A hand blender is used to blend, puree, mix, or emulsify food directly in a suitable container. Correct attachment selection, hygienic handling, and safe control of the rotating blade help achieve consistent results while reducing splashes, cuts, and electrical hazards.

## Main parts

- Motor housing contains the electric motor and controls.
- Blending shaft connects the motor to the blade assembly.
- Blade guard covers the rotating blade area.
- Blade assembly cuts and blends food.
- Speed control adjusts blending speed where fitted.
- Power switch starts and stops the blender.
- Detachable whisk or mixer attachment supports other mixing tasks where provided.
- Power cable or battery supplies energy to the unit.

## Before you start

1. Read the operating instructions and use the blender only for approved tasks.
2. Inspect the motor housing, shaft, blade guard, attachment lock, and cable or battery for damage.
3. Confirm the attachment is clean, correctly fitted, and suitable for the food and task.
4. Use a stable, deep container that can accommodate the ingredients without overflowing.
5. Cut large or hard ingredients into suitable pieces and add sufficient liquid when required by the recipe.
6. Keep the motor housing and electrical connections dry, and ensure hands are dry before plugging in.

## How to use

1. Wash hands and prepare the ingredients according to the recipe.
2. Place ingredients in a suitable container and keep the container stable on the work surface.
3. Fit and lock the required blending or mixing attachment while the blender is switched off and unplugged where applicable.
4. Position the blade guard fully within the ingredients before starting the motor.
5. Start at a low speed and increase gradually if required.
6. Move the blender gently through the mixture without lifting the running blade above the food surface.

7. Pause the motor before repositioning the blender, scraping the container, or changing speed if the manual requires it.
8. Switch off and unplug the unit before removing the attachment or clearing food from the blade area.
9. Transfer the blended food hygienically and inspect the result for the required consistency.
10. Clean the shaft and attachments promptly according to the manufacturer's instructions.
11. Dry all parts thoroughly and store the blender safely after use.

## ⚠ Safety

- Never touch the blade or place fingers in the blade guard while the unit is connected to power.
- Switch off and unplug the blender before changing attachments or clearing a jam.
- Do not immerse the motor housing or power connection in water.
- Do not operate the blender with a damaged cable, loose attachment, or broken blade guard.
- Avoid overfilling the container and use care with hot liquids to prevent splashes and burns.
- Keep children and untrained persons away from the operating blender.

## Care & storage

- Wash detachable food-contact parts using the approved cleaning method after each use.
- Wipe the motor housing with a suitable damp cloth without immersing it.
- Inspect blades, attachment locks, seals, and cables regularly.
- Allow cleaned parts to dry completely before storage and arrange authorised repair for faults.

## Common mistakes to avoid

- Starting the blender before the blade guard is immersed in the ingredients.
- Changing attachments or clearing food while the motor is running.
- Submerging the motor housing in water.
- Using an unsuitable container or overfilling it, causing spills and splashes.

*Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.*