Facial Steamer



Category: **Beauty, Wellness & Fitness** Type: **Full SOP** Priority: **High** 2 labs

Covers these lab items: Facial Steamer

What it is used for

A facial steamer produces warm mist to support selected facial treatments. Use it at a suitable distance and temperature to reduce the risk of burns and skin irritation.

Main parts

- Water reservoir or tank
- Heating element and control panel
- Steam outlet or nozzle
- Power switch and power cord
- Reservoir lid and water-level markings
- Stand or adjustable support, if fitted

Before you start

1. Place the steamer on a stable, level, dry surface.
2. Inspect the power cord, plug, reservoir, and nozzle for damage.
3. Fill the reservoir with the water type specified by the manufacturer.
4. Ensure the water level is within the marked limits.
5. Check the client's skin sensitivity and suitability for steam treatment.
6. Keep the steam outlet clear and the surrounding area dry.

How to use

1. Switch off the steamer before filling the reservoir.
2. Fill the tank to the specified level and close the lid securely.
3. Position the unit so the nozzle can direct mist safely toward the client.
4. Connect the plug to a suitable electrical outlet.
5. Switch on the unit and allow it to heat as instructed.
6. Check that the mist output is steady before beginning treatment.
7. Position the client's face at the recommended distance from the nozzle.
8. Use the treatment time specified for the device and client's suitability.
9. Monitor comfort and skin response continuously during treatment.
10. Stop immediately if excessive heat, discomfort, or dizziness occurs.
11. Switch off and unplug the steamer after use.
12. Allow the unit to cool before emptying or cleaning the reservoir.

⚠ Safety

- Only trained personnel should operate the steamer.
- Never direct hot steam at the eyes or too close to the skin.
- Do not overfill the water reservoir or operate it empty.
- Keep the unit and plug away from splashes and wet surfaces.
- Use caution for clients with heat sensitivity or conditions unsuitable for steam.
- Never open a hot reservoir or move the unit while it contains hot water.

Care & storage

- Unplug and cool the unit before cleaning.
- Empty remaining water according to the manufacturer's instructions.
- Remove mineral deposits using only approved descaling methods.
- Inspect the nozzle and power cord regularly.

Common mistakes to avoid

- Positioning the face too close to the steam outlet.
- Using unapproved additives or oils in the reservoir.
- Filling above the maximum level or running the tank empty.
- Cleaning or opening the reservoir while it is hot.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar