Bamboo Sliver Making Machine



Category: **Power Tools & Workshop Machines** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Bamboo Sliver Making Machine

What it is used for

A bamboo sliver making machine converts bamboo strips or prepared sections into narrow slivers used for weaving, crafts, mats, and other products. Use suitable splitting and sizing settings and guide the material with approved supports to obtain consistent slivers while preventing cuts and splinter injuries.

Main parts

- Machine frame and feed table
- Slitting or sliver-forming blade assembly
- Guide plates and sizing channels
- Feed rollers, pusher, or holding fixture
- Drive motor and transmission
- Protective guards, waste tray, and emergency stop

Before you start

1. Confirm the machine's capacity, permitted bamboo dimensions, and required sliver width and thickness.
2. Inspect the blades, guides, feed mechanism, frame, guards, and controls for damage.
3. Ensure the blades are sharp, securely fitted, and aligned with the selected sliver size.
4. Prepare bamboo by removing dirt, loose fibres, knots, and damaged areas that could disrupt feeding.
5. Set the required sliver dimensions and install the correct guides or tooling.
6. Wear safety glasses, suitable gloves for handling raw bamboo, protective footwear, and other required PPE.

How to use

1. Switch off and isolate the machine before changing blades, guides, or settings.
2. Install the correct sliver-forming tooling and verify that it is secured according to the manual.
3. Adjust the guides and feed mechanism to the required dimensions.
4. Place the bamboo in the designated feed position using the approved holder or pusher.
5. Check that the bamboo is aligned with the cutting path and that the discharge area is clear.
6. Start the machine and allow the drive system to reach normal operating speed.
7. Feed the bamboo at a steady rate using the designed mechanism; keep hands away from blades and rollers.
8. Collect emerging slivers from the designated output area without reaching into the cutting zone.

9. Inspect the slivers for consistent width, thickness, straightness, and excessive splintering.
10. Stop the machine if the bamboo shifts, slivers jam, or the drive system operates abnormally.
11. Wait for all motion to stop before clearing jams, removing waste, or making adjustments.
12. Switch off and isolate power, clean the machine, and record production quality or maintenance issues.

⚠ Safety

- Only trained operators should use or adjust the sliver making machine.
- Never reach toward the blade or feed rollers while the machine is running.
- Use the designated pusher or holding fixture rather than fingers to feed short pieces.
- Do not bypass guards or operate with loose, damaged, or incorrectly fitted blades.
- Keep the output area clear and handle sharp bamboo slivers carefully to prevent cuts and splinters.
- Isolate power before clearing a jam, changing tooling, or performing maintenance.

Care & storage

- Remove bamboo fibres and slivers from the machine after shutdown.
- Inspect blades, guides, fasteners, and feed rollers regularly.
- Keep the cutting assembly clean, sharp, and correctly aligned.
- Lubricate moving parts only as specified by the manufacturer.
- Arrange servicing if sliver dimensions become inconsistent or the machine develops unusual vibration or noise.

Common mistakes to avoid

- Using incorrect guide settings for the required sliver dimensions.
- Feeding bamboo by hand too close to the cutting assembly.
- Allowing slivers or fibres to accumulate in the feed and discharge areas.
- Clearing a jam or changing a blade without isolating the machine.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.