Blind Stitch Machine



Category: **Sewing, Textile & Handicraft** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Blind stitch machine

What it is used for

A blind stitch machine creates nearly invisible stitches that secure folded fabric edges, hems, or linings without showing prominent stitches on the outer surface. Correct needle selection, stitch depth, and fabric positioning are important to achieve a neat finish while preventing needle injuries and fabric damage.

Main parts

- Machine head and needle
- Blind-stitch presser foot and fabric guide
- Thread spool and tension assembly
- Stitch-depth or bite adjustment
- Feed mechanism and work table
- Motor, pedal or start control, and protective guard

Before you start

1. Confirm the fabric type, hem construction, and required blind-stitch finish.
2. Inspect the needle, presser foot, thread path, feed mechanism, guard, and power cable for damage.
3. Select a needle and thread suitable for the fabric weight and fibre type.
4. Thread the machine and set the tension and stitch depth according to the manual.
5. Fold and position the hem so the needle catches the intended amount of inner fabric without making visible outer stitches.
6. Test the setup on a matching fabric scrap and check stitch visibility and strength.

How to use

1. Switch off the machine before changing the needle, threading near the needle, or adjusting internal components.
2. Install the correct needle and presser foot, ensuring they are secure and aligned.
3. Set the blind-stitch depth and thread tension according to the sample result and job specification.
4. Position the folded hem against the guide and place the fabric under the presser foot.
5. Lower the presser foot and ensure the fabric lies flat without pulling or twisting.
6. Start the machine using the approved pedal or control and guide the fabric steadily along the hem.

7. Observe the first stitches to confirm that they catch the fold correctly and remain inconspicuous on the outer side.
8. Stop the machine if the needle breaks, thread tangles, fabric slips, or unusual noise occurs.
9. Raise the presser foot and remove the fabric only after the needle has stopped safely.
10. Inspect the hem for skipped stitches, visible outer stitches, puckering, and uneven tension.
11. Trim loose thread ends with suitable scissors and avoid placing fingers near the needle.
12. Switch off the machine, clean lint from the needle plate and feed area, and record any quality issues.

⚠ Safety

- Only trained users should operate or adjust the sewing machine.
- Keep fingers away from the needle and presser foot while the machine is running.
- Never bypass needle guards or other safety devices.
- Switch off and isolate power before replacing the needle, clearing a jam, or performing maintenance.
- Do not pull or twist fabric forcibly while the needle is engaged.
- Keep loose clothing, hair, and jewellery away from the moving parts.

Care & storage

- Remove lint and thread waste from the needle plate, feed mechanism, and accessible areas after shutdown.
- Replace bent, blunt, or damaged needles promptly.
- Check thread tension, guides, presser foot, and feed movement regularly.
- Lubricate designated points only as instructed by the manufacturer.
- Arrange servicing if stitch depth becomes inconsistent, the machine skips stitches repeatedly, or unusual vibration occurs.

Common mistakes to avoid

- Setting the stitch depth too deep and creating visible outer stitches.
- Using unsuitable needle or thread for the fabric.
- Pulling the fabric while the needle is engaged.
- Ignoring skipped stitches, puckering, or incorrect thread tension.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.