Button Sewing Machine



Category: **Sewing, Textile & Handicraft** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Button sewing machine

What it is used for

A button sewing machine attaches buttons to garments using a programmed or mechanically controlled stitch pattern. Select the correct needle, thread, button clamp, and stitch settings to ensure secure attachment while preventing needle injuries and fabric damage.

Main parts

- Machine head and sewing needle
- Button clamp or button holder
- Needle and bobbin thread system
- Stitch pattern and tension controls
- Presser mechanism and fabric support
- Motor, start pedal, and protective guard

Before you start

1. Confirm the button type, size, hole pattern, fabric, and required attachment strength.
2. Inspect the needle, button clamp, thread path, bobbin, guards, and power cable for damage.
3. Fit a needle suitable for the fabric and thread and ensure it is securely mounted.
4. Thread the machine and install the correct button holder or clamp.
5. Select the appropriate stitch pattern and settings according to the machine manual.
6. Test the setup on a sample fabric and check button security before production.

How to use

1. Switch off the machine before changing the needle, threading near the needle, or adjusting the clamp.
2. Install the correct needle and button holder, then confirm that the holder is securely fixed.
3. Set the stitch pattern, stitch count, and thread tension according to the button and fabric specifications.
4. Position the button in the designated holder and ensure its holes align with the needle path.
5. Place the garment under the clamp with the button attachment point correctly aligned.
6. Lower the clamp and confirm that the fabric and button are held securely without excessive tension.
7. Keep fingers clear of the needle and start the machine using the approved control.
8. Observe the first sewing cycle to confirm that stitches pass through the intended button holes.
9. Stop the machine if the button shifts, the needle breaks, thread tangles, or unusual noise occurs.
10. After the needle stops safely, release the clamp and remove the garment carefully.

1. Check that the button is secure, correctly positioned, and free from loose or excessive thread.
2. Switch off the machine, remove lint and thread waste, and record any quality issues.

⚠ Safety

- Only trained operators should use or adjust the machine.
- Keep fingers away from the needle, button clamp, and moving mechanisms during operation.
- Never bypass needle guards or safety interlocks.
- Switch off and isolate power before changing needles, clearing jams, or performing maintenance.
- Do not hold or reposition a button by hand while the needle is moving.
- Keep loose clothing, hair, and jewellery away from moving parts.

Care & storage

- Clean lint and thread waste from the needle plate, clamp, and bobbin area after shutdown.
- Inspect the needle, button holder, thread guides, and clamp alignment regularly.
- Replace bent or blunt needles promptly.
- Lubricate only the designated points according to the manufacturer's instructions.
- Arrange servicing if stitches become inconsistent, the clamp slips, or the machine develops unusual noise.

Common mistakes to avoid

- Using a button holder or stitch pattern unsuitable for the button.
- Misaligning the button holes with the needle path.
- Placing fingers close to the needle during sewing.
- Ignoring loose stitches or failing to check button security after sewing.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar