Jig Saw



Category: **Power Tools & Workshop Machines** Type: **Full SOP** Priority: **High** 1 labs

Covers these lab items: Jig Saw

What it is used for

To cut wood, plastic, or other approved sheet materials using a jigsaw and a suitable blade. To follow the marked cutting line while controlling the tool and limiting the risk of kickback, blade breakage, and injury.

Main parts

- Electric motor and housing
- Reciprocating blade and blade clamp
- Base plate or shoe
- Trigger switch and lock, if fitted
- Cutting-angle adjustment
- Power cord or battery and blade guard

Before you start

1. Read the tool manual and confirm that the blade is suitable for the material and thickness.
2. Inspect the blade, clamp, base plate, cord or battery, and switch for damage.
3. Disconnect power or remove the battery before changing the blade or adjusting the tool.
4. Secure the workpiece firmly using clamps and support the material near the cutting line.
5. Mark the cut line and check for hidden nails, screws, cables, or pipes.
6. Wear safety glasses and hearing protection; use suitable respiratory protection when dust requires it.

How to use

1. Fit the correct blade securely and verify that the blade clamp is locked.
2. Adjust the base plate and cutting angle as required, then tighten all adjustment locks.
3. Set the cutting speed and orbital action, if available, according to the material and blade.
4. Place the base plate flat on the workpiece with the blade clear of the material.
5. Hold the tool firmly with both hands where the design permits and keep the cord clear of the cutting path.
6. Start the tool and allow the blade to reach operating speed before beginning the cut.
7. Guide the jigsaw along the marked line without forcing or twisting the blade.
8. Support offcuts so they do not pinch the blade or fall unexpectedly.
9. Release the trigger and wait for the blade to stop before setting the tool down.
10. Disconnect power before clearing a jam, changing settings that expose the blade, or replacing the blade.

1. Inspect the cut edge and remove dust and debris using a safe method.
2. Store the jigsaw with the blade protected and the power source disconnected.

⚠ Safety

- Keep hands away from the blade path and never reach beneath the workpiece while cutting.
- Do not use damaged blades or operate with a loose blade clamp.
- Never cut a workpiece that is not securely supported.
- Wait for the blade to stop completely before placing the tool down.
- Keep the cord away from the blade and check for concealed electrical wiring before cutting.
- Do not use the tool in wet conditions unless specifically rated for them.
- Secure loose clothing and hair, and keep bystanders away from flying chips and dust.

Care & storage

- Clean dust from the vents and base plate after use.
- Inspect blades for cracks, dullness, or damaged teeth and replace as needed.
- Check the base plate, blade clamp, switch, and power cable regularly.
- Use only manufacturer-approved replacement parts and accessories.
- Store in a dry place and remove the battery or disconnect the cord before storage.

Common mistakes to avoid

- Using the wrong blade for the material or cut type.
- Forcing the tool and bending the blade away from the cut line.
- Failing to clamp the workpiece securely.
- Changing the blade while the tool is connected to power.
- Setting the tool down before the blade has stopped.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.