Tyre Pressure Gauge



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 6 labs

Covers these lab items: Tire pressure gauges; Tyre pressure gauge

What it is used for

A tyre pressure gauge measures the air pressure inside a vehicle tyre. Compare the reading with the vehicle manufacturer's recommended pressure for the tyre condition and load.

How to use

1. Check the gauge, hose, and connector for damage or leakage.
2. Find the recommended tyre pressure from the vehicle label or manual.
3. Park safely, switch off the vehicle, and check the tyre when appropriate.
4. Remove the valve cap and press the gauge connector firmly onto the valve.
5. Read the pressure and compare it with the recommended value.
6. Adjust pressure if required, recheck the reading, and replace the valve cap.

⚠ Safety

- Check pressure on a safe, level surface away from moving traffic.
- Do not measure or inflate a visibly damaged or dangerously hot tyre without professional guidance.
- Keep fingers clear of the valve and avoid sudden air release.

Care & storage

- Keep the gauge clean and dry, protect it from impact, and store it safely.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.