Oil Pressure Gauge



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 4 labs

Covers these lab items: Oil pressure gauges

What it is used for

To measure engine oil pressure using an appropriate oil pressure gauge. To compare the reading with the vehicle manufacturer's specified range.

Main parts

- Pressure gauge
- Connecting hose
- Adapter fittings
- Pressure port connector
- Gauge scale or display

Before you start

1. Park the vehicle securely and consult the service manual.
2. Confirm the gauge range and adapter suit the engine.
3. Inspect the hose, fittings, and gauge for damage.
4. Allow hot engine parts to cool before connecting the gauge.

How to use

1. Locate the specified oil pressure test port.
2. Switch off the engine before fitting the gauge.
3. Connect the correct adapter and tighten securely.
4. Start the engine according to the test procedure.
5. Observe pressure at the specified engine speed and temperature.
6. Compare readings with manufacturer specifications.
7. Switch off the engine before removing the gauge.
8. Reconnect the original fitting and check for leaks.

⚠ Safety

- Keep clear of hot oil and moving engine parts.
- Never remove a pressurized fitting while the engine is running.
- Use the correct pressure-rated hose and adapter.
- Stop the test if oil leaks or the gauge behaves abnormally.

Care & storage

- Clean the fittings after use.
- Inspect the hose and gauge regularly.
- Store the gauge in its protective case.

Common mistakes to avoid

- Using an incorrect adapter.
- Comparing readings without considering engine temperature or speed.
- Removing the gauge while the system is pressurized.
- Ignoring oil leakage.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar