Tappet Puller



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 4 labs

Covers these lab items: Tappet puller

What it is used for

To remove or reposition tappets or related valve-train components during approved engine maintenance. To apply controlled force using a compatible tappet puller and avoid damage to engine parts.

Main parts

- Puller body
- Gripping jaws or hooks
- Screw or pulling mechanism
- Handle or drive point
- Adjustment components

Before you start

1. Confirm the engine model and the correct puller type.
2. Switch off the engine and follow the service manual isolation procedure.
3. Allow hot engine components to cool.
4. Inspect the puller for cracks, wear, or damaged threads.
5. Prepare the specified tools and protect nearby components.

How to use

1. Access the tappet or component according to the service manual.
2. Position the puller securely on the intended component.
3. Align the pulling mechanism with the component axis.
4. Apply force gradually using the specified method.
5. Stop if the component binds or the tool slips.
6. Remove the component carefully and inspect it for damage.
7. Clean the tool and reinstall components according to the service procedure.

⚠ Safety

- Only trained technicians should perform engine disassembly.
- Never work on a running engine.
- Keep fingers clear of gripping jaws and pinch points.
- Do not use improvised extensions or excessive force.
- Follow manufacturer instructions for engine timing and reassembly.

Care & storage

- Clean the puller after use.
- Inspect jaws, threads, and moving parts regularly.
- Apply lubricant only where specified.
- Store in a dry tool case.

Common mistakes to avoid

- Using an incompatible puller.
- Applying force at an angle.
- Forcing a seized component and damaging the engine.
- Ignoring damaged puller threads or jaws.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.