Fan



Category: **Electrical & Electronic Components & Kits** Type: **Short SOP** Priority: **Medium**

3 labs

Covers these lab items: Ceiling Fan / Exhaust Fan; Fan

What it is used for

To operate a ceiling fan or exhaust fan for air circulation or ventilation. To maintain safe operation by checking mounting, electrical connections, and airflow before use.

Main parts

- Motor housing
- Blades or impeller
- Mounting bracket or frame
- Switch or speed controller
- Protective grille, if fitted
- Electrical wiring and terminal cover

Before you start

1. Confirm the fan type, voltage rating, and installation requirements.
2. Inspect the housing, blades, mounting points, and grille for damage.
3. Ensure the fan is securely mounted and the blades have adequate clearance.
4. Check that wiring and earthing are installed by a qualified person.
5. Isolate power before cleaning or inspecting internal electrical parts.

How to use

1. Ensure the area around the fan is clear.
2. Switch on the fan using the designated control.
3. Select an appropriate speed or operating mode.
4. Observe the fan for unusual noise, vibration, or reduced airflow.
5. Switch off immediately if abnormal operation occurs.
6. Isolate power before cleaning or performing maintenance.
7. Restore power only after covers and guards are securely fitted.

⚠ Safety

- Never touch moving blades or reach through a grille.
- Do not operate a fan with loose mounting, damaged blades, or exposed wiring.
- Electrical installation and repairs must be performed by qualified personnel.
- Keep water away from electrical components unless the equipment is specifically rated for that environment.

Care & storage

- Clean blades and grille after isolating power.
- Check mounting hardware and vibration periodically.
- Keep ventilation openings free of dust and obstructions.
- Report electrical faults and replace damaged parts before reuse.

Common mistakes to avoid

- Cleaning the fan while power is connected.
- Operating with loose mounting or damaged blades.
- Ignoring unusual noise or vibration.
- Blocking the exhaust path or air intake.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.

Prepared by - Subodh Kumar