Inclinometer



Category: **Measuring & Marking Tools** Type: **Short SOP** Priority: **Medium** 3 labs

Covers these lab items: Inclinometer

What it is used for

To measure the angle of inclination, slope, or tilt of a surface or component.

How to handle

- Inspect the inclinometer, display or scale, base, and calibration status before use.
- Place the instrument on the intended surface or align it with the component being measured.
- Zero or calibrate the device as required by its instructions and select the correct measurement mode or units.
- Allow the reading to stabilise, read the angle without disturbing the instrument, and record the result with units.
- Clean the instrument after use and avoid dropping it or exposing it to conditions outside its rated limits.

Storage

- Store in a protective case in a dry, dust-free place.
- Protect the measuring base, scale, and sensor from impact, moisture, and extreme temperatures.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.