Lug Wrench



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 3 labs

Covers these lab items: Lug wrenches

What it is used for

To loosen and tighten vehicle wheel lug nuts during wheel removal or installation.

How to handle

- Inspect the lug wrench for cracks, bending, or damaged socket ends before use.
- Park the vehicle on firm, level ground, apply the parking brake, and secure the wheels as appropriate.
- Use the correct socket size and loosen lug nuts slightly before lifting the vehicle, following the vehicle manual.
- Support the vehicle with approved jack stands before removing the wheel; never rely on a jack alone.
- Tighten lug nuts in the specified sequence and to the manufacturer's torque using a calibrated torque wrench where required.

Storage

- Wipe clean and store in a dry tool cabinet or designated rack.
- Keep socket ends protected from rust and avoid placing heavy loads on the wrench.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.