Stud Extractor



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 3 labs

Covers these lab items: Stud extractor; Stud remover; Stud remover with socket handle

What it is used for

To remove damaged, seized, or broken threaded studs from automotive components with minimal damage to surrounding material.

How to handle

- Inspect the extractor, socket handle, gripping mechanism, and compatible socket for wear or damage.
- Confirm the stud size, thread direction, and extractor compatibility before applying force.
- Secure the workpiece and wear eye protection and suitable gloves.
- Fit the extractor squarely onto the stud and apply controlled torque using the specified handle; avoid sudden force that may break the stud further.
- Clean the tool after use and inspect the removed threads and surrounding component for damage.

Storage

- Store clean and dry in a labelled automotive tool case with compatible sockets.
- Protect gripping surfaces from corrosion and keep the tool organised to avoid loss of small components.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.