Spring Caliper

Category: **Measuring & Marking Tools** Type: **Short SOP** Priority: **Medium** 2 labs

Covers these lab items: Spring Caliper Inside /Outside /Divider

What it is used for

A spring caliper transfers or compares internal and external dimensions without directly displaying a measurement. Use it with a suitable scale or measuring instrument to determine dimensions.

How to use

1. Identify whether the caliper is an inside, outside, or divider type.
2. Inspect the spring, adjustment nut, joints, and contact points for damage.
3. Adjust the legs gently to fit the dimension being checked.
4. Place the contact points correctly against the inside or outside surfaces.
5. Lock or hold the adjustment and remove the caliper without changing its setting.
6. Compare the setting with a suitable ruler or measuring instrument.

⚠ Safety

- Keep sharp points away from fingers, eyes, and other people.
- Do not force the legs against a workpiece or over-tighten the adjustment nut.
- Secure the workpiece before measuring near sharp or moving parts.

Care & storage

- Wipe clean after use, lightly protect metal surfaces if required, and store closed safely.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.