Air Pump



Category: **Power Tools & Workshop Machines** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Air pumps

What it is used for

An air pump moves air to inflate items or supply air to compatible equipment. Check its pressure rating and intended use before operation.

How to use

1. Inspect the pump, hose, power cable, connectors, and gauge for damage.
2. Confirm that the pump suits the item and required pressure.
3. Connect the correct nozzle or hose securely to the valve or inlet.
4. Switch on the pump or operate the manual handle steadily.
5. Monitor the pressure gauge or item firmness throughout inflation.
6. Stop at the specified pressure and disconnect the hose carefully.
7. Switch off and store the pump after use.

⚠ Safety

- Never exceed the pressure limit of the item or pump.
- Keep fingers, hair, and loose clothing away from moving parts.
- Do not use damaged electrical cables or operate electrical pumps in wet conditions.
- Allow the pump to cool if it becomes unusually hot.

Care & storage

- Keep air inlets clear and store the pump and hose clean and dry.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.