Ball Joint Separator



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Ball joint separators

What it is used for

A ball joint separator helps disconnect a vehicle's ball joint from its mating component during repair. Use the correct separator type and follow the vehicle service procedure.

How to use

1. Park the vehicle securely, switch off the engine, and prevent movement.
2. Consult the service manual and identify the correct ball joint separator.
3. Use approved lifting points and support the vehicle with rated stands when lifting is required.
4. Inspect the separator, threads, jaws, and contact points for damage.
5. Position the tool correctly around the joint according to its design.
6. Apply force gradually using the specified method until the joint separates.
7. Inspect components and remove the tool carefully after separation.

⚠ Safety

- Never work beneath a vehicle supported only by a jack.
- Wear eye protection and keep hands away from pinch points.
- Do not strike a loaded separator unless its instructions specifically permit it.
- Only trained persons should perform vehicle suspension repairs.

Care & storage

- Clean the tool after use, inspect its threads, and store it dry in its case.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.