Clutch Puller



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Clutch puller

What it is used for

A clutch puller removes a compatible clutch component from its shaft during mechanical servicing. Use the specified puller and follow the equipment manufacturer's removal procedure.

How to use

1. Switch off the machine or vehicle and isolate the power source as instructed.
2. Consult the service manual to identify the correct puller and attachment points.
3. Inspect the puller threads, bolts, jaws, and contact surfaces for damage.
4. Secure the component and fit the puller squarely according to its design.
5. Tighten the puller gradually using the specified tool and procedure.
6. Stop if the puller slips, bends, or excessive force is required.
7. Remove the separated component and inspect all parts before reassembly.

⚠ Safety

- Wear eye protection and keep hands clear of loaded components.
- Do not use improvised extensions or exceed the puller's rated capacity.
- Never strike a loaded puller unless the manufacturer explicitly permits it.
- Only trained personnel should perform clutch removal and servicing.

Care & storage

- Clean the puller after use, inspect threads, and store it dry in its case.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.