Fuel Pressure Tester



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: fuel pressure testers

What it is used for

A fuel pressure tester measures fuel-system pressure to help diagnose delivery problems. Use the correct tester and follow the vehicle manufacturer's service procedure.

How to use

1. Identify the vehicle fuel system and confirm tester compatibility and pressure range.
2. Park safely, switch off the ignition, and allow hot components to cool.
3. Wear suitable eye protection and gloves, and keep an appropriate fire extinguisher accessible.
4. Relieve fuel-system pressure using the specified service procedure.
5. Connect the tester to the designated test port with the correct fittings.
6. Restore the system as instructed, check for leaks, and measure pressure under specified conditions.
7. Switch off the engine or ignition, relieve pressure safely, and disconnect the tester as directed.

⚠ Safety

- Work in a well-ventilated area away from flames, sparks, and smoking.
- Never disconnect fuel lines while the system is pressurized.
- Avoid fuel contact with skin and eyes; clean spills promptly using approved procedures.
- Follow special precautions for high-pressure direct-injection and diesel systems.

Care & storage

- Clean the tester, inspect hoses and seals, and store it with fittings protected.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.