Grease Gun



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: Grease gun

What it is used for

A grease gun delivers lubricant into designated grease fittings on compatible machinery or vehicle components. Use the specified grease and apply the recommended quantity and pressure.

How to use

1. Identify the grease points and confirm the lubricant specification in the service manual.
2. Inspect the grease gun, hose, coupler, and fittings for damage or leaks.
3. Load the gun with the specified grease using the approved filling method.
4. Wipe dirt from the grease fitting before attaching the coupler.
5. Connect the coupler securely and operate the handle to deliver the recommended amount.
6. Stop if abnormal resistance, leakage, or seal damage is observed.
7. Release pressure as instructed, disconnect the coupler, and wipe away excess grease.

⚠ Safety

- Wear suitable gloves and eye protection when handling grease.
- Never point a grease gun at skin; high-pressure grease can cause serious injection injuries.
- Do not exceed the component's recommended pressure or lubricant quantity.
- Keep grease away from hot surfaces and dispose of waste properly.

Care & storage

- Clean the gun and coupler, inspect the hose, and store it in a clean location.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.