Motor Driver Module

Category: **Electrical & Electronic Components & Kits** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: L298P Motor Driver

What it is used for

An L298P motor driver module controls suitable DC motors or compatible loads using low-power control signals. Check the module specifications and connect the motor, supply, and controller according to its datasheet.

How to use

1. Inspect the module, terminals, connectors, and board for visible damage.
2. Read the datasheet to confirm operating voltage, current limits, and supported motor type.
3. Switch off all power before making connections.
4. Connect the motor, motor supply, logic supply, and controller signals according to the wiring diagram.
5. Check polarity, common ground requirements, and secure terminal connections.
6. Apply the specified power and test motor direction and speed using suitable control signals.
7. Switch off power before changing wiring and record any abnormal operation.

⚠ Safety

- Never exceed the module's voltage or current ratings.
- Avoid short circuits and keep exposed conductors separated.
- Use appropriate protection against motor current, heat, and inductive voltage spikes.
- Do not touch hot components while the module is operating.

Care & storage

- Disconnect power after testing and store the module in a dry, static-safe location.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.