Slide Hammer



Category: **Automotive** Type: **Short SOP** Priority: **Medium** 1 labs

Covers these lab items: slide hammers

What it is used for

A slide hammer applies controlled impact force to pull suitable automotive components or attachments. Select the correct adapter and follow the vehicle service procedure for the specific repair.

How to use

1. Inspect the hammer shaft, sliding weight, handle, threads, and adapters for damage.
2. Confirm that the tool and adapter are suitable for the component being removed.
3. Secure the vehicle or workpiece and isolate relevant power systems where required.
4. Attach the correct adapter firmly to the slide hammer and component.
5. Keep the shaft aligned with the removal direction and maintain a stable grip.
6. Move the sliding weight in controlled strokes to apply pulling force as specified.
7. Inspect the removed component and tool, then clean and store the equipment.

⚠ Safety

- Wear safety glasses and suitable gloves during impact work.
- Keep hands and body clear of the sliding weight and impact zones.
- Do not exceed the tool's rated load or use damaged adapters.
- Follow vehicle-specific precautions around airbags, fuel systems, and electrical components.

Care & storage

- Clean threads and moving surfaces after use and inspect adapters before storage.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.