Oil Measure Container



Category: **Automotive** Type: **Short SOP** Priority: **Low** 3 labs

Covers these lab items: Oil measure container; Oil measure container, funnel

What it is used for

An oil measure container and funnel help measure and transfer automotive oils with reduced spillage. Use clean, clearly marked equipment and follow the vehicle manufacturer's fluid specification.

How to use

1. Inspect the measuring container, markings, funnel, and cap for damage or contamination.
2. Confirm the required oil type, quantity, and specification from the service manual.
3. Place the vehicle on a stable surface and prepare the designated filling area.
4. Measure the oil at eye level using the correct scale and units.
5. Position the funnel securely and pour oil slowly into the specified fill opening.
6. Check the fluid level using the vehicle's prescribed method and add only if required.
7. Clean the container and funnel and dispose of oily waste appropriately.

⚠ Safety

- Keep oil away from hot engine parts and ignition sources.
- Wear suitable gloves and avoid prolonged skin contact with used oil.
- Do not mix incompatible fluids or use contaminated measuring equipment.
- Clean spills promptly to prevent slips and environmental contamination.

Care & storage

- Wipe and store the container and funnel separately from food or drinking-water equipment.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.