Air Filter

Category: **Automotive** Type: **Handling note** Priority: **Low** 6 labs

Covers these lab items: Air cleaner; Air filters

What it is used for

Automotive air filters remove dust and particles from intake air to help protect engine components.

How to handle

- Confirm the filter type and vehicle compatibility before replacement.
- Inspect the filter housing, seals, and intake area for damage or contamination.
- Switch off the engine and allow hot components to cool before servicing.
- Install the filter in the correct orientation and ensure the housing seals properly.
- Avoid blowing dust into the engine intake or breathing airborne particles.

Storage

- Keep replacement filters sealed in clean, dry packaging.
- Store away from moisture, oil, dust, and crushing pressure.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.