

ESD AND H2S MAINTENANCE BYPASS SWITCH DCS Manual						
	Document Title					
Department Production Revision No. Document No. Page						
Section	Process AB	04 TNU 200 402 (40) 4 of 44				
Area	Area Common 01 TNH-200-103 (10) 1 of 11					

	HISTORY of REVISION						
Rev. No.	Effective Date	Revised Page (s)	Description	Prepared by	Checked by	Noted by	Approved by
01			New	GJHO	DJN/HM	ON	FM
Ī							

Prepared by	Checked	by	Noted by	Approved by
Grezil Joie H. Ortega	Dexter J. Navales	Hiroyuki Mitsui	Osamu Nakai	Fumio Mizuno
Date:	Date:		Date:	Date:

IMPORTANT:

THIS COVER SHEET FORM IS PART OF THE FOLLOWING DOC SHEETS AND IS NOT TO BE DISCARDED UNLESS SUPERCEDE BY A REVISED ISSUE. UNAUTHORIZED REPRODUCTION IS STRICTLY PROHIBITED.



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS				
Manual				
Document Title				
Rev No. Doc No. Page				
01	TNH-200-103 (10)	2 of 11		

CONTENTS

I.	General Description	3
II.	Important Monitoring Items	
	1. Controllers' Description	
	2. Instruments' Description	
	3. Motors	4
	4. Actuated Valves	4
	5. Switches	
	1) ESD Maintenance Bypass Switches	4
	2) H2S (SIS) Maintenance Bypass Switches	
III.	Interlocks/Controls	
IV.	Control Sequences	9
٧.	Alarms	9
VI.	DCS Emergency Shutdown	9
	Trend Graphs Grouping	
	ex 1: ESD MAINTENANCE BYPASS SWITCH DCS Graphics	
	nex 2: H2S MAINTENANCE BYPASS SWITCH DCS Graphics	



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS			
Manual			
Document Title			
Rev No.	Rev No. Doc No. Page		
01	TNH-200-103 (10)	3 of 11	

I. General Description

ESD and SIS are very important safety system of THPAL plant that provides emergency shutdown of HPAL 102/202, MS Plant and H2S Plant when hazardous condition in the process area is occurring. The ESD and SIS are triggered by process alarms (instrument/equipment alarms), manual pushbutton or Electric Power Failure. Refer to *TNH-200-102 Emergency Shutdown (ESD) Manual* for detailed discussion of ESD and SIS.

Each process alarm linked to ESD and SIS has designated maintenance bypass switch. When these bypass switches are activated, the signal from the process alarms are cut off thus preventing activation of ESD or SIS by process alarm conditions. However, ESD and SIS manual pushbuttons and electric power failure signals are still active and ESD or SIS can still be activated when any of these two signals are triggered. Refer to Figure 1-1 for block diagram of the maintenance bypass function.




Figure 1-1: Maintenance Bypass Switch Block Diagram

The ESD Maintenance Bypass Switch Graphics provides operator access on the bypass switches of HPAL 102/202 and MS Plant ESD process alarms (refer to *Annex 1*). On the other hand, the H2S Maintenance Bypass Switch Graphics provides bypass switches for H2S Plant SIS process alarms (refer to *Annex 2*). Each bypass switch button in the DCS graphics has the name of the equipment and description of the instrument/process alarm.

During normal operation, these bypass switches must be deactivated in order to ensure safe operation of the Plant. Deactivated bypass switch buttons are colored light yellow. In case of maintenance servicing or instrument's testing and calibration the specific button must be clicked by the DCS operator in order to activate the maintenance bypass switch and prevent activation ESD or SIS. Activated bypass switch are colored light brown in order to distinguish it from other switches.



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS				
Manual				
Document Title				
Rev No.	Rev No. Doc No. Page			
01	01 TNH-200-103 (10) 4 of 11			

II. Important Monitoring Items

1. Controllers' Description None

2. Instruments' Description

None

3. Motors

None

4. Actuated Valves

None

5. Switches

1) ESD Maintenance Bypass Switches

Table 2-1: ESD Maintenance Bypass Switches

UZ Description	Process Alarm	Bypass Switch
102/202-UZ-600 –	102/202AC01 Level HH - 102/202-LA-028	102/202LS028BP
Autoclave Shutdown	102/202HX03 Press HH - 102/202-PA-006	102/202PS006BP
Shutdown	102/202AC01 Press HH - 102/202-PA-010	102/202PS010BP
102/202-UZ-620 –	102/202VE04 Level HH - 102/202-LA-036	102/202LS036BP
Steam Shutdown	HP Steam Header Press HH - 102/202-PA-009	102/202PS009BP
	102/202AC01 Comp.1A Acid Flow LL - 102/202-FA-007	102/202FS007BP
	102/202AC01 Comp.1B Acid Flow LL - 102/202-FA-039	102/202FS039BP
	102/202AC01 Comp.1A Acid Press LL - 102/202-PA-023	102/202PS023BP
	102/202AC01 Comp.1A Acid Press LL - 102/202-PA-037	102/202PS037BP
	102/202AG03A Stop - 102/202XA015	102/202XS015BP
102/202-UZ-660 – Acid Shutdown	102/202AG03B Stop - 102/202XA016	102/202XS016BP
	102/202AC01 Comp.7 Level LL - 102/202-LA-029	102/202LS029BP
	102/202AC01 Comp.7 Level LL - 102/202-LA-029	102/202LS029BP
	416TK01 Level LL - 416-LA-001	416LS001BP
	416TK02 Level LL - 416-LA-002	416LS002BP
	416TK03 Level LL – 416-LA-003	416LS003BP



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS Manual			
Document Title			
Rev No.	Rev No. Doc No. Page		
01	TNH-200-103 (10)	5 of 11	

UZ Description	Process Alarm	Bypass Switch
<u> </u>	102/202AC01 HP Air Header Pressure HH	
	- 102/202PA033A	102/202PS033ABP
	102/202AC01 HP Air Header LL Pressure	100/202DC022DDD
	- 102/202PA033B	102/202PS033BBP
102/202-UZ-680 -	Autoclave Shutdown Logic	
HP Air Shutdown	- 102/202-UZ-600	
	HP Air Shutdown Push Button at 200-XA-001	
	- 102/202HS629	
	Electric Power Failure from PSP	
	- 000XA001	
	106VE02 Press HH	106PS003BP
	– 106-PA-003	Tool Goodbi
	106VE02 Level HH	106LS004BP
	– 106-LA-004	1002000181
	106VE01 Press HH	106PS002BP
	- 106-PA-002	
	106VE01 Level HH	106LS003BP
400 117 000 140	- 106-LA-003	
106-UZ-800 – MS	106VE03 Press HH	106PS004BP
Plant Shutdown	- 106-PA-004	
	106VE03 Level HH - 106-LA-005	106LS005BP
	106VE04 Press HH	
	– 106-PA-005	106PS005BP
	106VE04 Level HH	
	- 106-LA-006	106LS006BP
	106CP01AB Press HH	
	- 106-PA-009	106PS009BP
	106SR02 Level LL	
	- 106-LA-501	106LS501BP
	106SR02 O2 HH	400400000
	– 106-AA-002	106AS002BP
	106SR02 Press HH	106DC010DD
	– 106-PA-018	106PS018BP
	106FN01A Stop	106XS054BP
	– 106-XA-054	100/30346F
	106FN01B Stop	106XS055BP
	_ 106-XA-055	ТООЛООООВІ
106-UZ-810 – H2S	106SR02 H2S HH	106AS005ABP
Vent Scrubber	_ 106-AA-005A	
(106SR02)	106SR02 H2S HH	106AS005BBP
Shutdown	- 106-AA-005B	
	106PU41A Stop	106XS050BP
	- 106-XA-050	
	106PU41B Stop - 106-XA-051	106XS051BP
	106SR00 Level LL	
	- 106-LA-510	106LS510BP
	106PU00A Stop	
	– 106-XA-500	106XS500BP
	106PU00B Stop	
	- 106-XA-300	106XS300BP
		1



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS				
	Manual			
Document Title				
Rev No.	Doc No.	Page		
01	TNH-200-103 (10)	6 of 11		

UZ Description	Process Alarm	Bypass Switch
	106SR03 Level LL - 106-LT-601	106LT601BP
	106FN02A Stop - 106-XA-056	106XS056BP
106-UZ-820 –	106FN02B Stop - 106-XA-057	106XS057BP
Scrubber (106SR03)	106PU51A Stop - 106-XA-058	106XS058BP
Shutdown	106PU41B Stop – 106-XA-059	106XS059BP
	106SR03 H2S HH - 106-AA-013A	106AS013ABP
	106SR03 H2S HH - 106-AA-013B	106AS013BBP
106-UZ-800 / 106-	Nitrogen Press LL – 525-PA-001	525PS001BP
UZ-810 / 106-UZ- 820 Common	Instrument Air Press LL – 521-PA-002	521PS002BP

2) H2S (SIS) Maintenance Bypass Switches

Table 2-2: H2S (SIS) Maintenance Bypass Switches

SIS Description	Process Alarm	Bypass Switch
109SIF026 – Process Gas Scrubber	109SR01 Diff Press HH - 109-PDA-057	109PDT057BP
(109SR01) High High Pressure	109SR01 Inlet Press HH - 109-PA-110	1099PT110BP
109-UZ-450 – H2S Conc High High on Emergency Gas	109SR02 H2S Content HH - 109-AA-085A	109AT085ABP
Scrubber (109SR02) Discharge	109SR02 H2S Content HH - 109-AA-085B	109AT085BBP
109SIF059 - H2S	109SR02 H2S Content HH - 109-AA-083A	109AT083ABP
Conc High High on Emergency Gas Scrubber (109SR02)	109SR02 H2S Content HH - 109-AA-083B	109AT083BBP
Discharge	109SR02 H2S Content HH - 109-AA-083C	109AT083CBP
	109SR02 Upper Flow LL - 109-FA-076A	109FT076ABP
109SIF001 -	109SR02 Lower Flow LL - 109-FA-076B	109FT076BBP
Emergency Gas Scrubber (109SR02)	109SR02 Level LL - 109-LA-089	109LT089BP
Unavailable	109SR02 Diff Press HH - 109-PDA-074	109PDT074BP
	109SR02 Inlet Press HH - 109-PA-082	109PT082BP
109-UZ-460 – H2S Conc High High on	109SR03 H2S Content HH - 109-AA-110A	109AT110ABP
Gas Leak Scrubber (109SR03) Discharge	109SR03 H2S Content HH - 109-AA-110B	109AT110BBP



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS Manual			
Document Title			
Rev No.	Doc No.	Page	
01	TNH-200-103 (10)	7 of 11	

SIS Description	Process Alarm	Bypass Switch
400015000 1100	109SR03 H2S Content HH	109AT1083BP
109SIF060 - H2S	- 109-AA-108A	
Conc High High on Gas Leak Scrubber	109SR03 H2S Content HH - 109-AA-108B	109AT108BBP
(109SR03) Discharge	109SR03 H2S Content HH	
(10001100) Bloomargo	- 109-AA-108C	109AT108CBP
	109SR03 Solution Flow LL	400570000
400015000 0	- 109-FA-099	109FT099BP
109SIF003 – Gas	109SR03 Level LL	109LT091BP
Scrubber (109SR03) Unavailable	– 109-LA-091	TUBLIUBIDE
Oriavaliable	109SR03 Diff Press HH	109PDT098BP
	– 109-PDA-098	1001 100001
	109VE05 Inst. Air Press LL	109PT146BP
	- 109-PA-146	
	421DR01A/B Hi Purity N2 Press LL	109PT148BP
400 117 470 114:134:00	- 109-PA-148	
109-UZ-470 – Utilities Unavailable	525NG02 Low Purity N2 Press LL - 109-PA-149	109PT149BP
Unavallable	421VE12 H2 Press LL	
	- 421-PA-026	421PT026BP
	Electric Power Failure	
	- 000-XA-001	000XA001BP
109-UZ-430 – MS	MS Plant Interlock Signal	40074044DDD
Plant Unavailable	– 109-XA-841B	109XA841BBP
	109FT01A/B 2F H2S Content HH	109AT115BP
	– 109-AA-115	IUSATTIODE
	109FT01A/B GF H2S Content HH	109AT116BP
	_ 109-AA-116	100/11/1001
	109VE01 H2S Content HH	109AT212BP
	- 109-AA-212	
	109FT01A/B H2S Content HH - 109-AA-213	109AT213BP
	NE Corner Bound H2S Content HH	
109SIF153g – Area	- 109-AA-214	109AT214BP
H2S Gas Detector	SE Corner Bound H2S Content HH	
High High Trip	- 109-AA-215	109AT215BP
	NW Corner Bound H2S Content HH	400 4 T040DD
	– 109-AA-216	109AT216BP
	SW Corner Bound H2S Content HH	109AT217BP
	– 109-AA-217	109A1Z1/DF
	209VE01 H2S Content HH	209AT212BP
	- 209-AA-212	
	209HX11A/B H2S Content HH	209AT213BP
109SIF102/209SIF202	- 209-AA-213	
- Hydrogen Feed to	109/209VE01 Press HH	109/209PT105BP
Reactor High High	- 109/209-PA-105	
Pressure Trip	109/209VE01 Press HH	109/209PT104BP
	- 109/209-PA-104	700,200. 11015.



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS Manual		
Document Title		
Rev No.	Doc No.	Page
01	TNH-200-103 (10)	8 of 11

SIS Description	Process Alarm	Bypass Switch
109/209-UZ-410 – Quench Column (109/209QC01) High	109/209QC01 Diff Press HH - 109/209-PDA-546A	109/209PDT546ABP
High Differential Pressure	109/209QC01 Diff Press HH - 109/209-PDA-546B	109/209PDT546BBP
109SIF105/209SIF205 – Quench Tower (109/209QC01) Gas Temperature High High Trip	109/209QC01Temperature HH - 109/209-TA-129B	109/209TT129BBP
109SIF111/209SIF211 - H2S Gas Cooler	109/209QC01 Pressure HH - 109/209-PA-547	109/209PT547BP
(109/209HX11AB) High High Pressure Trip	109/209HX11AB Pressure HH - 109/209-PA-210	109/209PT210BP
109SIF153a/209SIF25 3a – H2S Gas Cooler	109/209ST12 H2S Content HH - 109/209-AA-601A	109/209AT601ABP
(109/209HX11AB) Room Gas Detector	109/209BW02 H2S Content HH - 109/209-AA-601B	109/209AT601BBP
High High Trip	From 109/209BW02 to 109SR03 - 109/209-PALL-605	109/209PT605BP
109SIF153b/209SIF25 3b – Knockout Drum	109/209ST13 H2S Content HH - 109/209-AA-602A	109/209AT602ABP
(109/209VE02) Room Gas Detector High	109/209BW03 H2S Content HH - 109/209-AA-602B	109/209AT602BBP
High Trip	From 109/209BW03 to 109SR03 - 109-PALL-606	109/209PT606BP
	109/209ST11 H2S Content HH - 109/209-AA-620A	109/209AT620ABP
109SIF153c/ 209SIF253c – Quench	109/209ST11 H2S Content HH - 109/209-AA-621	109/209AT621BP
Column (109/209QC01) Room	109/209ST11 H2S Content HH - 109/209-AA-622	109/209AT622BP
Gas Detector High High Trip	109/209BW01AB H2S Content HH - 109/209-AA-620B	109/209AT620BBP
	From 109/209BW01AB to 109SR03 - 109-PALL-621	109/209PT621BP
109SIF153d/209SIF25 3d – Quench Column	109/209BW04AB H2S Content HH - 109/209-AA-615	109/209AT615BP
Flange Box Gas Detector High High	109/209BW04AB H2S Content HH - 109/209-AA-616	109/209AT616BP
Trip	From 109/209BW04AB to 109SR03 - 109-PALL-614	109/209PT614BP



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS Manual			
Document Title			
Rev No. Doc No. Page			
01	TNH-200-103 (10)	9 of 11	

SIS Description	Process Alarm	Bypass Switch
	109/209VE01 Temperature HH - 109/209-TA-113	109/209TT113BP
	109/209VE01 Level LL - 109/209-LA-114	109/209LT114BP
	109/209HX10 T.B. Temperature HH - 109/209-TA-134	109/209TT134BP
	109/209HX10 Tube Temperature HH - 109/209-TA-133A	109/209TT133ABP
	109/209HX10 Tube Temperature HH - 109/209-TA-133B	109/209TT133BBP
109SIF104/209SIF204 - Reactor Heater	109/209HX10 Tube Temperature HH - 109/209-TA-133C	109/209TT133CBP
(109/209HX10) Unavailable	109/209HX10 Tube Temperature HH - 109/209-TA-133D	109/209TT133DBP
	109/209HX10 Tube Temperature HH - 109/209-TA-133E	109/209TT133EBP
	109/209HX10 Tube Temperature HH - 109/209-TA-133F	109/209TT133FBP
	109/209HX10 Tube Temperature HH - 109/209-TA-133G	109/209TT133GBP
	109/209HX10 Tube Temperature HH - 109/209-TA-133H	109/209TT133HBP
	109/209HX10 Tube Temperature HH - 109/209-TA-133I	109/209TT133IBP

III.	Interlocks/Controls

None

IV. Control Sequences

None

V. Alarms

None

VI. DCS Emergency Shutdown

None

VII. Trend Graphs Grouping


None



ESD AND H2S MAINTENANCE BYPASS SWITCH DCS Manual

Document Title		
Rev No.	Page No.	
01	TNH-200-103 (10)	10 of 11

Annex 1: ESD MAINTENANCE BYPASS SWITCH DCS Graphics





ESD AND H2S MAINTENANCE BYPASS SWITCH DCS Manual

	Document Title		
	Rev No.	Doc No.	Page No.
	01	TNH-200-103 (10)	11 of 11

Annex 2: H2S MAINTENANCE BYPASS SWITCH DCS Graphics

