

Printer setup and your receipt

Pick a printer for receipts, invoices and the kitchen, and choose what prints on them.

Before you start

The printer has to already be installed in Windows before it will show up here. Plug it in and install its driver first; Settings → Print picks from whatever Windows already knows about.

Choosing a printer

Settings → Print has three sub-tabs: Printer selection, Print stations and Customize receipt. This guide covers the first and third; Print stations, for routing kitchen and bar tickets to different printers, has its own guide.

Printer selection has three rows: Print receipt, Print kitchen ticket and Print invoice. Each gets its own printer from the dropdown, so they do not have to be the same machine. A red mark next to a row means nothing is chosen for it yet.

Once a printer is picked, a gear icon opens its settings: printer type, paper size, header and footer text, number of copies, and the cash drawer.

Windows printer or Generic / Text only

Windows printer is for anything with a proper Windows driver. It gets nicer formatting and lets you choose a paper size of 58mm, 80mm or A4. Your logo prints on it automatically, with nothing to turn on.

Generic / Text only is for a basic thermal printer with no real driver behind it. It sends plain text instead, sized by characters per line rather than a paper size. A shop only ever needs one of the two settings, and switching printer type is what decides which one you see.

A Print logo switch appears only for a Generic printer, but right now it does not do anything: that kind of printer has no way to print an image yet, switch on or off.

Testing it

Print test page, in the same panel, sends a real print with whatever settings you currently have, so you can check them before trusting it to a customer.

Opening the cash drawer

Turn on Open cash drawer on a printer and it pops the drawer every time that printer prints. The exact code that does this differs by printer, so use Find my command: pick your printer's make and model and try each code it offers until the drawer actually opens, then save that one.

More printer settings

An Advanced tab in the same panel has further options: cutting the paper automatically, how many blank lines to feed before it cuts, the character set, and, for a Windows printer on roll paper, printable margins. A receipt printer also has its own barcode option there. Most shops can leave these at their defaults.

Customizing the receipt

Settings → Print → Customize receipt covers what appears on it: currency and decimal places, whether tax totals and the tax name print, which customer details show when a customer is attached to the sale, and an address format you can build from tokens with a live preview.

Your shop's own name, address and logo are set separately, under Management → My company.