

# Printer setup and your receipt

Pick a printer for receipts, invoices and the kitchen, and choose what prints on them.

## Before you start

---

Install the printer in Windows before it will show up here. Plug it in and install its driver first. Settings → Print picks from whatever Windows already knows about.

## Choosing a printer

---

Settings → Print has three sub-tabs: Printer selection, Print stations and Customize receipt. This guide covers the first and third. Print stations, for routing kitchen and bar tickets to different printers, has its own guide.

Printer selection has three rows: Print receipt, Print kitchen ticket and Print invoice. Each gets its own printer from the dropdown, so they do not have to be the same machine. A red mark next to a row means nothing is chosen yet.

Pick a printer, then click its gear icon to open the settings: printer type, paper size, header and footer text, number of copies, and the cash drawer.

## Windows printer or Generic / Text only

---

Windows printer suits anything with a proper Windows driver. It gets nicer formatting and lets you choose a paper size of 58mm, 80mm or A4. Your logo prints automatically, nothing to turn on.

Generic / Text only suits a basic thermal printer with no real driver. It sends plain text instead, sized by characters per line rather than a paper size. A shop only ever needs one of the two; switching printer type decides which settings you see.

A Print logo switch appears only for a Generic printer, but right now it does nothing. That kind of printer cannot print an image yet, switch on or off.

## Testing it

---

Click Print test page, in the same panel, to send a real print with your current settings. Check it before trusting it to a customer.

## Opening the cash drawer

---

Turn on Open cash drawer on a printer and it pops the drawer every time that printer prints. The exact code differs by printer, so use Find my command: pick your printer's make and model, try each code it offers until the drawer opens, then save that one.

## More printer settings

---

An Advanced tab in the same panel holds further options: cutting the paper automatically, how many blank lines to feed before it cuts, the character set, and, for a Windows printer on roll paper, printable margins. A receipt printer also gets its own barcode option there. Most shops can leave these at their defaults.

## Customizing the receipt

---

Settings → Print → Customize receipt covers what appears on it: currency and decimal places, whether tax totals and the tax name print, which customer details show when a customer is attached to the sale, and an address format you can build from tokens with a live preview.

Your shop's own name, address and logo live separately, under Management → My company.