

Namespace Epson.RoboticsShared. ExtensionsAPI

Classes

[IRCXControllerAPI.ControllerSettingValue](#)

Represents a controller setting value.

[IRCXIOAPI.IRCXIOGroup.PortRange](#)

Represents a range of I/O port numbers.

[IRCXMainMenuItemProvider.MenuItem](#)

Represents a menu item.

[IRCXPointAPI.PointsChangedEventArgs](#)

Provides event data for a points change.

[IRCXPointAPI.RCXPointElement](#)

Represents a point element value.

[IRCXPointAPI.RCXPointFileDescriptor](#)

Descriptor for a points file.

[IRCXPreferencesAPI.PreferenceValue](#)

Represents a preference value for Preferences.

[IRCXProjectAPI.ProjectFileInfo](#)

Project file information.

[IRCXProjectAPI.ProjectPropertyValue](#)

Represents a setting value for project properties.

[IRCXProjectExplorerItemProvider.Item](#)

Represents a tree item description.

[IRCXProjectExplorerItemProvider.MenuItem](#)

Represents a context menu item description.

[IRCXRobotManagerAPI.RCXPartialRobotInfo](#)

Provides a partial subset of robot information.

[IRCXRobotManagerAPI.RobotSettingValue](#)

Represents the setting values related to robot configuration.

[IRCXWindowAPI.WebMessage](#)

Represents the common structure of messages exchanged with the web side.

[IRCXWindowAPI.WebViewInfo](#)

Contains definition and configuration details for a WebView component.

[RCXCaption](#)

Represents a caption specified by number or text.

[RCXCommon](#)

Common definitions for interfaces used by RC+ Extensions.

[RCXCommon.RCXSettingValue](#)

Base class for setting values.

Interfaces

[IRCXCaptionGetter](#)

Caption-related API

[IRCXConfiguration](#)

Configuration data access API for RC+ Extensions

[IRCXControllerAPI](#)

Controller API

[IRCXControllerConnectionAPI](#)

Controller Connection API

[IRCXControllerConnectionAPI.IRCXConnection](#)

Connection information.

[IRCXIOAPI](#)

Interface for I/O-related APIs.

[IRCXIOAPI.IRCXIOWatchGroup](#)

I/O group information.

[IRCXIOAPI.IRCXIOLabel](#)

I/O label object.

[IRCXIOAPI.IRCXIOLabel<T>](#)

Represents an I/O label that exposes typed read/write operations.

[IRCXIOAPI.IRCXIOWatcher](#)

I/O data monitoring object.

[IRCXIOAPI.IRCXInputIOLabel<T>](#)

I/O label for input ports.

[IRCXIOAPI.IRCXMemoryIOLabel<T>](#)

I/O label for memory I/O.

[IRCXIOAPI.IRCXOutputIOLabel<T>](#)

I/O label for output ports.

[IRCXLangRxCaption](#)

Language reactive caption

[IRCXMain](#)

RC+ Extensions Main

[IRCXMainMenuItemProvider](#)

Provides main menu items.

[IRCXPointAPI](#)

API related to points.

[IRCXPreferencesAPI](#)

API related to Preferences.

[IRCXProgramEditorAPI](#)

API related to the Program Editor.

[IRCXProgramEditorAPI.IRCXProgramEditor](#)

Represents the Program Editor.

[IRCXProgramExecutionAPI](#)

API related to program execution.

[IRCXProgramExecutionAPI.IRCXFunctionInfo](#)

Function information.

[IRCXProgramExecutionAPI.IRCXGlobalVariable](#)

Global variable object.

[IRCXProgramExecutionAPI.IRCXLocalVariable](#)

Local variable object.

[IRCXProgramExecutionAPI.IRCXModuleVariable](#)

Module variable object.

[IRCXProgramExecutionAPI.IRCXTask](#)

Represents a task object.

[IRCXProgramExecutionAPI.IRCXTask.IRCXCallStackEntry](#)

Represents a call stack entry.

[IRCXProgramExecutionAPI.IRCXVariable](#)

Variable object.

[IRCXProjectAPI](#)

Project-related API.

[IRCXProjectExplorerItemProvider](#)

Interface for providing items for the Project Explorer.

[IRCXProjectFileProvider](#)

Interface for providing additional files for a project.

[IRCXRobotManagerAPI](#)

Robot manager-related API

[IRCXRobotManagerAPI.IRCXJogger](#)

Represents a jog object.

[IRCXRobotManagerAPI.IRCXJointState](#)

Represents the joint state.

[IRCXRobotManagerAPI.IRCXRobotInfo](#)

Provides robot information.

[IRCXUserControlViewModel](#)

Interface for providing a view model for a UserControl hosted in a docking window.

[IRCXWindowAPI](#)

Provides window-related API.

Enums

[IRCXControllerConnectionAPI.IRCXConnection.CnKind](#)

The connection kind.

[IRCXControllerConnectionAPI.IRCXConnection.CnSeries](#)

The controller series.

[IRCXIOAPI.RCXIOKind](#)

The I/O kind.

[RCXMainMenuItemProvider.TopLevelMenu](#)

Specifies the top-level menu.

[RCXPointAPI.RCXPointElement.Elbow](#)

Specifies the elbow configuration.

[RCXPointAPI.RCXPointElement.Hand](#)

Specifies the hand orientation.

[RCXPointAPI.RCXPointElement.Wrist](#)

Specifies the wrist orientation.

[IRCXProgramExecutionAPI.IRCXTask.RCXTaskKind](#)

Represents the kind of a task.

[IRCXProgramExecutionAPI.IRCXTask.RCXTaskState](#)

Represents the state of a task.

[IRCXRobotManagerAPI.RCXJogCartesianAxis](#)

Jog Cartesian axis specification.

[IRCXRobotManagerAPI.RCXJogDistance](#)

Jog step amount (distance increment).

[IRCXRobotManagerAPI.RCXJogJointAxis](#)

Jog joint axis specification.

[IRCXRobotManagerAPI.RCXJogMode](#)

Jog mode specification.

[IRCXRobotManagerAPI.RCXJogSpeed](#)

Jog speed.

[IRCXWindowAPI.ButtonType](#)

Specifies the set of buttons to display in a message box.

[IRCXWindowAPI.ContentState](#)

Represents flags that indicate the current content state.

[IRCXWindowAPI.IconType](#)

Specifies the icon to display in a message box.

[IRCXWindowAPI.ResponseType](#)

Represents the user's response in a message box.

[RCXCaption.TypeTag](#)

Specifies how the caption is defined.

[RCXCommon.RCXResult](#)

Common result codes.

Delegates

[IRCXIOAPI.RCXIODataChangedCallback](#)

Callback invoked when I/O data changes.

[IRCXPointAPI.PointsChangedEventHandler](#)

Represents the delegate for handling points changed events.

[RCXExternalFunction](#)

Delegate for invoking an external function.